

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [TWOMEOW](#) /

› [TWOMEOW KM802 K Cup Coffee Maker Instruction Manual](#)

## TWOMEOW KM802

# TWOMEOW KM802 K Cup Coffee Maker Instruction Manual

Model: KM802

## INTRODUCTION

---

Thank you for choosing the TWOMEOW KM802 K Cup Coffee Maker. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new coffee machine. Please read it thoroughly before first use and keep it for future reference.

## IMPORTANT SAFETY INSTRUCTIONS

---

- Read all instructions before using the appliance.
- Do not immerse the power cord, plug, or the appliance in water or other liquids to protect against electrical shock.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach the plug to the appliance first, then plug the cord into the wall outlet. To disconnect, turn any control to 'off', then remove the plug from the wall outlet.
- Do not use the appliance for other than intended use.
- Scalding may occur if the lid is removed during the brewing cycles.

## PACKAGE CONTENTS

---

- TWOMEOW KM802 Coffee Maker

- K Pod Holder
- Ground Coffee Holder (Reusable Filter)
- Instruction Manual

## PRODUCT OVERVIEW

The TWOMEOW KM802 is a versatile single-serve coffee maker designed for convenience and quality. It features a sleek design, a large removable water reservoir, and a user-friendly control panel.



**Figure 1:** Front view of the TWOMEOW KM802 K Cup Coffee Maker, showcasing its compact design and brewing capabilities for both K-cups and ground coffee.

# Bold Flavor Option

Enjoy a stronger flavor in both hot and cold coffee!



**Figure 2:** Detailed view of the intuitive touch control panel, allowing users to select brew size, coffee type (capsule or ground), and strength (standard or bold).

## SETUP AND FIRST USE

1. **Unpacking:** Carefully remove all packaging materials and labels from the unit.
2. **Initial Cleaning:** Thoroughly clean both the water reservoir and the brew basket before first use. It is recommended to run 3-4 full water cycles without coffee to flush the internal system.
3. **Fill Water Reservoir:** Remove the 52oz water reservoir from the back of the unit. Fill it with fresh, cold water up to the 'MAX' line. Place it back securely onto the coffee maker.

# Removable 52oz Water Tank

Large capacity water tank for easy refilling and cleaning



**Figure 3:** The 52oz removable water tank, designed for easy refilling and cleaning, minimizing the need for frequent refills.

4. **Power Connection:** Plug the power cord into a grounded electrical outlet. The machine will power on and enter standby mode.

## OPERATING INSTRUCTIONS

### Brewing Hot Coffee

Your TWOMEOW KM802 coffee maker offers flexibility to brew hot coffee using either K-cups or your preferred ground coffee.

### Using K-Cups

1. Lift the handle to open the K-cup chamber.
2. Insert a standard K-cup into the K Pod Holder.

3. Place the K Pod Holder with the K-cup into the chamber and close the handle firmly.
4. Place your coffee mug on the drip tray.
5. Select your desired brew size (6, 8, 10, 12, or 14 oz) using the 'SIZE' button.
6. Press the 'CAPSULE' button to begin brewing.

### **Using Ground Coffee**

1. Lift the handle to open the K-cup chamber.
2. Fill the reusable Ground Coffee Holder with your desired amount of ground coffee (refer to specifications for recommended ratios).
3. Place the Ground Coffee Holder into the chamber and close the handle firmly.
4. Place your coffee mug on the drip tray.
5. Select your desired brew size (6, 8, 10, 12, or 14 oz) using the 'SIZE' button.
6. Press the 'GROUND' button to begin brewing.

# 5 Brewing Capacities



**Figure 4:** The 3-in-1 compatibility feature, allowing use of K-pods, ground coffee, or tea with dedicated holders.

**Video 1:** Official TWOMEOW video demonstrating the K Cup Coffee Maker with Bold Setting, including how to use both K-cups and ground coffee.

## Brewing Iced Coffee

1. Fill your cup with ice cubes.
2. Prepare your K-cup or ground coffee as described above.
3. Place the cup with ice on the drip tray.
4. Select your desired brew size (6, 8, 10, 12, or 14 oz) using the 'SIZE' button.
5. Press the 'OVER ICE' button to begin brewing. The machine will brew a concentrated coffee over ice.

# Heat And Ice The Choice Is Your



**High-temp**



**Lower-temp**  
Lower-Temp Brew Setting



**Figure 5:** The control panel highlighting the 'OVER ICE' option for brewing refreshing iced coffee.

## Brew Size Selection

The coffee maker offers five brewing capacities to suit your preference:

- 6 oz
- 8 oz
- 10 oz
- 12 oz
- 14 oz

Use the 'SIZE' button to cycle through the available options until your desired volume is displayed.

# 3-in-1 Compatibility

Compatible with K Cup & Grounds & Tea  
The Parts are Removable and  
Dishwasher Safe



Figure 6: The display showing the different brew size options available for customization.

## Bold Setting

For a stronger flavor, activate the 'BOLD' setting. This option is available for both hot and iced coffee brewing.

1. After selecting your brew size, press the 'BOLD' button to toggle between 'STANDARD' and 'STRONGER' strength.
2. The display will indicate the selected strength.

# Bold Flavor Option

Enjoy a stronger flavor in both hot and cold coffee!



Figure 7: Visual representation of the 'BOLD' setting, offering a choice between standard and stronger coffee flavors.

## Removable Drip Tray

The removable drip tray accommodates various cup heights, including travel mugs up to 6.8 inches, minimizing spills and ensuring compatibility.

# Removable Drip Tray

The removable drip tray allows for use with taller cups, ensuring compatibility with various cup heights.



Figure 8: The removable drip tray, designed to fit taller cups and travel mugs.

## MAINTENANCE

### Cleaning

- **Exterior:** Wipe the exterior of the coffee maker with a damp cloth. Do not use abrasive cleaners.
- **Water Reservoir:** The water reservoir can be removed and washed with warm, soapy water. Rinse thoroughly.
- **K Pod Holder & Ground Coffee Holder:** These components are removable and dishwasher safe for easy cleaning.
- **Drip Tray:** The drip tray and its cover can be removed and washed with warm, soapy water.

## Descaling

Over time, mineral deposits can build up in your coffee maker, affecting performance and taste. The TWOMEOW KM802 features a descaling reminder.

- When the 'DESCALING' indicator light flashes, it is time to descale your machine.
- To descale, fill the water reservoir with a descaling solution (e.g., vinegar and water mixture) or a commercial descaling agent according to the product instructions.
- Place a large mug on the drip tray.
- Press and hold the 'OVER ICE' button for 3 seconds to initiate the descaling cycle.
- Repeat the process with fresh water to rinse the system thoroughly.



**Figure 9:** The descaling indicator on the control panel, prompting users to perform a descaling cycle.

**Video 2:** A video demonstrating the descaling process and the descaling indicator on the TWOMEOW KM802 coffee maker.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Coffee maker does not turn on.	Not plugged in or power outage.	Ensure the power cord is securely plugged into a working outlet. Check your circuit breaker.
Coffee not brewing.	Water tank empty or not properly seated. K-cup/Ground holder not properly inserted.	Fill the water tank and ensure it is correctly placed. Verify the K-cup or Ground holder is securely in place and the lid is closed.
Coffee tastes weak.	Incorrect coffee-to-water ratio or 'BOLD' setting not activated.	Adjust the amount of ground coffee or select the 'STRONGER' option using the 'BOLD' button. Consider a smaller brew size.
Coffee is not hot enough.	Pre-heating cycle not complete.	Allow the machine to complete its pre-heating cycle before brewing. Ensure the water reservoir is filled with cold water.
'DESCALING' light is flashing.	Mineral buildup in the machine.	Perform a descaling cycle as described in the Maintenance section.

## SPECIFICATIONS

---

- **Brand:** TWOMEOW
- **Model Name:** KM802
- **Color:** Gray
- **Product Dimensions:** 11.4"D x 5.28"W x 13"H
- **Water Tank Capacity:** 52 oz (Removable)
- **Brewing Capacities:** 6, 8, 10, 12, 14 oz
- **Compatibility:** K-pods, Ground Coffee, Tea
- **Special Features:** 3-in-1, Removable Water Tank, Bold Setting, 5 Brewing Capacities, Removable Drip Tray, Energy Efficient (Auto-off after 5 minutes)
- **Operation Mode:** Fully Automatic
- **Human Interface Input:** Touchscreen
- **Item Weight:** 4.91 pounds

## WARRANTY AND SUPPORT

---

The TWOMEOW KM802 K Cup Coffee Maker comes with a **2-year warranty** and a **6-month replacement service**. For technical support or any inquiries, please contact us directly via email at [support@twomeow.com](mailto:support@twomeow.com). Our customer service team is dedicated to providing prompt assistance.