

## SGIN GE8300

# SGIN Android Tablet 10.1 Inch Model GE8300 User Manual

Brand: SGIN | Model: GE8300

## 1. INTRODUCTION

Welcome to the user manual for your SGIN Android Tablet 10.1 Inch, Model GE8300. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your new tablet. Designed with children in mind, this tablet features a durable case, parental controls, and pre-installed educational content through Kidoz software. Please read this manual thoroughly to ensure proper use and to maximize your tablet's potential.

## 2. PRODUCT OVERVIEW

The SGIN Android Tablet 10.1 Inch is equipped with a 10.1-inch HD IPS display, a quad-core processor, 4GB RAM, and 64GB of internal storage. It runs on Android 13 and includes a protective case with an adjustable bracket.

## Smoother operation, larger storage space



  
2.4+5G WiFi

  
Front 2MP  
Rear 5MP

  
2+64GB

  
32G Expansion

  
Quad-core  
A133

  
Bluetooth 4.2

  
Android 12

  
5000 mAh

Image: SGIN Android Tablet 10.1 Inch with its protective blue case and yellow butterfly stand.

### Tablet Components

**SGIN Supports 2.4G & 5G  
WiFi and Bluetooth 4.2**

Easy to connect, happy to share

providing a better network  
connection with lower  
latency, stronger signals,  
and faster speeds. Whether  
you are watching movies,  
playing games with friends,  
or watching videos online,  
it is always smooth and stable

A blue protective case for a tablet is shown from the front. The screen displays a colorful cartoon game with two bears and a basket of fruit. The case has a yellow butterfly-shaped stand attached to the center.

1. **Front Camera:** For video calls and selfies.
2. **Rear Camera:** For taking photos and videos.
3. **Speakers:** For audio output.
4. **Type-C Port:** For charging and data transfer.
5. **TF Card Slot:** For expandable storage.
6. **Headphone Jack:** For connecting wired headphones.
7. **Increase Volume:** Button to raise the audio level.
8. **Reduce Volume:** Button to lower the audio level.
9. **Bracket:** Adjustable stand integrated into the protective case.

## 3. SETUP

---

### 3.1 Charging the Tablet

Before first use, fully charge the tablet using the provided Type-C cable and power adapter. The 5000mAh battery provides approximately 6-8 hours of usage on a full charge. A charging indicator will typically appear on the screen.

### 3.2 Powering On/Off

- **To Power On:** Press and hold the power button (usually located on the side) until the SGIN logo appears.
- **To Power Off:** Press and hold the power button, then select 'Power Off' from the options on the screen.
- **To Restart:** Press and hold the power button, then select 'Restart' from the options.

### 3.3 Initial Setup and Wi-Fi Connection

Upon first power-on, follow the on-screen prompts to complete the initial Android 13 setup. This includes selecting your language, region, and connecting to a Wi-Fi network. The tablet supports both 2.4G and 5G Wi-Fi for stable internet connectivity.

1. Go to **Settings > Network & internet > Wi-Fi**.
2. Toggle Wi-Fi **On**.
3. Select your desired network from the list.
4. Enter the password if prompted, then tap **Connect**.

## 4. OPERATING INSTRUCTIONS

---

### 4.1 Basic Navigation

The tablet uses a touch-sensitive screen for navigation. Common gestures include tapping to select, swiping to scroll, pinching to zoom, and long-pressing for additional options.

### 4.2 Camera Usage

The tablet features a 2MP front-facing camera and a 5MP rear camera. To use the camera:

1. Open the **Camera** application.
2. Select between front and rear cameras using the switch icon.
3. Tap the shutter button to take a photo or start/stop video recording.

### 4.3 Storage Management

The tablet comes with 64GB of internal storage. If more space is needed, you can expand it by inserting a TF (microSD) card into the TF card slot. The tablet supports expansion up to 34GB.

### 4.4 Bluetooth Connectivity

The tablet supports Bluetooth 4.2 for connecting to wireless accessories such as headphones or speakers.

1. Go to **Settings > Connected devices > Connection preferences > Bluetooth**.
2. Toggle Bluetooth **On**.
3. Select your device from the list of available devices to pair.

## 5. PARENTAL CONTROL FEATURES

---

The SGIN tablet includes a built-in parental control security system to manage your child's usage and content access.

- **Set Passwords:** Create a password to secure parental control settings.
- **Screen Time Limits:** Define daily usage limits for the tablet.
- **Content Filtering:** Eliminate unwanted ads and create specific media files or approved websites for your children.
- **Multiple Accounts:** Set up individual accounts for each child, allowing personalized settings and content access.

## 6. KIDOZ KIDS SOFTWARE

---

The tablet comes with the Kidoz Kid's software pre-installed, offering a safe and engaging environment for children.

- **Accessing Kidoz:** Launch the Kidoz app from the home screen.
- **Kids Store:** Explore thousands of free games and educational apps available for download within the Kidoz environment.
- **Educational Content:** Kidoz provides content that supports learning in subjects like math, language, music, and painting.

## 7. MAINTENANCE

---

### 7.1 Cleaning

Use a soft, lint-free cloth to clean the screen and the tablet's body. For stubborn smudges, slightly dampen the cloth with water. Avoid harsh chemicals or abrasive materials.

### 7.2 Battery Care

To prolong battery life, avoid exposing the tablet to extreme temperatures. Charge the tablet regularly and avoid letting the battery completely drain frequently.

### 7.3 Software Updates

Periodically check for system updates to ensure optimal performance and security. Go to **Settings > System > System update**.

### 7.4 Protective Case

The included kid-proof case is designed to protect the tablet from dust, bumps, and drops. It also features a hollow design for heat dissipation. Ensure the tablet is properly seated within the case for maximum protection.

# Children's Tablet Function Details




Image: The durable anti-drop protective case with its adjustable bracket.

## 8. TROUBLESHOOTING

If you encounter issues with your SGIN tablet, refer to the following common solutions:

- **Tablet Not Powering On:** Ensure the tablet is charged. Connect it to the charger and wait a few minutes before attempting to power it on again.
- **Unresponsive Screen:** If the screen becomes unresponsive, try restarting the tablet by holding down the power button for approximately 10-15 seconds until it powers off, then power it on normally.
- **Wi-Fi Connection Issues:** Check if other devices can connect to the Wi-Fi network. Restart your Wi-Fi router. On the tablet, forget the network and reconnect.
- **Slow Performance:** Close unused applications running in the background. Clear cache data for apps. Consider performing a factory reset if performance issues persist (back up important data first).
- **Apps Crashing:** Ensure apps are updated to their latest versions. Clear the app's cache and data via **Settings > Apps > [App Name] > Storage & cache**.

For issues not resolved by these steps, please contact customer support.

## 9. SPECIFICATIONS

Key technical specifications for the SGIN Android Tablet 10.1 Inch Model GE8300:

Feature	Specification
Model Number	GE8300
Screen Size	10.1 Inches
Display Resolution	1280 x 800 pixels (HD IPS)
Processor	1.6 GHz Quad-core (Allwinner A133)
RAM	4GB (2GB physical + 2GB expandable)

Internal Storage	64GB ROM
Expandable Storage	Up to 34GB via TF Card
Operating System	Android 13
Battery Capacity	5000mAh
Front Camera	2MP
Rear Camera	5MP
Wireless Connectivity	2.4G/5G WiFi, Bluetooth 4.2
Color	Deep Blue
Parcel Dimensions	32.2 x 20.4 x 4.7 cm; 1.04 kg

## 10. WARRANTY AND SUPPORT

---

### 10.1 Product Warranty

The SGIN Android Tablet 10.1 Inch Model GE8300 comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. Please retain your proof of purchase for warranty claims.

### 10.2 Customer Support

If you require further assistance or have questions not covered in this manual, please contact SGIN customer support. Refer to the product packaging or the official SGIN website for the most current contact information.