

EMEET E3402

EMEET C60E Dual-Camera 4K Webcam User Manual

Model: E3402

1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your EMEET C60E Dual-Camera 4K Webcam. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.



Image: The EMEET C60E Dual-Camera 4K Webcam shown with its included remote control.

2. WHAT'S IN THE BOX

Verify that all items are present in the package:

- C60E Dual-Camera 4K Webcam
- Remote Control (batteries not included)
- Privacy Cover
- USB 2.0 Cable

A Webcam with Everything You Need in the Box

- 1 EMEET C60E Dual-Camera 4K Webcam
- 2 Remote Control
- 3 Privacy Cover
- 4 User Manual
- 5 Quality Manual

Note: The included remote control is compatible with 2 AAA batteries (batteries not included and need to be purchased separately).



Image: An illustration showing the EMEET C60E webcam, remote control, privacy cover, USB cable, and manuals included in the box.

3. SETUP

3.1 Connecting the Webcam

1. Connect the integrated USB 2.0 Type-A cable from the webcam to an available USB port on your computer.
2. The webcam is plug-and-play and should be automatically recognized by your operating system (Windows 10/11 64-bit, macOS 10.14+).

3.2 Mounting the Webcam

The EMEET C60E offers flexible mounting options:

- **Monitor Clip:** The integrated clip allows secure placement on top of most computer monitors or laptop screens. Adjust the clip to fit the thickness of your display.
- **Tripod Mounting:** For alternative setups, the webcam features a standard 1/4" tripod screw hole on its base. This allows attachment to tripods, stands, or other mounting accessories (tripod not included).

Set It Up Your Way

Mount on any standard tripod and enjoy hands-free, stable streaming



Image: The EMEET C60E webcam shown mounted on a small tripod, connected to a laptop via its USB cable. This demonstrates flexible setup options.

3.3 Installing the Privacy Cover

The included privacy cover can be attached over the camera lenses when not in use to ensure privacy.

1. Align the privacy cover with the camera lenses.
2. Gently press it into place until it is securely attached.

3.4 Remote Control Setup

The remote control requires 2 AAA batteries (not included). Insert the batteries according to the polarity markings inside the battery compartment.

3.5 Software Installation (Optional)

For advanced control and customization, download the EMEET STUDIO software from the official EMEET website. While the webcam functions without it, EMEET STUDIO provides access to features like brightness, focus, and RGB lighting adjustments.

Compatible with Your Devices, Protects Your Privacy



Supports: Windows 10 and above (64-bit), macOS 10.14 and above
Not Supports: ARM-based Windows



Image: A graphic illustrating the wide compatibility of the EMEET C60E webcam with platforms like OBS, Twitch, Xsplit, ManyCam, Facebook, YouTube, and operating systems Windows 10/11 (64-bit) and macOS 10.14+.

4. OPERATING INSTRUCTIONS

4.1 Dual-Camera Functionality

The EMEET C60E features two cameras sharing a 1/2.8" CMOS 4K sensor:

- **Wide-Angle Camera (Left):** Captures panoramic scenes, suitable for showing a broader environment or multiple participants.
- **Telephoto Camera (Right):** Provides detailed close-ups, ideal for focusing on specific objects or individuals at a recommended distance of 13.8 inches.

You can switch between these views using the remote control or EMEET STUDIO software.

Dual-Camera Wide or Zoom, All in One



Wide-Angle View

Capture people, products
& scenes in one frame



11X Telephoto Zoom

Show jewelry, fashion &
beauty in vivid detail



Image: A close-up of the EMEET C60E's dual lenses, illustrating the wide-angle view for capturing scenes and the 11X telephoto zoom for detailed close-ups.


4.2 Hybrid Zoom and Autofocus

The webcam supports up to 11X hybrid zoom, allowing seamless transitions from a full-scene panorama to a clear close-up. PDAF (Phase Detection Autofocus) ensures stable, clear, and fast focusing during zoom operations.

- Zoom levels include 1X, 3X, 5X, 7X, and Max 11X.
- **Note:** Zoom functionality is not supported in 4K, 60FPS, or YUY2 modes.

Max 11X Zoom From Panorama to Close-Up

Autofocus for Instant Detail



1X

3x

5x

7x

9x

11X

Note: Zoom not supported in 4K, 60FPS, or YUY2 modes.

Image: A split image demonstrating the difference between a 1X zoom (full panorama) and an 11X zoom (clear close-up) using the webcam, with a zoom slider indicating available levels.

PDAF Fast Autofocus

Lock onto faces or products instantly for sharp, clear details




Image: A woman holding a lipstick, with a green square indicating the PDAF autofocus locking onto her face or the product for sharp details.

4.3 Remote Control Functions

The included 22-key remote control provides convenient access to various camera settings without needing

to interact with software:

Button	Function
Reset	Restores image to initial state.
Switch	Switches between Wide-Angle and Telephoto Cameras.
Flip	Rotates image 180° vertically.
Sharpness +/-	Increases/Decreases image sharpness.
3X/5X/7X/11X	Magnifies image 3, 5, 7, or 11 times.
Color +/-	Increases/Decreases image color saturation.
Focus	Switches between Autofocus and Fixed Focus.
Mirror	Flips image 180° horizontally.
Zoom In/Out	Enlarges/Reduces image display.
1X	Restores image to original size.
Brightness +/-	Increases/Decreases image brightness.
Image Effect 1/2/3/4	Switches between various image effects.



Image: A detailed diagram of the EMEET C60E's 22-key remote control, with each button clearly labeled for its specific function, such as zoom, focus, color, and image effects.

4.4 EMEET STUDIO Software Control

For fine-tuning and advanced features, use the EMEET STUDIO software:

- Adjust brightness, contrast, and color saturation.
- Control focus modes (autofocus/manual focus).
- Customize RGB lighting effects.
- Access advanced tools including AIGC and Desktop Mode.

Smart Control with EMEET STUDIO

From basics like Brightness, Zoom & Focus to advanced tools including RGB effects, AIGC, and Desktop Mode




Image: A screenshot of the EMEET STUDIO software interface, showing various controls for brightness, contrast, zoom, focus, and RGB effects, with a live preview of the webcam feed.

4.5 RGB Lighting

The webcam features integrated RGB lighting (red, green, blue) that serves both aesthetic and functional purposes:

- **Visual Indication:** The lighting helps users easily locate the camera and indicates its active status.
- **Customization:** Colors can be adjusted via EMEET STUDIO to match personal preferences or specific moods.

Light Up Your Style with RGB

Choose Red, Green, or Blue — personalize your vibe in EMEET STUDIO



Image: The EMEET C60E webcam displayed with its RGB lighting set to red, green, and blue, showcasing the customizable illumination options.

4.6 Audio Capture

The C60E is equipped with two noise-canceling microphones designed to capture clear, natural sound within a 9.8ft radius, ensuring high-quality audio for meetings, classes, or live streaming.

2 Noise-Canceling Microphones

Sound Pickup Range is Radius 9.8 ft



Image: A man using a laptop with the EMEET C60E webcam, illustrating the 9.8ft sound pickup radius of its noise-canceling microphones during an online meeting.

4.7 Landscape & Portrait Modes

The webcam supports both horizontal (landscape) and vertical (portrait) video orientations, offering versatility for various content creation and streaming needs.




Image: A split image showing the EMEET C60E webcam capturing video in both horizontal (landscape) and vertical (portrait)

modes, demonstrating its adaptability for different content formats.

5. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the webcam's exterior. For lenses, use a lens cleaning cloth and solution specifically designed for optical surfaces. Avoid abrasive materials or harsh chemicals.
- **Storage:** When not in use, store the webcam in a cool, dry place. Use the privacy cover to protect the lenses from dust and scratches.
- **Cable Care:** Avoid bending or twisting the USB cable excessively to prevent damage.

6. TROUBLESHOOTING

6.1 Webcam Not Detected

- Ensure the USB cable is securely connected to both the webcam and your computer.
- Try connecting the webcam to a different USB port on your computer.
- Restart your computer.
- Check your operating system's device manager or system information to see if the webcam is listed.

6.2 Image is Blurry or Out of Focus

- Ensure the protective film (if any) has been removed from the lenses.
- Clean the camera lenses with a soft, lint-free cloth.
- If using EMEET STUDIO, check the focus settings and ensure autofocus is enabled or adjust manual focus.
- Use the remote control to adjust focus or reset the image.

6.3 Remote Control Not Responding

- Check and replace the AAA batteries in the remote control.
- Ensure there are no obstructions between the remote control and the webcam.

6.4 EMEET STUDIO Software Issues

- Ensure you have the latest version of EMEET STUDIO installed from the official EMEET website.
- If experiencing issues, try using your operating system's built-in camera application (e.g., Windows Camera app) as a primary interface, as the webcam is designed for plug-and-play functionality.

7. SPECIFICATIONS




Feature	Detail
Brand	EMEET
Model Number	E3402
Item Weight	9.9 ounces
Package Dimensions	5.98 x 5.12 x 1.93 inches
Color	Black




Feature	Detail
Photo Sensor Technology	CMOS
Video Capture Resolution	4K
Connectivity Technology	USB 2.0 Type-A
Optical Zoom	11x Hybrid Zoom
Microphones	2 Noise-Canceling Mics (9.8ft radius)
Special Features	Dual-Camera (Wide-angle & Telephoto), PDAF Autofocus, Remote Control, RGB Lighting
Compatibility	Windows 10/11 (64-bit), macOS 10.14+, OBS, Twitch, YouTube, Facebook

8. WARRANTY AND SUPPORT

The EMEET C60E Dual-Camera 4K Webcam comes with a **2-year warranty**. EMEET also provides **lifetime professional technical support**. For further assistance, troubleshooting, or warranty claims, please visit the official EMEET support website or contact their customer service. You can find more information and contact details on the [EMEET Store on Amazon](#).

Related Documents - E3402

	EMEET C970L HD Webcam Quick Start Guide and User Information Concise guide for the EMEET C970L HD Webcam, covering setup, privacy features, software, warranty, and safety. Includes multilingual instructions and compliance details.
	EMEET SmartCam C60E 4K Dual Quick Start Guide Quick start guide for the EMEET SmartCam C60E 4K Dual webcam, covering setup, connection, privacy cover installation, remote control, and software personalization.
	EMEET SmartCam Quick Start Guide This guide provides quick start instructions for the EMEET SmartCam, covering installation, usage, and troubleshooting tips in multiple languages.

	<p>eMeet Smart Webcam User Manual</p> <p>User manual for the eMeet Smart Webcam, covering installation, usage, EMEETLINK software, warranty, and safety guidelines.</p>
	<p>EMEET SmartCam Quick Start Guide</p> <p>A quick start guide for the EMEET SmartCam, providing instructions on installation, usage, and warranty information in multiple languages.</p>
	<p>EMEET PIXY User Manual and Guide</p> <p>Comprehensive guide to the EMEET PIXY, a smart camera with AI tracking and multiple shooting modes. Learn about its components, setup, connection, operation, and software features.</p>