

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Hawk Gaming](#) /

› [Hawk Gaming HK258 Membrane LCD RGB Wireless/Bluetooth Gaming Keyboard User Manual](#)

Hawk Gaming HK258

Hawk Gaming HK258 Membrane LCD RGB Wireless/Bluetooth Gaming Keyboard User Manual

Model: HK258

1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your Hawk Gaming HK258 Membrane LCD RGB Wireless/Bluetooth Gaming Keyboard. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

The HK258 keyboard features a membrane design, an integrated LCD display, RGB backlighting, and versatile connectivity options including wireless 2.4GHz and Bluetooth, in addition to a wired connection.

2. SAFETY INFORMATION

- Keep the keyboard away from liquids and excessive moisture.
- Avoid exposing the keyboard to extreme temperatures.
- Do not attempt to disassemble or modify the keyboard. This may void the warranty and cause damage.
- Use only the provided charging cable or a certified equivalent.
- Clean the keyboard with a soft, dry cloth. Avoid harsh chemicals.

3. PACKAGE CONTENTS

Ensure all items are present in the package:

- Hawk Gaming HK258 Keyboard
- USB-C to USB-A Cable (for wired connection and charging)
- 2.4GHz Wireless Receiver (typically stored in the keyboard's battery compartment or a dedicated slot)
- User Manual (this document)

4. PRODUCT OVERVIEW

Familiarize yourself with the layout and key features of your HK258 keyboard.



Figure 4.1: Top-down view of the HK258 keyboard. This image displays the full Turkish QWERTY layout, including the numeric keypad, function keys (F1-F12), and dedicated multimedia keys. The LCD screen is visible on the top right, next to a rotary knob, and the overall color scheme is grey and purple.



Figure 4.2: Angled view of the HK258 keyboard. This perspective shows the ergonomic keycap profile and provides a glimpse of the RGB backlighting beneath the keys. The grey and purple keycaps are clearly visible.



Figure 4.3: Rear view of the HK258 keyboard. This image focuses on the back edge of the keyboard, revealing the 2.4G/OFF/BT mode switch and the USB-C port for charging and wired connection. The adjustable feet are also visible.

Key Features:

- **Triple Mode Connectivity:** Wired (USB-C), 2.4GHz Wireless, and Bluetooth.
- **Membrane Switches:** For a quiet and comfortable typing experience.
- **RGB Backlighting:** Customizable lighting effects.
- **Integrated LCD Display:** Shows connection status, battery level, and other information.
- **Multimedia Control Knob:** For volume adjustment and other functions.
- **Full Turkish Layout:** Designed for Turkish language users.

5. SETUP

5.1 Wired Connection

1. Locate the USB-C port on the back of the keyboard.
2. Connect one end of the provided USB-C cable to the keyboard and the other end to an available USB-A port on your computer.
3. Ensure the connectivity switch on the back of the keyboard is set to the "OFF" position. The keyboard will automatically switch to wired mode.
4. Your computer should recognize the keyboard automatically.

5.2 2.4GHz Wireless Connection

1. Locate the 2.4GHz wireless receiver. It is usually stored in a compartment on the keyboard's underside or near the USB-C port.
2. Plug the 2.4GHz receiver into an available USB-A port on your computer.
3. Set the connectivity switch on the back of the keyboard to the "2.4G" position.
4. The keyboard should connect automatically. The LCD display will indicate the 2.4G connection status.

5.3 Bluetooth Connection

1. Set the connectivity switch on the back of the keyboard to the "BT" position.
2. The keyboard will enter pairing mode. The LCD display may show a blinking Bluetooth icon or "BT Pairing".
3. On your computer or device, open Bluetooth settings.
4. Search for new devices and select "HK258" (or similar name) from the list.
5. Follow any on-screen prompts to complete the pairing process. The LCD display will confirm a successful connection.
6. To pair with another Bluetooth device, you may need to press and hold a specific key combination (e.g., Fn + BT1/BT2/BT3) to switch between Bluetooth profiles or initiate pairing mode again. Refer to the LCD display for current Bluetooth channel.

5.4 Charging the Keyboard

The keyboard is equipped with a rechargeable battery. When the battery is low, the LCD display will indicate a low battery warning.

- Connect the USB-C cable to the keyboard's USB-C port and the other end to a powered USB port (e.g., computer, USB wall adapter).
- The LCD display will show a charging indicator.
- Charging time may vary. Disconnect the cable once fully charged to preserve battery life.

6. OPERATING INSTRUCTIONS

6.1 Basic Key Functions

The HK258 features a standard full-size Turkish QWERTY layout. All keys function as labeled. The **Fn** key can be used in combination with other keys for additional functions.

6.2 RGB Lighting Control

The keyboard offers various RGB lighting effects. Use the following key combinations to control the lighting:

- **Fn + [Key]**: (Specific key combinations for lighting effects are usually printed on the keycaps or detailed in a quick

start guide. As this information is not provided, a general instruction is given.) Experiment with Fn combinations, typically involving arrow keys or dedicated lighting keys, to change modes, brightness, and speed.

6.3 LCD Display Functions

The integrated LCD display provides real-time information:

- **Connection Mode:** Indicates whether the keyboard is in Wired, 2.4G, or Bluetooth mode.
- **Battery Level:** Shows the current battery charge.
- **Caps Lock/Num Lock Indicator:** Displays the status of these lock keys.
- **Bluetooth Channel:** If in Bluetooth mode, it may indicate which paired device (BT1, BT2, BT3) is currently active.

6.4 Multimedia Control Knob

The rotary knob located near the LCD display typically controls multimedia functions:

- **Rotate:** Adjusts system volume (clockwise to increase, counter-clockwise to decrease).
- **Press:** Mutes/unmutes audio.
- (Additional functions may be available by pressing and holding or combining with Fn key, refer to product specific documentation if available.)

6.5 Switching Connection Modes

Use the physical switch on the back of the keyboard to select your desired connection mode: "2.4G", "OFF" (for wired mode), or "BT".

7. MAINTENANCE

7.1 Cleaning

- Disconnect the keyboard from all power sources and devices before cleaning.
- Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution to wipe the surface.
- For dust and debris between keycaps, use compressed air or a small brush.
- Do not spray cleaners directly onto the keyboard.

7.2 Storage

- Store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures.
- If storing for an extended period, ensure the battery is partially charged (around 50%) to prolong its lifespan.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Keyboard not responding (Wired)	Loose cable connection, incorrect switch position.	Ensure USB-C cable is securely connected. Set the mode switch to "OFF" (wired mode). Try a different USB port.
Keyboard not responding (2.4GHz Wireless)	Receiver not plugged in, incorrect switch position, low battery.	Ensure 2.4GHz receiver is plugged into a USB port. Set the mode switch to "2.4G". Charge the keyboard.
Keyboard not responding (Bluetooth)	Not paired, incorrect switch position, low battery, interference.	Set the mode switch to "BT". Re-pair the keyboard with your device. Charge the keyboard. Move closer to the device or reduce interference.

Problem	Possible Cause	Solution
Keys are fading / lettering wearing off	Normal wear and tear, aggressive cleaning.	This can occur with prolonged use. Use gentle cleaning methods.
Cannot assign custom key functions / No driver software	Product may not support custom key assignments via software.	The HK258 may not have dedicated driver software for advanced customization. Functions are typically hardware-based.
Keyboard needs to be reset	Software glitch, unexpected behavior.	Press Fn + Esc simultaneously to perform a factory reset.

9. SPECIFICATIONS

Feature	Detail
Brand	Hawk Gaming
Model	HK258
Keyboard Description	Membrane
Connectivity	Wired (USB-C), 2.4GHz Wireless, Bluetooth
Color	Grey Purple
Layout	Full Turkish QWERTY
Battery Required	No (Integrated rechargeable battery)
Package Dimensions	45.1 x 14.2 x 4.9 cm
Item Weight	990 grams
Country of Origin	China

10. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the retailer or the official Hawk Gaming website. Keep your proof of purchase for any warranty claims.

Manufacturer: Hawk Gaming Chair

