



Manuals.plus /

- › [ghd](#) /
- › [ghd Chronos Curve Max Wand 1.5" Barrel Curling Wand Instruction Manual](#)

ghd Chronos Curve Max Wand

ghd Chronos Curve Max Wand 1.5" Barrel Curling Wand Instruction Manual

Model: Chronos Curve Max Wand

1. INTRODUCTION

The ghd Chronos Curve Max Wand is designed to create loose, voluminous waves with advanced responsive technology. This manual provides essential information for safe and effective use, maintenance, and troubleshooting.



Image: The ghd Chronos Curve Max Wand, a professional curling wand with a 1.5-inch barrel.

2. SAFETY INFORMATION

- Always ensure the appliance is switched off and unplugged when not in use.
- Do not use near water or immerse in liquid.
- Keep out of reach of children.
- Allow the wand to cool completely before storing.
- Use the provided protective styling glove to prevent burns.
- If the cord is damaged, it must be replaced by the manufacturer or a qualified service agent to avoid hazards.

3. SETUP

3.1 Unboxing

Carefully remove the ghd Chronos Curve Max Wand from its packaging. Ensure all components, including the protective styling glove and power cable, are present.

Your browser does not support the video tag.

Video: An unboxing demonstration of the ghd Chronos Curve Max Wand, showing the product and its accessories being removed from the packaging.

3.2 Initial Power On

1. Plug the power cable into a suitable electrical outlet.
2. Press and hold the power button until the indicator light illuminates.
3. The wand will heat up to its optimal styling temperature of 365°F in approximately 50 seconds. A beep will indicate it is ready for use.

3.3 Using the Protective Styling Glove

For added safety and comfort during styling, wear the provided protective styling glove on the hand that will be wrapping the hair around the hot barrel.

4. OPERATING INSTRUCTIONS

4.1 Optimal Temperature

The ghd Chronos Curve Max Wand maintains a consistent optimal styling temperature of 365°F across the entire barrel. This temperature is scientifically proven to deliver effective styling results without causing extreme heat damage to your hair. No temperature dial is needed.



Image: A close-up of the ghd Chronos Curve Max Wand showing the power button and an illustration of the 365°F optimal styling temperature, indicating "No Style: Too Cool" below 300°F and "Damage Zone: Too Hot" above 380°F.

4.2 Styling Steps for Loose Waves

Follow these steps to achieve loose, voluminous waves:

1. **Prepare Hair:** Ensure hair is dry and detangled. Section your hair into manageable parts.
2. **Position the Wand:** Take a medium section of hair. Place the Chronos Curve Max Wand vertically into the hair, close to the roots.
3. **Wrap Hair:** Wrap the section of hair around the barrel, away from your face. Ensure the hair lies flat against the barrel for even heat distribution.
4. **Hold:** Hold the hair around the barrel for 3-8 seconds, depending on your hair type and desired curl intensity.
5. **Release:** Gently release the curl by opening the clamp and sliding the wand out. Allow the curl to cool in your palm for a few seconds to set.
6. **Repeat:** Continue this technique, alternating the direction of each curl (towards and away from the face) for a natural, voluminous look.
7. **Finish:** Once all sections are curled, gently dress the waves using your fingers or a wide-tooth comb for a softer finish.

Your browser does not support the video tag.

Video: A step-by-step guide demonstrating how to create loose waves using the ghd Chronos Curve Max Wand, including hair sectioning, wrapping, holding, and releasing techniques.



Image: A close-up view of hair being wrapped around the 1.5-inch barrel of the ghd Chronos Curve Max Wand, illustrating the correct technique for curling.

4.3 Responsive Technology

The ghd Chronos Curve Max Wand features an intelligent algorithm that continuously monitors and adapts to your dynamic curling actions. This ensures ultimate heat control, delivering frizz-free curls without extreme damage.

GHD MAX WAND

For loose waves that last all day

65% bigger barrel¹ for 3x faster,² high-definition results for easy, frizz-free³ curls that last all day⁴



¹Vs standard competitor barrel. ²Vs competitor curler set to 356°F - 374°F. Lab test measuring time taken to form the same curl length. ³Consumer testing, Jan-Feb'24. an average of 73% of 921 consumers agree that ghd Chronos Curve makes frizz-free curls & waves. ⁴When used with curl hold spray. Technical test measuring curl retention in a humidity chamber at 50% relative humidity.

HD FRIZZ FREE
CURLS³



CURL
RESPONSIVE
TECHNOLOGY

UP TO
3X
FASTER
CURLS²

Image: Infographic highlighting the ghd Chronos Curve Max Wand's features: HD Frizz-Free Curls, Curl Responsive Technology, and up to 3X Faster Curls.

4.4 Automatic Sleep Mode

For safety and energy conservation, the wand will automatically enter sleep mode after 20 minutes of inactivity.

5. MAINTENANCE

5.1 Cleaning

- Ensure the wand is unplugged and completely cool before cleaning.
- Wipe the barrel and handle with a soft, damp cloth. Do not use abrasive cleaners or harsh chemicals.
- Ensure no moisture enters the internal components.

5.2 Storage

Store the ghd Chronos Curve Max Wand in a safe, dry place, away from direct sunlight and moisture. Ensure the power cord is not tightly wrapped around the appliance to prevent damage.

6. TROUBLESHOOTING

- **Wand not heating up:** Ensure the power cable is securely plugged in and the power button is pressed. Allow approximately 50 seconds for the wand to reach its optimal temperature.
- **Hair not curling effectively:** Ensure hair is completely dry before styling. Take smaller sections of hair and hold them around the barrel for the recommended 3-8 seconds.
- **Appliance unexpectedly turns off:** The wand features an automatic sleep mode that activates after 20 minutes of inactivity. Simply turn it back on if you wish to continue styling.
- **Unusual odors or smoke:** Immediately unplug the appliance from the power outlet. Do not use the wand if you detect any burning smell or smoke. Contact customer support for assistance.

7. SPECIFICATIONS

Feature	Detail
Product Dimensions	12 x 3.75 x 3.75 inches
Item Weight	1 Pound
Model Number	99350173967
UPC	850041485584
Manufacturer	ghd
Barrel Size	1.5 Inch
Max Temperature Setting	365°F
Power Source	Corded Electric
Material Type	Metal, Silicone (Heater Surface: Anodized Coating)
Product Benefits	Frizz control, shine enhancement, wave creation

8. WARRANTY INFORMATION

This ghd product comes with a 2-year manufacturer's warranty that covers defects in materials and workmanship. During the warranty period, ghd will repair or replace the product at no cost to you. This warranty does not cover damages caused by accidents, misuse, or normal wear and tear. Please retain your proof of purchase for warranty claims.

9. CUSTOMER SUPPORT

For further assistance, product registration, or to inquire about repairs, please visit the official ghd website or contact their customer service department.

- **Online Support:** Refer to the ghd official website for FAQs and support resources.
- **Contact:** Details for customer service can typically be found on the product packaging or the official ghd website.

