Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Miisekmy GS-001

Miisekmy BOX-3 Portable Biometric Handgun Safe Instruction Manual

Model: GS-001

Introduction

Thank you for choosing the Miisekmy BOX-3 Portable Biometric Handgun Safe. This manual provides essential information for the safe and effective use of your new handgun safe. Please read these instructions carefully before operation and retain them for future reference. This safe is designed to secure your handgun and other valuables, preventing unauthorized access, especially by children.

Safety Guidelines

- Always keep the safe locked when not in use.
- Store the mechanical keys in a secure location away from the safe and out of reach of children.
- Do not store loaded firearms in the safe unless explicitly permitted by local laws and regulations, and always ensure the firearm is in a safe condition.
- Ensure children cannot access the safe or its contents.
- Do not attempt to force the safe open if it malfunctions. Refer to the troubleshooting section or contact customer support.
- This safe is not water-resistant. Avoid exposure to moisture.



Image: The Miisekmy handgun safe positioned on a table, with a child in the background, emphasizing the importance of keeping firearms secured and out of reach of children.

Product Features

- **Portable Handle Design:** Integrated handle for easy and secure transportation.
- **Three Quick Access Methods:** Biometric fingerprint, 6-digit backlit keypad, and mechanical key.
- **Professional Fingerprint Recognition:** Stores up to 100 fingerprints with 0.1-second quick access and over 99% recognition rate.
- **Durable Construction:** Made from heavy-duty alloy steel for enhanced security against impacts and tampering.
- **Security Cable:** Includes a steel cable to secure the safe to fixed objects, preventing theft.
- **Internal LED Light:** Provides illumination for visibility in low-light conditions.
- **USB-C Charging:** Convenient Type-C rechargeable design for power supply.
- **Soft Sponge Interior:** Protects contents from scratches and damage.
- **Low Battery Alert:** Notifies user when battery is low.



Image: Overview of the Miisekmy handgun safe highlighting its innovative portable handle and key features.

Package Contents

- Miisekmy BOX-3 Handgun Safe × 1
- Mechanical Keys × 2
- Steel Security Cable × 1
- USB-C Charging Cable × 1
- User Manual × 1

Setup

1. Initial Unlocking

1. Locate the keyhole on the side of the safe.
2. Insert one of the mechanical keys and turn it to unlock the safe.
3. Open the safe lid.



Image: Initial unlocking of the safe using the mechanical key.

2. Charging the Safe

1. Connect the provided USB-C charging cable to the safe's charging port.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer USB port.
3. The indicator light will show charging status. Ensure the safe is fully charged before first use.



Image: The safe being charged via its USB-C port.

3. Securing the Safe (Optional)

Use the included steel security cable to attach the safe to a fixed object for added security.

1. Loop the steel cable around a secure, immovable object (e.g., car seat frame, desk leg).
2. Insert the cable's end into the designated slot on the safe.
3. Ensure the cable is securely fastened.



Image: The steel security cable attached to the safe and a fixed object.

Operating Instructions

1. Registering Fingerprints

1. With the safe open, locate the "SET" button inside the safe.
2. Press the "SET" button. The fingerprint sensor will illuminate.
3. Place your finger on the sensor. Lift and repeat several times from different angles until registration is

complete (usually indicated by a specific light or sound).

4. You can register up to 100 fingerprints. For best results, register multiple prints for the same finger and different fingers.



Image: Fingerprint registration process and features of the biometric sensor.

2. Setting Keypad Passwords

1. With the safe open, locate the "SET" button.
2. Press the "SET" button twice. The keypad will illuminate.
3. Enter your desired 6-digit password.
4. Press the "#" or "Enter" key to confirm. Repeat the password and confirm again.
5. You can set up to 10 keypad passwords.



Image: Close-up of the safe's keypad, indicating its backlit feature for use in the dark.

3. Unlocking the Safe

- **Biometric Fingerprint:** Place a registered finger on the fingerprint sensor. The safe will open if the fingerprint is recognized.
- **Keypad Password:** Enter your 6-digit password on the keypad, then press the "#" or "Enter" key. The safe will open if the password is correct.
- **Mechanical Key:** In case of battery depletion or electronic malfunction, use one of the mechanical keys to manually unlock the safe.



Image: Visual representation of the three quick access methods for the safe.

4. Using the Internal LED Light

The safe features a built-in LED light that activates when the safe is opened, providing visibility in dark environments.



Image: The internal LED light illuminating the safe's contents.

Maintenance

- **Cleaning:** Wipe the exterior with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Battery:** Recharge the safe regularly to ensure optimal performance. The low battery alert will indicate when charging is needed.
- **Fingerprint Sensor:** Keep the fingerprint sensor clean and dry for accurate recognition.
- **Keypad:** Ensure the keypad is free from dirt or debris.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Safe does not open with fingerprint.	Unregistered fingerprint, dirty sensor, low battery.	Ensure finger is registered. Clean the sensor. Recharge the safe. Try another registered finger.
Safe does not open with keypad.	Incorrect password, low battery.	Verify the password. Recharge the safe.
No power/lights.	Battery is completely depleted.	Use the mechanical key to open the safe and then charge it via USB-C.
Safe makes unusual sounds.	Internal mechanism issue.	Do not force. Contact customer support.

Specifications

- **Brand:** Miisekmy
- **Model Number:** GS-001
- **Product Dimensions:** 11.8"D x 7.4"W x 1.2"H
- **Lock Type:** Biometric, Electronic Combination Lock, Key
- **Color:** Black
- **Capacity:** 1.68 liters (fits 1 standard size pistol)
- **Material:** Alloy Steel
- **Item Weight:** 5 pounds
- **Power Supply:** USB-C Rechargeable
- **Water Resistance Level:** Not Water Resistant



Image: Dimensions and capacity of the Miisekmy handgun safe.

Warranty and Support

This product comes with a manufacturer's warranty. For warranty details, technical support, or any questions regarding your Miisekmy BOX-3 Handgun Safe, please contact Miisekmy customer service through the retailer's platform or the contact information provided with your purchase.
Manufacturer Warranty Description: 1 year (as per product specifications)

Product Videos

Miisekmy Gun Safe for Handgun with Handle for 2 Pistols

Your browser does not support the video tag.

Video: An official product video demonstrating the Miisekmy gun safe, including its capacity for two pistols and handle design. This video is provided by the seller.

Miisekmy Gun Safe for Handgun with Handle

Your browser does not support the video tag.

Video: An official product video showcasing the Miisekmy gun safe and its integrated handle for portability. This video is provided by the seller.

© 2023 Miisekmy. All rights reserved.

For further assistance, please visit the product page or contact customer support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FQJ2127X

More documents and user manuals: **https://manuals.plus/**