

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [KEMEI](#) /

› [KEMEI KM-2230 Professional Hair Clipper User Manual](#)

## KEMEI KM-2230

# KEMEI KM-2230 Professional Hair Clipper User Manual

Model: KM-2230

## 1. SAFETY INSTRUCTIONS

---

Please read all instructions carefully before using the KEMEI KM-2230 Professional Hair Clipper. Retain this manual for future reference.

- Do not immerse the clipper in water or other liquids.
- Keep the appliance away from children.
- Ensure the power adapter is compatible with your local voltage before charging.
- Do not use the clipper if the blades are damaged, as this may cause injury.
- Only use attachments and accessories supplied by the manufacturer.
- Unplug the clipper before cleaning or performing maintenance.
- Avoid using the clipper on irritated or damaged skin.

## 2. PACKAGE CONTENTS


---

The KEMEI KM-2230 Professional Hair Clipper package includes the following items:

- KEMEI KM-2230 Hair Clipper
- Charging Base
- USB Charging Cable
- 4 Guide Combs (1mm, 2mm, 3mm, 4mm)
- Cleaning Brush
- Lubricant Oil

# ROTARY MOTOR

# 7500 RPM



Low noise <60DB



Not pulling hair



high speed

Image: KEMEI KM-2230 Hair Clipper with its included accessories, including the charging base, USB cable, guide combs, cleaning brush, and oil.

## 3. PRODUCT OVERVIEW

The KEMEI KM-2230 is a professional-grade cordless hair clipper designed for precision hair cutting and grooming. It features a durable metal casing and an ergonomic design for comfortable handling.

### Key Features:

- **High-Speed Motor:** Equipped with a 7500 RPM motor for efficient cutting across all hair types.
- **Adjustable Blades:** Stainless steel precision blades with an adjustable gradient bar for precise control (0.5-2.0mm).
- **Dual Charging Options:** Features a dedicated charging base and a standard Type-C interface for flexible charging.
- **Long Battery Life:** A single charge provides approximately 210 minutes of use. Full charge takes about 3.5 hours.
- **LED Display:** Built-in digital display shows battery level, lubrication reminders, and charging status.

# RECHARGEABLE LI-ION BATTERY

**3.5 Hours**

(working time)

**210 Mins**

(charging time)

2500mah



**LED Display**

Battery percentage,  
oil status, clear at  
a glance

Image: The KEMEI KM-2230 Hair Clipper resting on its charging base, showcasing the LED display with battery percentage.

**7500 RPM**

 Battery Type: **2500mAh**

**HIGH SPEED MOTOR**

**Professional Hair Clipper**



Image: Diagram illustrating the internal 7500 RPM high-speed motor and 2500mAh battery of the KEMEI KM-2230 Hair Clipper.

## 4. SETUP

### 4.1 Initial Charging

Before first use, fully charge the clipper. The LED display will indicate the battery level.

1. Connect the USB charging cable to the charging base or directly to the Type-C port on the clipper.
2. Plug the other end of the USB cable into a suitable USB power adapter (not included) or a computer USB port.
3. Place the clipper onto the charging base, ensuring proper contact. The LED display will show charging status.
4. Allow approximately 3.5 hours for a full charge. The display will show 100% when fully charged.



Image: The KEMEI KM-2230 Hair Clipper connected to a USB port for charging, highlighting its dual charging capability.

## 4.2 Attaching Guide Combs

Select the desired guide comb for your preferred hair length.

1. Ensure the clipper is turned off.
2. Align the guide comb with the clipper blade and push it firmly until it clicks into place.
3. To remove, gently pull the comb away from the blade.



Image: The KEMEI KM-2230 Hair Clipper displayed alongside its four limit combs (1mm, 2mm, 3mm, 4mm).

## 5. OPERATING INSTRUCTIONS

### 5.1 Turning On/Off

Press the power button to turn the clipper on or off.

### 5.2 Adjusting Blade Length

Use the adjustable lever on the side of the clipper to fine-tune the cutting length from 0.5mm to 2.0mm without a guide comb.

### 5.3 Hair Cutting Tips

- For best results, ensure hair is clean and dry.
- Start with a longer guide comb and gradually reduce the length if desired.
- Hold the clipper with the blades pointing downwards and move against the direction of hair growth.
- Use smooth, even strokes.
- Regularly brush away cut hair from the blades to maintain optimal performance.



Image: Examples of various hairstyles that can be achieved with the KEMEI KM-2230 Hair Clipper, including buzz cut fade, classic comb-over, long shag, and long curly hair fade.

## 6. MAINTENANCE

### 6.1 Cleaning the Blades

Clean the blades after each use to ensure hygiene and performance.

1. Turn off the clipper and remove any attached guide comb.
2. Use the provided cleaning brush to remove loose hairs from the blades.
3. For a more thorough clean, the blades can be carefully detached and rinsed under running water. Ensure they are completely dry before reattaching.

### 6.2 Oiling the Blades

Regular oiling maintains blade sharpness and extends the clipper's lifespan.

1. After cleaning, apply a few drops of the provided lubricant oil to the blades.
2. Turn on the clipper for a few seconds to distribute the oil evenly.
3. Wipe off any excess oil with a soft cloth.

### 6.3 Battery Care

- Do not overcharge the battery. Unplug once fully charged.
- If storing for an extended period, charge the battery to about 50% and store in a cool, dry place.
- Avoid exposing the clipper to extreme temperatures.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Clipper does not turn on	Battery is depleted	Charge the clipper fully.
Clipper pulls hair	Blades are dull or dirty; Insufficient lubrication	Clean and oil the blades. If problem persists, consider blade replacement.
Clipper runs slowly	Low battery; Blades are clogged	Charge the clipper. Clean the blades thoroughly.
Clipper not charging	Charging cable or base is faulty; Improper connection	Check cable and base for damage. Ensure proper connection. Try a different USB power source.

## 8. SPECIFICATIONS

Feature	Detail
Model	KM-2230
Brand	KEMEI
Motor Speed	7500 RPM
Battery Type	Lithium Ion
Operating Time	Up to 210 minutes
Charging Time	Approximately 3.5 hours
Blade Material	High Carbon Stainless Steel
Power Source	Battery Powered
Charging Interface	USB Type-C, Charging Base
Dimensions	8.46 x 7.48 x 3.03 inches
Weight	1.82 Pounds

## 9. WARRANTY AND SUPPORT

KEMEI products are manufactured to high-quality standards. For warranty information or technical support, please refer to the warranty card included in your package or contact KEMEI customer service through the retailer where the product was purchased. Keep your proof of purchase for warranty claims.