

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [iWALK](#) /

› [iWALK 10000mAh 45W PD Portable Charger \(Model UBM003\) User Manual](#)

iWALK UBM003

iWALK 10000mAh 45W PD Portable Charger (Model UBM003) User Manual

Model: UBM003



1. INTRODUCTION

This manual provides essential instructions for the safe and efficient use of your iWALK 10000mAh 45W PD Portable Charger, Model UBM003. Please read this manual thoroughly before use and retain it for future reference.

2. PACKAGE CONTENTS

- iWALK 45W Power Bank (10000mAh)
- 9.84 inch Cable x 2 (one USB-C to USB-C, one USB-C to Lightning)
- User Manual

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your portable charger.



Image: The iWALK 10000mAh 45W PD Portable Charger in pink, showing the integrated USB-C cable and digital display.

- 1. Digital Display:** Shows remaining battery percentage.
- 2. Integrated USB-C Cable:** For charging devices or recharging the power bank.
- 3. Additional USB-C Port:** For connecting the second detachable cable or other USB-C devices.
- 4. Foldable Phone Stand:** Located on the back for hands-free viewing.
- 5. Power Button:** To check battery level or initiate charging.

4. SETUP

4.1 Initial Charging of the Power Bank

1. Connect the integrated USB-C cable or one of the provided detachable USB-C cables to the power bank's USB-C input port.
2. Connect the other end of the cable to a compatible USB wall charger (not included).
3. The digital display will show the charging progress. Charge the power bank fully before first use.



iWALK SenseForce Charging System

iWALK's "SenseForce Charging System" is powered by an advanced smart chip. It detects temperature and voltage changes, intelligently adjusting output power in real time. This reduces charging heat and improves energy conversion efficiency.



Image: Illustration demonstrating the recharging process of the power bank using a wall adapter.

5. OPERATING INSTRUCTIONS

5.1 Charging Your Devices

- Using the Integrated Cable:** Pull out the integrated USB-C cable and connect it to your device's charging port.
- Using the Detachable Cables:** Connect one of the provided 9.84-inch cables (USB-C to USB-C or USB-C to Lightning) to the power bank's additional USB-C port and then to your device.
- The power bank will automatically begin charging. The digital display will show the power bank's remaining battery percentage.
- To charge two devices simultaneously, use both the integrated cable and one of the detachable cables via the additional USB-C port.



Image: The iWALK power bank connected to an iPhone and an iPad, demonstrating simultaneous charging.

5.2 Using the Phone Stand

- Locate the foldable stand on the back of the power bank.
- Gently pull it out to deploy the stand.
- Place your smartphone or tablet horizontally into the stand's groove for hands-free viewing while charging.

Palm-Sized & Pocket-Friendly



Image: The iWALK power bank with its built-in stand extended, supporting a smartphone for viewing.

5.3 Power Bank Recharging

When the power bank's battery level is low, indicated by the digital display, recharge it using a compatible USB wall adapter as described in Section 4.1.

6. MAINTENANCE

- Keep the power bank away from water, fire, and extreme temperatures.
- Avoid dropping or subjecting the device to strong impacts.
- Clean the device with a dry, soft cloth. Do not use corrosive cleaners.
- Store in a cool, dry place when not in use.
- For optimal battery life, fully charge the power bank at least once every three months if not used regularly.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Power bank not charging device.	Low battery on power bank; loose connection; incompatible device.	Recharge power bank; ensure cables are securely connected; verify device compatibility.
Power bank not recharging.	Faulty wall adapter or cable; loose connection.	Try a different wall adapter or cable; ensure secure connection.
Slow charging.	Using a non-fast charging adapter/cable; device not supporting fast charging.	Use a 45W PD compatible wall adapter and cable; ensure device supports fast charging.
Digital display not working.	Power bank is off or completely drained.	Press the power button; recharge the power bank.

8. SPECIFICATIONS

Brand	iWALK
Model Number	UBM003
Battery Capacity	10000 Milliamp Hours (mAh)
Output Power	Up to 45W Power Delivery (PD)
Connector Type	USB Type C (Input & Output)
Special Features	Auto Shut-Off, Built-In Cable, Digital Display, Fast Charging, Foldable Phone Stand
Product Dimensions	5.45 x 3.94 x 1.56 inches
Item Weight	11.3 ounces
Battery Type	Lithium Polymer

9. WARRANTY AND SUPPORT

Your iWALK 45W Power Bank (10000mAh) comes with an 18-month worry-free warranty.

For customer service and support, please refer to the contact information provided on the product packaging or visit the official iWALK website.

10. SAFETY INFORMATION

- Do not disassemble, modify, or repair the device.

- Do not expose to direct sunlight or high temperatures.
- Dispose of the power bank according to local regulations. Do not dispose of with household waste.
- Keep out of reach of children.

11. PRODUCT VIDEO

Your browser does not support the video tag.

Video: An official product video demonstrating the features and usage of the iWALK MagicGo 10000 portable charger, including its fast charging capabilities, wide compatibility, built-in cable, and integrated stand. The video highlights its compact size and convenience for charging multiple devices.



Related Documents - UBM003

<p>-Product Introduction 1.1 Beschreibung der einzelnen Teile 1.2 Presentación del producto 1.3 Presentazione del prodotto 1.4 Presentación del presente 1.5 Presentación del producto</p>	<p><u>iWALK MagicGo10000 Power Bank: User Guide and Specifications</u> Discover the iWALK MagicGo10000, a versatile power bank designed to keep your devices charged on the go. This guide provides essential information on product features, charging methods, and technical specifications for model UBM003.</p>
<p>iWALK® Welcome Guide LPX001 使用说明书 User's manual Manuel d'utilisation Bedienungsanleitung Manuale di istruzione 使用说明书</p>	<p><u>iWALK LinkPod X Welcome Guide and User Manual</u> Comprehensive guide to the iWALK LinkPod X (LXP001), covering product features, charging instructions, safety precautions, specifications, and warranty information.</p>
<p>iWALK® Welcome Guide LinkMe 4 使用说明书 User's manual Manuel d'utilisation Bedienungsanleitung Manuale di istruzione 使用说明书</p>	<p><u>iWALK LinkMe 4 Welcome Guide: Portable Charger User Manual</u> Comprehensive welcome guide and user manual for the iWALK LinkMe 4 portable charger, covering specifications, usage instructions, safety precautions, and warranty information.</p>

	<p><u>iWALK PowerStand 10000 Magnetic Power Bank with Adjustable Stand - User Manual</u></p> <p>Comprehensive user manual for the iWALK PowerStand 10000, detailing its features as a magnetic power bank and adjustable stand for smartphones. Includes setup, usage, safety, and specifications.</p>
	<p><u>iWALK LinkPod 5 Portable Charger LPB5500PC User Guide</u></p> <p>Comprehensive user guide for the iWALK LinkPod 5 portable charger (Model LPB5500PC), covering quick start, usage, safety precautions, troubleshooting, specifications, and warranty information.</p>
	<p><u>iWALK PowerSlim 5000 (MXB018)</u></p> <p>iWALK PowerSlim 5000 (MXB018) RoHS</p>