

[Manuals.plus](#) /

› [webeauty](#) /

› webeauty F9E 3-in-1 High-Speed Hair Styler User Manual

webeauty F9E

webeauty F9E 3-in-1 High-Speed Hair Styler User Manual

Model: F9E
Brand: webeauty

IMPORTANT SAFETY INFORMATION

Please read all safety instructions before use to prevent injury or damage.

- Keep out of reach of children.
- Do not use the hair styler while bathing or near water.
- Allow the hair styler to cool completely before storing.
- Do not use the hair styler if the cord is damaged.
- Always unplug the hair styler when not in use.
- This appliance is equipped with an ALCI Safety Plug for automatic leakage protection.

PRODUCT OVERVIEW

The webeauty F9E 3-in-1 High-Speed Hair Styler is a versatile hair styling tool designed for fast drying, frizz control, and various styling options. It features a high-speed brushless motor and negative ionic technology for smoother, shinier hair.



Image: The webeauty F9E 3-in-1 High-Speed Hair Styler, showcasing the main unit, two curling barrels, and the product packaging.

Key Features:

- **High-Speed Brushless Motor:** 110,000 RPM motor with 1200W power for ultra-fast drying.
- **Negative Ionic Technology:** Reduces frizz and static, promoting smoother, shinier, and healthier hair.
- **Airflow Auto Air Curls:** Utilizes Coanda technology to gently attract and wrap hair for curls without extreme heat. Includes two curling barrels (1.25 inch).
- **Adjustable Settings:** 3 temperature modes (Cool/Warm/Hot) and 2 speed levels for various hair types.
- **Versatile Attachments:** Functions as a high-speed blow dryer, auto air curler, and includes other styling attachments (straightening brush, volumizing brush, etc., as implied by product description).

PACKAGE CONTENTS

Verify that all items are present in your package:

- webeauty F9E Main Unit
- Auto-Wrap Curling Barrels (Left and Right, 1.25 inch)
- High-Speed Hair Dryer Attachment
- Straightening Brush Attachment
- Volumizing Brush Attachment
- Heat Resistant Glove
- Storage Case
- User Manual (this document)

SETUP AND ASSEMBLY

Follow these steps to correctly attach and detach the styling accessories.

Attaching/Detaching Accessories:

1. Identify the triangle symbol (▼) on the accessory and the main unit.
2. Align the triangle symbol on the accessory with the "unlock" position (open padlock icon) on the main unit.
3. Insert the accessory firmly into the main unit.
4. Rotate the metal ring (gold ring) clockwise until the "lock" position (closed padlock icon) aligns with the triangle symbol. This secures the attachment.
5. To detach, rotate the metal ring counter-clockwise to the "unlock" position and pull the accessory upwards.

Easily Switch Between Dryer & Curler



**Rotate the clasp gold ring
until the "▼" lines up with
the "🔓" "🔒" to complete the
Disassembly/Installation.**

Image: Visual guide for attaching and detaching styling heads by aligning the triangle symbol with the unlock/lock icons on the rotary barrel lock.

Your browser does not support the video tag.

Video: Demonstration on how to install and change the tool accessories for the webeauty hair styler.

OPERATING INSTRUCTIONS

Power and Settings:

The main unit features controls for power, temperature, and wind speed.

- **Power Button:** Press to turn the device ON/OFF.
- **Temperature Settings:** Cycle through 3 modes:
 - Cool (same as environment)
 - Warm (160°F/71°C)
 - Hot (210°F/100°C)

- **Wind Speed Settings:** Adjust between 2 levels: High and Medium.



Image: Detailed view of the intelligent heat regulation and wind speed settings on the styler's handle.

Using the Hair Dryer Attachment:

Attach the high-speed hair dryer head. Use appropriate temperature and speed settings to dry your hair efficiently. The negative ionic technology helps reduce frizz during drying.

Using the Auto-Wrap Curling Barrels:

The auto-wrap barrels use airflow to create curls. Two barrels are provided for curling in different directions (left and right).

1. Ensure hair is 80%+ dry before curling.
2. Part a thin piece of hair (about 1-inch section) and comb it well to remove tangles.
3. Set the styler to the highest temperature (red light) and higher speed (Level 2) for optimal curling.
4. Hold the barrel near the hair tail, ensuring the hair tail is towards the same direction as the arrow on the wand. The airflow will automatically wrap the hair around the barrel.

5. Hold for about 10 seconds to heat the curl.
6. Switch to the cool air setting for about 8 seconds to set the curl. This helps the curl last longer.
7. Gently release the curl.



Image: The auto-wrap curler in action, demonstrating how hair is automatically wrapped by airflow for curling.

Your browser does not support the video tag.

Video: A guide on common mistakes to avoid and the correct way to use the auto air curler for best results.

Using Straightening and Volumizing Brushes:

Attach the desired brush head. Use the appropriate heat and speed settings for your hair type. Glide the brush through sections of hair to straighten or add volume.

Your browser does not support the video tag.

Video: Overview of the 3-in-1 hair dryer, auto air curling iron, and hair styler, demonstrating various attachments and their use.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your webeauty F9E Hair Styler.

- **Cleaning the Air Inlet Filter:** Regularly check and clean the detachable air inlet and filter accessory to prevent dust and hair buildup, which can affect performance and lifespan. Rotate the detachable air inlet to remove it, clean any debris, and reattach securely.
- **General Cleaning:** Wipe the main unit and attachments with a soft, damp cloth after each use. Ensure the device is unplugged and completely cool before cleaning.
- **Storage:** Store the styler and its attachments in the provided storage case in a dry, safe place when not in use.



Image: Illustration of the detachable inlet and filter, highlighting its role in extending the product's lifespan.

TROUBLESHOOTING

If you encounter any issues, refer to the common problems and solutions below:

Problem	Possible Cause	Solution
Device not turning on.	Not plugged in, power outlet issue, or ALCI tripped.	Ensure the device is securely plugged into a working outlet. Check the ALCI safety plug and reset if tripped.
Weak airflow or overheating.	Blocked air inlet filter.	Unplug the device and clean the detachable air inlet filter as described in the Maintenance section.
Curls not holding or hair not wrapping.	Hair too wet, sections too large, or incorrect temperature/speed settings.	Ensure hair is 80%+ dry. Use smaller, well-combed sections (approx. 1 inch). Use the highest temperature and speed settings. Apply cool shot to set curls.
Hair tangling during use.	Hair not properly combed or sections too large.	Always comb hair thoroughly before styling. Work with smaller, manageable sections.

SPECIFICATIONS

Feature	Detail
Product Dimensions	14.96 x 9.45 x 4.72 inches
Item Weight	2.91 Pounds
Model Number	F9E
Manufacturer	webeauty
Material	Metal
Wattage	1400.0 W
Power Source	Corded Electric

Feature	Detail
Motor Speed	110,000 RPM

WARRANTY AND SUPPORT

webeauty is committed to quality and customer satisfaction.

- **Warranty:** This product comes with a 1-year warranty to guarantee your satisfaction.
- **Customer Support:** For any questions, concerns, or support needs, please refer to the contact information provided with your product packaging or visit the official webeauty store.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question