okulaku DP101

okulaku 10.1 inch Smart Electronic Frameo Digital Picture Frame User Manual

Model: DP101

1. Introduction

This manual provides instructions for the setup, operation, and maintenance of your okulaku 10.1 inch Smart Electronic Frameo Digital Picture Frame (Model DP101). Please read this manual thoroughly before using the device to ensure proper function and longevity.

The digital picture frame features a 10.1-inch 1280x800 HD IPS touchscreen display, 32GB internal storage, Wi-Fi connectivity, and supports photo and video sharing via the Frameo application.

2. Safety Information

- Use only the provided power adapter. Using unauthorized adapters may damage the device and void the warranty.
- Do not expose the device to water or excessive moisture.
- Avoid placing the device in direct sunlight or near heat sources.
- Do not attempt to disassemble or repair the device yourself. Contact customer support for assistance.
- Keep the device away from strong magnetic fields.
- Ensure proper ventilation around the device during operation.

3. Package Contents

Verify that all items are present in the package:

- okulaku 10.1 inch Digital Picture Frame
- Power Adapter
- User Manual (this document)
- Desk Stand (pre-attached or separate)

4. Product Overview

Familiarize yourself with the components and key features of your digital picture frame.



Image: The digital picture frame displaying a photo, alongside a smartphone screen showing the Frameo application interface for sharing.

Key Features:

- **10.1-inch HD IPS Touch Screen:** Provides clear images with wide viewing angles and intuitive navigation.
- **32GB Internal Storage:** Capable of storing over 100,000 photos.
- **Wi-Fi Connectivity:** Enables instant photo and video sharing via the Frameo app.
- **Auto-Rotate Function:** Automatically adjusts photo orientation for both landscape and portrait display.
- **Desk or Wall Mountable:** Flexible placement options for your home or office.
- **Video Playback with Sound:** Supports 15-second video clips with audio.
- **Interactive Features:** Send greetings, captions, and reactions through the Frameo app.
- **Clock, Date, and Weather Display:** Additional useful information available on the frame.

5. Setup

5.1 Initial Power-On and Wi-Fi Connection

1. Connect the power adapter to the frame and plug it into an electrical outlet. The frame will power on automatically.
2. Follow the on-screen startup wizard to select your language, time zone, and connect to a Wi-Fi network. A stable Wi-Fi connection is required for sharing photos and videos.



Image: The digital picture frame highlighting Wi-Fi connectivity and instructions to download the Frameo app from Google Play or the App Store.

5.2 Frameo App Installation and Pairing

1. Download the free Frameo app on your smartphone from the Google Play Store (Android) or Apple App Store (iOS).
2. Open the Frameo app and create an account or log in.
3. On your digital picture frame, navigate to the 'Add Friend' or 'Connect' section to obtain a unique code.
4. In the Frameo app on your smartphone, enter this code to pair your device with the picture frame. This establishes a secure connection for sharing.



Image: A sequence of smartphone screenshots illustrating the process of downloading the Frameo app, setting up a profile, and adding a new frame using a code.

6. Operating Instructions

6.1 Sending Photos and Videos

1. Open the Frameo app on your smartphone.

2. Select the photos or videos you wish to send from your phone's gallery.
3. Choose the connected digital picture frame(s) as the recipient.
4. Optionally, add a caption to your photos or videos.
5. Adjust and preview the content, then confirm to send.



Image: A four-step visual guide demonstrating how to select, send, caption, and preview photos or videos using the Frameo app before sending them to the digital picture frame.

Note: Videos are limited to 15 seconds in length when displayed on the frame.

6.2 Interacting with Content

- **Touchscreen Navigation:** Swipe left or right on the screen to browse through photos and videos. Tap to pause or play videos.
- **Reactions:** The Frameo app allows you to send reactions (e.g., 'like', 'happy', 'surprised', 'sad') to photos received on the frame.
- **Settings:** Access the frame's settings menu by swiping down from the top of the screen or tapping the menu icon to adjust display, Wi-Fi, and other preferences.



Image: An illustration of various interactive features available through the Frameo app, including sending greetings, adding captions, reacting to photos, and receiving notifications.

6.3 Sleep Mode

You can configure sleep and wake-up times for the frame in the display settings. This feature allows the frame to automatically turn off the screen during specified hours (e.g., night mode) and turn it back on (e.g., day mode).



Image: A visual representation of the frame in 'Night Mode' (screen off) and 'Day Mode' (screen on), demonstrating the sleep schedule feature.

6.4 Placement and Orientation

The frame supports both desk placement using its integrated stand and wall mounting. The auto-rotate feature ensures that photos are displayed correctly regardless of the frame's orientation (landscape or portrait).



Image: The digital picture frame shown in various orientations (landscape and portrait) and placements (desk and wall-mounted), illustrating its auto-rotate and versatile mounting capabilities.

7. Maintenance

- **Cleaning the Screen:** Use a soft, lint-free cloth to gently wipe the screen. For stubborn smudges, slightly dampen the cloth with water or a screen-cleaning solution. Do not spray liquids directly onto the screen.
- **Cleaning the Frame:** Wipe the frame's exterior with a dry, soft cloth.
- **Software Updates:** Ensure your frame's software is up to date for optimal performance and new features. Check for updates in the frame's settings menu.
- **Data Management:** Periodically review and delete unwanted photos or videos to manage the 32GB storage capacity.

8. Troubleshooting

Problem	Possible Cause	Solution
Frame does not power on.	Power adapter not connected or faulty.	Ensure the power adapter is securely connected to both the frame and a working power outlet. Try a different outlet.
Cannot connect to Wi-Fi.	Incorrect password, weak signal, or router issue.	Verify the Wi-Fi password. Move the frame closer to the router. Restart your router. Check if other devices can connect to the Wi-Fi.
Photos/Videos not sending from app.	Frame not paired, no internet connection, or app issue.	Ensure the frame is connected to Wi-Fi and paired with your Frameo app. Check your phone's internet connection. Restart the Frameo app.
Frame freezes or becomes unresponsive.	Temporary software glitch.	Unplug the power adapter, wait 10 seconds, then plug it back in to restart the frame. If the issue persists, perform a factory reset (refer to settings menu).
Screen is blank during scheduled display time.	Sleep mode is active.	Check the sleep mode settings in the frame's display preferences to ensure the wake-up time is correctly set.

9. Specifications

Feature	Detail
Model Number	DP101
Screen Size	10.1 Inches
Display Resolution	1280x800 (HD IPS)
Aspect Ratio	16:9
Memory Storage Capacity	32 GB
Connectivity Technology	Wi-Fi
Power Source	Corded Electric
Touchscreen	Yes
Compatible Devices	Smartphone (via Frameo app)
Supported Photo Formats	JPG/JPEG/BMP/PNG
Supported Video Formats	MP4 (15-second clips)
Item Dimensions (L x W)	9.8" x 6.7"
Manufacturer	YNC
UPC	704505879542

10. Warranty Information

This product comes with a**1-Year Limited Warranty** from the date of purchase. The warranty covers manufacturing defects and malfunctions under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or improper installation.

Please retain your proof of purchase for warranty claims.

11. Customer Support

If you encounter any issues or have questions not covered in this manual, please contact our customer support team for assistance.

- **Email:** [Insert Customer Support Email Here]
- **Phone:** [Insert Customer Support Phone Number Here]
- **Website:** okulaku Official Store

When contacting support, please provide your product model (DP101) and a detailed description of the issue.

12. Video Resources

No official product videos from the seller were found that meet the criteria for inclusion in this manual.

© 2026 okulaku. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question