Arkveld Apex1-01

Arkveld Apex1-01 Electric Dirt Bike User Manual

Model: Apex1-01

1. Introduction

Thank you for choosing the Arkveld Apex1-01 Electric Dirt Bike. This manual provides essential information for the safe assembly, operation, and maintenance of your electric dirt bike. Please read this manual thoroughly before your first ride to ensure proper use and to maximize the lifespan of your product. Retain this manual for future reference.



Figure 1: Arkveld Apex1-01 Electric Dirt Bike, showcasing its robust frame and fat tires.

2. Safety Information

Your safety is paramount. Always wear a helmet and appropriate protective gear (gloves, knee pads, elbow pads) when riding. Adhere to all local traffic laws and regulations. This electric dirt bike is designed for adult use only.

2.1 General Safety Guidelines

- Perform a pre-ride inspection before each use, checking brakes, tire pressure, and battery charge.
- Do not ride under the influence of alcohol or drugs.
- Avoid riding in adverse weather conditions (heavy rain, snow, ice).
- Maintain a safe distance from other vehicles and pedestrians.
- Familiarize yourself with the controls and handling characteristics in a safe, open area before riding in traffic or challenging terrain.

2.2 Battery Safety

- Use only the charger provided by Arkveld.

- Do not expose the battery to extreme temperatures or direct sunlight.
- Do not puncture, drop, or disassemble the battery pack.
- If the battery shows signs of damage or overheating, discontinue use immediately and contact support.

3. Package Contents

Upon unpacking, verify that all components are present:

- Arkveld Apex1-01 Electric Dirt Bike (partially assembled)
- Battery Pack (48V 32AH)
- Battery Charger
- Headlight
- Installation Tools
- User Manual (this document)

If any items are missing or damaged, please contact Arkveld customer support immediately.

4. Setup and Assembly

The Arkveld Apex1-01 Electric Dirt Bike arrives approximately 90% pre-assembled. The remaining assembly steps typically include attaching the front wheel, handlebars, pedals, and headlight. Refer to the included installation video (if provided separately) for visual guidance.

4.1 Required Tools

The necessary installation tools are included in your package.

4.2 Assembly Steps

1. **Unpacking:** Carefully remove all components from the packaging.
2. **Handlebar Installation:** Attach the handlebars to the stem, ensuring they are centered and tightened securely.
3. **Front Wheel Installation:** Install the front wheel, ensuring the disc brake rotor is correctly seated within the caliper. Tighten the quick-release or axle nuts firmly.
4. **Pedal Installation:** Identify the left (L) and right (R) pedals. Thread the pedals into the crank arms. Note that the left pedal is reverse-threaded. Tighten securely with a wrench.
5. **Headlight Attachment:** Mount the headlight to the designated position and connect its wiring.
6. **Battery Insertion:** Insert the fully charged battery into its compartment, ensuring it clicks into place securely.
7. **Final Inspection:** Double-check all bolts, nuts, and quick releases for tightness. Ensure brakes are functioning correctly and tires are inflated to the recommended pressure.

5. Operating Instructions

5.1 Powering On/Off

To power on the bike, press and hold the power button on the LCD display. To power off, press and hold the power button again.

5.2 LCD Display

The multi-function LCD display provides real-time metrics such as speed, battery level, riding mode, and trip distance. Refer to the separate LCD display manual (if applicable) for detailed instructions on navigating menus and adjusting parameters.

5.3 Riding Modes

The Arkveld Apex1-01 offers three distinct riding modes:

- **Pure Electric Mode:** Engages the motor fully without pedal input. Controlled via the throttle. Ideal for quick acceleration or when you prefer not to pedal.
- **Pedal Assist Mode (PAS):** The motor provides assistance as you pedal. The level of assistance can typically be adjusted via the LCD display. This mode extends battery life and reduces rider effort, especially on inclines.
- **Normal Biking Mode:** The motor is disengaged, and the bike operates like a traditional bicycle, powered solely by pedaling.

5.4 Gearing

The bike features a 7-gear shifting system. Use the gear shifter on the handlebars to select appropriate gears for varying terrain and speed requirements. Shift smoothly to avoid strain on the drivetrain.

5.5 Braking

The Arkveld Apex1-01 is equipped with dual hydraulic disc brakes for reliable stopping power. Apply both front and rear brakes simultaneously and gradually for controlled deceleration. Avoid sudden, hard braking, especially with the front brake, to prevent loss of control.



Figure 2: Rider operating the Arkveld Apex1-01 Electric Dirt Bike on varied terrain.

6. Battery Information

6.1 Charging the Battery

The 48V 32AH battery is removable for convenient charging. Connect the charger to a standard wall outlet and then to the battery's charging port. The charging indicator on the charger will typically show red during charging and turn green when fully charged. A full charge takes approximately 6-7 hours.



Figure 3: Close-up view of the Arkveld Apex1-01 battery compartment, showing the integrated 48V 32AH battery.

6.2 Battery Care and Storage

- Avoid completely draining the battery. Recharge it regularly, even if not in use.
- Store the battery in a cool, dry place, away from direct sunlight and extreme temperatures.
- If storing for an extended period, charge the battery to approximately 50-70% every 1-2 months.
- The battery is UL 2849 certified, indicating compliance with safety standards for electric bicycles.

7. Maintenance

Regular maintenance ensures optimal performance and longevity of your electric dirt bike.

7.1 General Cleaning

Clean the bike regularly with a damp cloth. Avoid using high-pressure washers directly on electrical components,

bearings, or the motor.

7.2 Tire Care

Check tire pressure before each ride. The 25-inch fat tires are designed for various terrains; maintain pressure within the recommended range printed on the tire sidewall. Inspect tires for wear, cuts, or punctures.

7.3 Brake Maintenance

Regularly inspect brake pads for wear and replace them when necessary. Check brake fluid levels for hydraulic systems and ensure brake levers provide firm, consistent stopping power. Adjust brake cables or bleed hydraulic lines as needed.

7.4 Drivetrain

Keep the chain clean and lubricated. Inspect the chain, cassette, and chainring for wear and replace components as needed to ensure smooth shifting and efficient power transfer.



Figure 4: Detail of the adjustable dual hydraulic suspension system on the Arkveld Apex1-01.

8. Troubleshooting

This section addresses common issues you might encounter. For problems not listed here, please contact Arkveld customer support.

Problem	Possible Cause	Solution
Bike does not power on	Low battery charge, loose battery connection, faulty power button	Charge battery, ensure battery is fully seated, contact support if issue persists
Motor not assisting	Battery low, PAS level set to zero, sensor issue	Charge battery, increase PAS level on display, check sensor connections
Brakes feel weak	Worn brake pads, air in hydraulic lines, misaligned caliper	Inspect/replace pads, bleed brakes (professional recommended), adjust caliper
Unusual noises	Loose components, dry chain, worn bearings	Inspect and tighten components, lubricate chain, contact support for bearing issues

9. Specifications

Key technical specifications for the Arkveld Apex1-01 Electric Dirt Bike:

Feature	Specification
Model	Apex1-01
Motor	Peak 3000W Brushless Hub Motor
Battery	48V 32AH (UL 2849 Certified)
Max Speed	Up to 40 MPH
Range	40-90 Miles (depending on riding mode and terrain)
Charging Time	6-7 Hours
Wheel Size	25 Inches (Fat Tires)
Brakes	Dual Hydraulic Disc Brakes
Suspension	High-strength Front and Rear Suspension
Frame Material	High Carbon Steel
Gears	7-Speed Shifting
Display	Multi-function LCD Display



Figure 5: Detailed view of the 3000W Peak Brushless Hub Motor and drivetrain components.

10. Warranty and Support

Arkveld provides a limited warranty for the Apex1-01 Electric Dirt Bike. Please refer to the warranty card included with your purchase for specific terms and conditions. For technical assistance, parts, or warranty claims, please contact Arkveld customer support through the retailer or the official Arkveld website.

When contacting support, please have your model number (Apex1-01) and purchase date available.

© 2025 Arkveld. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How can I troubleshoot or repair the motor on my Arkveld Apex 1 e-bike if it has stopped working after two months of use?

Based on the Arkveld Apex1-01 manual, if your motor has stopped assisting, you should perform the following diagnostic steps:Check the Battery: Ensure the battery is fully charged and securely seated in its compartment. A...

Read full answer

I recently bought an Arkveld Apex One e-bike and after two months of use, the motor stopped working. How can I troubleshoot this issue?

If the motor on your Arkveld Apex One (Apex1-01) has stopped working, please follow these troubleshooting steps based on the user manual:Check the Battery Level: Ensure the battery is fully charged. A low battery...

Read full answer