Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Moulinex DK855H

Moulinex Fresh Express Electric Vegetable Slicer DK855H

User Manual

1. Important Safety Instructions

Please read all instructions carefully before using your Moulinex Fresh Express. Retain this manual for future reference.

- Always unplug the appliance from the power supply before assembly, disassembly, or cleaning.
- Keep hands and utensils away from moving blades during operation to prevent injury.
- Do not operate the appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Ensure the appliance is placed on a stable, flat, and dry surface during use.
- Do not immerse the motor unit in water or any other liquid.
- The intelligent airflow system with ventilation prevents motor overheating.



Image: The appliance features an intelligent airflow system for motor protection.

2. Product Overview and Components

The Moulinex Fresh Express DK855H is a versatile electric vegetable slicer designed for shredding, slicing, and grating various ingredients directly into your serving bowl.



Image: Main unit of the Moulinex Fresh Express.

Components:

1. Motor Unit (Base)
2. Feeding Tube
3. Pusher
4. Cone Holder
5. 5 Interchangeable Cones:
    - Fine Shredding Cone
    - Coarse Shredding Cone
    - Thin Slicing Cone
    - Thick Slicing Cone
    - Grating Cone (e.g., for hard cheese)



Image: The five interchangeable cones for different cutting tasks.

3. Setup

1. Unpack all components and remove any packaging materials.
2. Wash all removable parts (feeding tube, pusher, cone holder, and cones) in warm soapy water, then rinse and dry thoroughly.
3. Place the motor unit on a clean, dry, and stable surface.
4. Attach the cone holder to the motor unit by aligning the tabs and twisting until it locks into place.
5. Select the desired cone for your task and insert it into the cone holder. Ensure it is securely seated.
6. Place the feeding tube assembly onto the cone holder.

4. Operating Instructions

The Moulinex Fresh Express allows you to prepare fresh ingredients quickly and efficiently.

1. Ensure the appliance is correctly assembled with the desired cone.
2. Place a bowl or plate directly under the outlet of the cone holder to collect the processed ingredients.
3. Plug the appliance into a suitable power outlet.
4. Cut ingredients into pieces that fit easily into the feeding tube.
5. Turn on the appliance.
6. Place the ingredients into the feeding tube and gently push them down with the pusher. Do not force the ingredients or use your fingers.
7. Once all ingredients are processed, turn off the appliance and unplug it.



Image: The direct serving system allows ingredients to be cut directly into your bowl.

Tips for Best Results:

- For softer ingredients, use a gentle, continuous pressure with the pusher.
- For harder ingredients, apply firmer, steady pressure.
- Process ingredients in batches if necessary to avoid overloading the motor.

- Experiment with different cones for various textures and preparations, such as salads, gratins, or garnishes.



Image: Prepare a variety of fresh and healthy dishes with fruits, vegetables, and cheese.

5. Cleaning and Maintenance

Proper cleaning ensures the longevity and hygiene of your appliance.

1. Always unplug the appliance before cleaning.
2. Disassemble the feeding tube, pusher, cone holder, and selected cone from the motor unit.
3. All removable parts are dishwasher safe. Alternatively, wash them by hand in warm soapy water and rinse thoroughly.
4. Wipe the motor unit with a damp cloth. Do not immerse the motor unit in water.
5. Ensure all parts are completely dry before reassembling or storing.



Image: Removable parts are dishwasher safe for easy cleaning.

6. Storage

The compact design of the Moulinex Fresh Express allows for easy storage.

- After cleaning and drying, store the cones within the cone holder or in a designated storage area.

- The appliance features an integrated cord storage system. Wrap the power cord around the designated area on the base.
- Store the assembled unit in a cupboard or on a shelf.



Image: Compact design with integrated cord storage for convenient storage.

7. Troubleshooting

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet issue; improper assembly.	Check power connection; try a different outlet; ensure all parts are correctly assembled and locked.
Motor stops during operation.	Overload; ingredients too hard or large.	Turn off and unplug; remove some ingredients; cut ingredients into smaller pieces. Allow motor to cool if overheated.

Problem	Possible Cause	Solution
Ingredients are not processed evenly.	Incorrect cone used; ingredients not fed properly.	Ensure the correct cone is selected for the desired result; feed ingredients steadily and evenly.

If the problem persists, please contact customer support.

8. Specifications

- **Brand:** Moulinex
- **Model Number:** DK855HE0
- **Style:** Fresh Express
- **Functions:** 4-in-1 (Fine Shredding, Coarse Shredding, Slicing, Grating)
- **Dimensions (L x W x H):** 16.5L x 16.5W x 28.2H cm
- **Weight:** 1.45 Kilograms
- **Dishwasher Safe Parts:** Yes (removable parts)
- **Country of Origin:** France





Image: Dimensions of the Moulinex Fresh Express appliance.

9. Warranty and Support

Moulinex is committed to product quality and customer satisfaction.

- **Repairability:** This product is designed for repairability for 15 years. Moulinex maintains a network of 6200 international repair centers.
- For service, spare parts, or further assistance, please visit the official Moulinex website or contact your local customer support.



Image: Moulinex's commitment to 15 years of repairability.

© 2026 Moulinex. All rights reserved.

For more information, visit www.moulinex.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FQJYLQLJ

More documents and user manuals: **https://manuals.plus/**