

[Manuals.plus](#) /

› [Motorola](#) /

› Motorola Edge 60 Fusion 5G Smartphone User Manual

Motorola Edge 60 Fusion

Motorola Edge 60 Fusion 5G Smartphone User Manual

Model: Edge 60 Fusion

1. INTRODUCTION

This manual provides essential information for the safe and efficient use of your Motorola Edge 60 Fusion 5G Smartphone. Please read this guide thoroughly before operating your device to ensure optimal performance and longevity. Keep this manual for future reference.



Image 1.1: Front and back view of the Motorola Edge 60 Fusion 5G Smartphone. The device is shown in a Pantone Amazonite color, highlighting its camera module on the rear and the display with a punch-hole front camera.

2. WHAT'S IN THE BOX

Verify that all items are present in your product packaging:

- Motorola Edge 60 Fusion 5G Smartphone
- USB Cable

- Quick Start Guide (may vary by region)
- SIM Ejector Tool (may vary by region)

3. SETUP

3.1. Inserting the SIM Card(s)

1. Locate the SIM tray on the side of your device.
2. Insert the SIM ejector tool into the small hole next to the tray and push gently until the tray pops out.
3. Place your Nano-SIM card(s) into the tray with the gold contacts facing down. Ensure they are correctly seated. This device supports Dual-SIM functionality.
4. Carefully reinsert the SIM tray into the phone.

3.2. Initial Power On and Setup

1. Press and hold the Power button (located on the right side of the device) until the Motorola logo appears.
2. Follow the on-screen prompts to select your language, connect to a Wi-Fi network, and set up your Google account.
3. You will be guided through setting up security features such as a PIN, pattern, or fingerprint.

4. OPERATING YOUR DEVICE

4.1. Basic Navigation

- **Home Screen:** Swipe left or right to access different panels.
- **App Drawer:** Swipe up from the bottom of the screen to view all installed applications.
- **Notifications & Quick Settings:** Swipe down from the top of the screen to access notifications and quick settings toggles.
- **Gestures:** Utilize Android 15's gesture navigation for back, home, and recent apps.

4.2. Making Calls and Sending Messages

- **Calls:** Tap the Phone icon, enter the number, and tap the call button.
- **Messages:** Tap the Messages icon, start a new conversation, enter the recipient, and type your message.

4.3. Camera Usage

Your Motorola Edge 60 Fusion features a versatile camera system.



Image 4.1: Rear view of the Motorola Edge 60 Fusion 5G Smartphone, highlighting the multi-lens camera module and the Motorola logo.

- **Launch Camera:** Tap the Camera icon or use a quick gesture (e.g., twist the phone twice).

- **Modes:** Swipe left or right on the viewfinder to switch between photo, video, portrait, and other modes.
- **Settings:** Tap the gear icon to adjust resolution, aspect ratio, and other camera settings.

4.4. Connectivity

- **Wi-Fi:** Go to *Settings > Network & internet > Wi-Fi* to connect to available networks.
- **Bluetooth:** Go to *Settings > Connected devices > Bluetooth* to pair with other Bluetooth devices.
- **Mobile Data (5G):** Ensure your SIM card is active and mobile data is enabled in *Settings > Network & internet > Mobile network*.

5. MAINTENANCE

5.1. Battery Care

- Use only approved chargers and cables.
- Avoid extreme temperatures, which can degrade battery life.
- For optimal battery health, try to keep the charge level between 20% and 80%.

5.2. Software Updates

Regularly check for software updates to ensure your device has the latest features and security patches. Go to *Settings > System > System updates*.

5.3. Cleaning Your Device

- Use a soft, lint-free cloth to clean the screen and body.
- Avoid harsh chemicals or abrasive materials.
- Do not submerge the device in water.

6. TROUBLESHOOTING

Problem	Solution
Device won't turn on	Ensure the battery is charged. Connect to a charger for at least 15 minutes, then try powering on.
Apps are crashing or freezing	Clear the app's cache (<i>Settings > Apps > [App Name] > Storage & cache > Clear cache</i>) or restart the device.
Poor network signal	Check SIM card insertion. Move to an area with better coverage. Restart the device.
Battery drains quickly	Reduce screen brightness, close unused apps, disable unnecessary features (Bluetooth, GPS). Check battery usage in settings.

For more advanced troubleshooting, refer to the official Motorola support website or contact customer service.

7. SPECIFICATIONS

Feature	Detail
Model Name	Motorola Edge 60 Fusion

Feature	Detail
Operating System	Android 15
RAM Memory	12 GB
Storage Capacity	256 GB
Screen Size	6.67 Inches
CPU Model	Cortex
CPU Speed	3.4 GHz
Battery Power Rating	5200 mAh
Product Dimensions	6.34 x 2.87 x 0.33 inches
Special Features	LED flash
Wireless Carrier	Unlocked for All Carriers (GSM Only No CDMA)

8. WARRANTY AND SUPPORT

Your Motorola Edge 60 Fusion 5G Smartphone is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase or visit the official Motorola website for detailed warranty terms and conditions. For technical support, service, or additional information, please visit the official Motorola support page:

[Motorola Support Website](#)

© 2025 Motorola. All rights reserved. Motorola and the Stylized M Logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question