

## BANDAI No.1 Sentai Gojujer DX Centering Set

# Bandai No.1 Sentai Gojujer DX Centering Set Instruction Manual

Model: No.1 Sentai Gojujer DX Centering Set

Brand: BANDAI

## 1. INTRODUCTION

---

This instruction manual provides essential information for the safe and proper use of your Bandai No.1 Sentai Gojujer DX Centering Set, featuring Kakuranger and Decarenger. Please read this manual thoroughly before use and retain it for future reference.

## 2. PACKAGE CONTENTS

---

Verify that all items listed below are included in your package:

- Centering Crayons: 1 piece
- Centering Decalanger: 1 piece
- Ring parts (small): 2 pieces (inner diameter approx. 0.6 inches / 15 mm)
- Ring parts (large): 2 pieces (inner diameter approx. 0.8 inches / 21 mm)

*Note: Other items shown in promotional images are not included unless specified above.*

## 3. SETUP

---

1. Carefully remove all components from their packaging.
2. Identify the Centering Crayons and Centering Decalanger.
3. Insert the provided ring parts into the Centering Decalanger to create various configurations.
4. Experiment with combining small and large ring parts to achieve different appearances and functionalities.

## 4. OPERATING INSTRUCTIONS

The Centering Set allows for interactive play and combination with other compatible items.

1. **Image Change Gimmick:** The Centering Decalanger is equipped with a feature that changes its displayed image. To activate this, rotate the top section of the Centering Decalanger 180 degrees. This action will reveal a different character or scene.
2. **Linking with DX Tegasode (Sold Separately):** For enhanced play, the Centering Set can be linked with the DX Tegasode (sold separately). When connected, you can enjoy a variety of lighting and sound effects specific to each ring. Refer to the DX Tegasode manual for detailed linking instructions.



**Figure 1:** This image illustrates the Centering Kakuranger and Centering Decalanger. It highlights the ability to rotate the Centering rings 180 degrees to change the displayed image and shows how they can be set into the separately sold DX Tegasode for enhanced abilities, including lighting and sound effects.

## 5. MAINTENANCE

To ensure the longevity of your Centering Set, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the product with a dry, soft cloth. Do not use harsh chemicals, abrasive cleaners, or immerse the product in water.

- **Storage:** Store the product in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Handle the product with care to prevent damage to its intricate parts.

## 6. TROUBLESHOOTING

---

If you encounter any issues with your Centering Set, consider the following:

- **Gimmick Not Functioning:** Ensure the rotating part is not obstructed by foreign objects. Apply gentle, even pressure when rotating.
- **Compatibility Issues:** If linking with DX Tegasode, ensure both products are genuine BANDAI items and are connected correctly as per their respective manuals.
- **General Damage:** If the product appears damaged, discontinue use.

For persistent issues, please contact customer support.

## 7. SPECIFICATIONS

---

Feature	Detail
Product Dimensions	4.33 x 5.12 x 0.79 inches
Item Weight	1.41 ounces
Manufacturer Recommended Age	3 years and up
Batteries Required	No
Manufacturer	BANDAI

## 8. SAFETY INFORMATION

---

- **Recommended Age:** This product is suitable for ages 3 years and up. Keep small parts away from younger children to prevent choking hazards.
- **No Batteries Required:** This product does not require batteries for its core functions.
- **Supervision:** Adult supervision is recommended during play.
- **Avoid Misuse:** Do not throw, hit, or step on the product.

## 9. WARRANTY AND SUPPORT

---

BANDAI products are manufactured to high-quality standards. For any questions, concerns, or support regarding your product, please refer to the contact information provided on the product packaging or visit the official BANDAI website.

