

[Manuals.plus](#) /

› [VINGLI](#) /

› VINGLI Fireplace Corner TV Stand with Electric Fireplace Heater and LED Light (Model BL0JGBS) User Manual

VINGLI BL0JGBS

VINGLI Fireplace Corner TV Stand User Manual

Model: BL0JGBS

Brand: VINGLI

INTRODUCTION

This manual provides essential instructions for the safe assembly, operation, and maintenance of your VINGLI Fireplace Corner TV Stand with Electric Fireplace Heater and LED Light. Please read this manual thoroughly before assembly and use, and retain it for future reference.

IMPORTANT SAFETY INSTRUCTIONS

WARNING: To reduce the risk of fire, electric shock, or injury, read all instructions before using this appliance.

General Safety

- Ensure all components are present and undamaged before assembly.
- Do not use this unit if any part has been submerged in water.
- Keep packaging materials away from children.
- This product is intended for indoor use only.
- Always use the anti-tilt device provided to secure the TV stand to the wall, preventing accidental tipping.

Electrical Safety (Electric Fireplace Heater)

- Connect the fireplace heater to a properly grounded 120V AC outlet.
- Do not overload electrical circuits. Avoid using extension cords or power strips with the heater.
- Keep combustible materials (furniture, bedding, papers, clothes, curtains) at least 3 feet (0.9 m) from the front of the heater.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- The fireplace heater is CSA certified with overheat protection. If the heater overheats, it will automatically shut off. Unplug the unit and allow it to cool before restarting.

PACKAGE CONTENTS

Your VINGLI Fireplace Corner TV Stand package includes the following items:

- Fireplace TV Stand components (Engineered Wood panels, hardware)
- Electric Fireplace Insert
- Remote Control for Fireplace
- LED Light Strip (with APP/remote control)
- Instruction Manual (this document)
- Anti-tilt Device

Note: The item may be delivered in 2 packages, which may arrive at different times.



Figure 1: Electric Fireplace Insert and Packaging Information

ASSEMBLY INSTRUCTIONS

Detailed assembly instructions, including diagrams and step-by-step guidance, are provided in the separate assembly manual included with your product. Please follow these instructions carefully to ensure proper and safe assembly.

1. Unpack all components and verify against the parts list in the assembly manual.
2. Identify all hardware and tools required (typically a screwdriver).
3. Assemble the TV stand frame according to the numbered steps.
4. Install the glass doors using the silent drawer hinges provided.
5. Insert the electric fireplace into its designated opening.
6. Attach the LED light strip as instructed.
7. Secure the unit to the wall using the anti-tilt device.



Figure 2: Key Assembly Components and Safety Features

SETUP

Placement

- Place the TV stand on a flat, stable surface in a corner of your room.
- Ensure adequate clearance around the unit for ventilation, especially for the fireplace heater.
- Position the stand away from direct sunlight or heat sources.
- The stand is designed to accommodate TVs up to 55 inches.




Figure 3: Product Dimensions and TV Compatibility

Power Connection

- Once assembled, plug the electric fireplace power cord into a standard 120V AC grounded outlet.
- Ensure the power cord is not pinched or routed under the unit.

OPERATING THE ELECTRIC FIREPLACE

The electric fireplace can be controlled via the touch panel on the unit or the included remote control.

Controls

- **Power Button:** Turns the fireplace on/off.
- **Flame Color Button:** Cycles through 6 flame color options (Orange, Red, Red & Orange, Red & Blue, Orange & Blue, Red & Orange & Blue, Auto-cycling).
- **Heater Button:** Activates the heater. Press again to adjust temperature.
- **Temperature Control:** Adjusts temperature from 62°F to 82°F.
- **Timer Button:** Sets an auto-off timer from 0.5 to 6 hours.



Figure 4: Electric Fireplace Flame Color Options

Features

- **Authentic Flame Effect:** Enjoy realistic flame visuals with or without the heater function.
- **Adjustable Heat Output:** Provides warmth with 1400 A/W heat output.
- **Overheat Protection:** Built-in safety feature automatically shuts off the heater if it gets too hot.
- **CSA Certified:** Ensures compliance with safety standards.

OPERATING THE LED LIGHTING

The integrated LED light strip can be controlled via a dedicated APP or the included remote control.

Controls and Features

- **Full-Color Adjustment:** Select from a wide spectrum of colors to match your ambiance.
- **Music Rhythm Sync:** Lights can synchronize with music playing in the room.
- **Mic-Sync Dynamic Modes:** Lights react to sounds detected by the microphone.
- **Auto-Off Timer:** Set a timer for the LED lights to automatically turn off.



Figure 5: LED Lighting Control Options and Effects

MAINTENANCE

Cleaning

- Always unplug the unit from the power outlet before cleaning.
- Wipe the exterior surfaces of the TV stand with a soft, damp cloth. Avoid abrasive cleaners.
- For the glass doors, use a glass cleaner and a soft cloth.
- Periodically vacuum the air intake and exhaust vents of the fireplace insert to prevent dust buildup.

General Care

- Avoid placing hot items directly on the surface of the TV stand.
- Do not expose the unit to excessive moisture or direct sunlight for prolonged periods.
- Regularly check all screws and connections to ensure they remain tight.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Fireplace does not turn on.	No power, power cord loose, overheat protection activated.	Check power outlet. Ensure cord is securely plugged in. Unplug unit, wait 15 minutes, then plug back in.
Heater not producing heat.	Heater function not activated, temperature setting too low, overheat protection.	Press heater button. Increase temperature setting. Check for obstructions around vents.
Remote control not working.	Dead batteries, remote out of range, obstruction.	Replace batteries. Ensure clear line of sight to fireplace sensor. Move closer to unit.
LED lights not responding.	Connection issue, app/remote malfunction.	Check LED strip connections. Restart app or replace remote batteries.

SPECIFICATIONS

Brand	VINGLI
Model Name	FireplaceTVStand
Item Model Number	BL0JGBS
Product Dimensions	20.08"D x 43.11"W x 32.01"H
Material	Engineered Wood
Color	White
Power Source	Corded Electric
Heat Output	1400 A/W
Special Feature	Adjustable Flame, LED Lighting, Electric Fireplace Heater
Item Weight	87.1 pounds
Installation Type	Floor Standing (with anti-tilt wall mount)
Specific Uses	Indoor

WARRANTY AND SUPPORT

VINGLI stands behind its products and offers a **1-year Quality Service** warranty. For any issues or inquiries, please contact VINGLI customer support. They provide **24/7 Professional Quality Service** to assist you. Please refer to your purchase documentation or the VINGLI official website for detailed warranty terms and contact information.