

[Manuals.plus](#) /

› [BrickSoul](#) /

› BrickSoul LED Light Up Kit for Lego Wall-E & EVE 43279 Building Set Instruction Manual

BrickSoul 43279-sound

BrickSoul LED Light Up Kit for Lego Wall-E & EVE 43279 Building Set Instruction Manual

1. OVERVIEW

This manual provides instructions for the BrickSoul LED Light Up Kit, designed to enhance your Lego Wall-E & EVE 43279 building set. This kit adds lighting and sound effects, transforming your model into a dynamic display piece. Please note that the Lego Wall-E & EVE 43279 model is not included with this lighting kit and must be purchased separately.

Create Stunning Visual Effects

Light Kit Only – Model Not Included



Light Off

VS

Light On



Lost in Darkness



Lively and Impressive

Image 1: Visual comparison of the Lego Wall-E and EVE models without and with the BrickSoul LED Light Up Kit installed, highlighting the enhanced visual effects.

2. PACKAGE CONTENTS

Before beginning installation, please verify that all components listed below are present in your package:

- LED Light Kits (various light strips and individual LEDs)
- Light Control Button
- Instructions for Use (this manual)
- Tweezers (for precise placement of small components)
- Battery Box (requires AAA batteries, not included)
- USB Power Cable

Light Kit Only – Not Model

Package Include:



Light Control Button



Light Kits



Instructions for Use



Tweezers



Battery Box
AAA not included

Image 2: An illustration of the BrickSoul LED Light Up Kit package contents, showing the main box, light control button, individual light kits, instruction manual, tweezers, and battery box.

3. INSTALLATION GUIDE

The BrickSoul LED kit is designed for straightforward installation. Follow the numbered step-by-step instructions provided in the included PDF guide or video tutorials available online. No specialized skills are required.

1. **Preparation:** Ensure your Lego Wall-E & EVE 43279 model is fully assembled. You may need to carefully remove a few bricks to integrate the lighting components.
2. **Component Placement:** Refer to the detailed instructions for specific placement of LED strips and individual lights within the Lego model. Use the provided tweezers for precise handling of small wires and components.
3. **Wiring:** Connect the light components to the main control board as indicated in the guide. Ensure all connections are secure. The wires are made from durable copper.
4. **Power Connection:** The kit can be powered via USB or by 3-5V AAA batteries (not included) inserted into the

battery box. Connect the power source to the main control board.

5. **Reassembly:** Carefully reassemble any Lego bricks that were removed during installation, ensuring wires are not pinched or damaged.

BRINGING EVERY DETAIL TO LIFE

Model is for Display Use Only and NOT INCLUDED





Image 3: Detailed close-up views of the BrickSoul LED lights integrated into the Lego Wall-E and EVE models, showcasing how the lights illuminate specific features.

4. OPERATION

Once the BrickSoul LED Light Up Kit is installed and connected to a power source, you can operate it using the provided Light Control Button.

- **Power On/Off:** Press the Light Control Button once to turn the lights on or off.
- **Music Mode:** The kit features an upgraded music mode that integrates sound effects with the lighting. Specific instructions for activating and controlling the music mode will be detailed in the supplementary PDF/video guides. This mode is designed to recreate the original atmosphere and sound effects, enhancing the immersive experience.

New Upgrade, Better Than Others


Why BrickSoul Beats the Rest?



OURS



CLEAN AND TIDY WIRING




CRISP, VIBRANT ILLUMINATION



STRONG HOLD, STICKS TIGHT


OTHERS



TANGLED WIRES



DIM LIGHTING



FALLS OFF EASILY

Image 4: The BrickSoul LED Light Up Kit illuminating the Lego Wall-E and EVE models in a nighttime setting, with a hand demonstrating the use of the light control button.

5. MAINTENANCE

To ensure the longevity and optimal performance of your BrickSoul LED Light Up Kit, follow these maintenance guidelines:

- **Cleaning:** Gently wipe the LED components and wires with a dry, soft cloth if dust accumulates. Avoid using liquids or abrasive cleaners.
- **Handling:** Handle the wires and connectors with care to prevent bending or breaking.
- **Storage:** If disassembling the kit for storage, ensure all components are stored in a dry, cool place away from direct sunlight.
- **Battery Replacement:** If using AAA batteries, replace them when the light intensity diminishes. Ensure correct polarity when inserting new batteries.

6. TROUBLESHOOTING

If you encounter any issues with your BrickSoul LED Light Up Kit, please refer to the following common troubleshooting steps:

- **Lights Not Turning On:**
 - Check all power connections (USB or battery box).
 - Ensure batteries are correctly inserted and not depleted if using battery power.
 - Verify that all light components are securely connected to the control board.
- **Flickering Lights:**
 - Inspect wire connections for looseness.
 - Ensure the power source is stable.
- **Music Mode Not Functioning:**
 - Refer to the specific instructions for activating the music mode.
 - Ensure all sound-related components are correctly installed.

For issues such as bent connectors or broken wires, BrickSoul offers a worry-free warranty and quick, hassle-free replacements. Please contact BrickSoul support for assistance.

7. PRODUCT SPECIFICATIONS

Feature	Detail
Model Number	43279-sound
Material	ABS Plastic, Copper Wire
Power Input	3-5V (USB or AAA Batteries)
Number of Light Sources	10
Batteries Required	1 AAA (not included)
Special Features	Non-Toxic, Upgraded Music Mode
Item Weight	136 g (0.3 Pounds)
Item Dimensions (LxWxH)	16.2 x 11 x 3.4 Centimeters (6.36 x 4.32 x 1.33 Inches)

8. WARRANTY AND SUPPORT

BrickSoul provides a worry-free warranty for its LED Light Up Kits. If you experience any accidental damage, such as bent connectors or broken wires, BrickSoul offers quick and hassle-free replacements to ensure your building experience remains smooth.

For any questions, technical support, or warranty claims, please contact the BrickSoul support team. Contact information can typically be found on the BrickSoul official website or through the retailer where the product was purchased.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question