

[Manuals.plus](#) /

› [Boomcore](#) /

› Boomcore 4-Pack Tracker Tags Instruction Manual - Model IF401

Boomcore IF401

Boomcore 4-Pack Tracker Tags Instruction Manual

MODEL: IF401

Brand: Boomcore

Introduction

The Boomcore 4-Pack Tracker Tags are designed to help you easily locate your valuable items. These smart tags connect to the global Apple Find My Network, utilizing billions of iOS devices to provide accurate tracking without any subscription fees. The tags feature a loud sound-emitting component for nearby searches and a 'Left Behind Reminder' to prevent accidental loss. With Apple MFi certification, all communication within the Find My network is anonymous and encrypted, ensuring your privacy and data security.

What's in the Box

- 4 x Boomcore Tracker Tags
- 4 x Built-in CR2032 Batteries (pre-installed)
- 1 x Extra Replacement CR2032 Battery
- 4 x Lanyards

COMPACT AND PORTABLE



Boomcore Tag*4



Built-in Battery*4
Backup Battery*1



Lanyard*4

Image: The package contents, including four Boomcore tags, lanyards, and an extra battery.

Setup

Follow these steps to set up your Boomcore Tracker Tags with your iOS device:

1. **Activate the Tag:** Each tag comes with a blue tab. Pull this tab out to activate the pre-installed battery. You will hear two beeps, indicating the tag is active.

2. **Enable Bluetooth:** Ensure Bluetooth is turned on your iPhone, iPad, or iPod touch.
3. **Open Find My App:** Launch the 'Find My' app on your iOS device.
4. **Add New Item:** Navigate to the 'Items' tab and tap the '+' icon. Select 'Add Other Item'.
5. **Connect:** Your device will search for nearby tags. Once 'Boomcore Tag' appears, tap 'Connect'.
6. **Name Your Item:** Enter a descriptive name for your tag (e.g., 'Keys', 'Wallet', 'Backpack'). You can also choose an emoji to represent it.
7. **Agree to Terms:** Review and agree to the terms and conditions.
8. **Finish Setup:** Complete the setup process. Your tag is now linked to your Apple ID and visible in the Find My app.

NEVER LOSE IMPORTANT ITEMS AGAIN



Image: Visual guide for connecting the Boomcore Tag to the Find My app.

Your browser does not support the video tag.

Video: A user demonstrates how to set up the tracker tag with an iPhone using the Find My app.

Your browser does not support the video tag.

Video: A quick demonstration of the setup process for the tracker tag, highlighting its ease of use.

Lost Mode and Multi-User Sharing

- **Activate Lost Mode:** If an item with a Boomcore Tag is lost, you can enable 'Lost Mode' in the Find My app. This allows nearby Apple devices to detect your tag and provide its location to you. You can also leave contact information for anyone who finds it.
- **Multi-User Sharing:** For iOS 17/iPadOS 17/macOS 14 or later, you can share your Boomcore Tag with up to 5 contacts, allowing multiple users to track the same item.

ACTIVATE THE LOST MODE




Image: Steps to activate Lost Mode and securely share contact information.

Operating Your Tracker Tags

- **Locate Nearby Items:** When your item is within 262 feet, open the Find My app and tap 'Play Sound'. The Boomcore Tag will emit a loud 108dB beep to help you pinpoint its location. You can also ask Siri for assistance.
- **Track Far Away Items:** If your item is beyond 262 feet, the Find My network will help you locate it. The app will display the most recent location on a map, updated by other iOS devices in the vicinity.
- **Left Behind Reminder:** Your iOS device will send a notification if you leave a Boomcore Tag behind and it goes out of connection range. This notification will include the last known location of the tag.

LOUDER, CLEAR, ITEM FOUND

Unique silicone chamber enhances resonance.




Up to
108 dB

Image: The internal design of the Boomcore Tag, emphasizing its loud sound feature.

LIFESAVER FOR LITTLE THINGS

Ring your keys and never turn the house upside down again.



Sound Volume
Up to **108 dB**



Range
Over **262 ft**

Image: Demonstrating how to use the Find My app to make the tag ring and locate keys.

THOUGHTFUL ASSISTANT WHEN FORGETTING

A glimpse of the pop-up window, and the memory surfaces.



Image: Illustrates tracking an item (backpack) beyond sight using the Find My app.

LOST TAG CAN BE FOUND, GREATER PEACE OF MIND

Leave your contact information to easily return lost items.

Your contact info is securely shared only when needed.



Image: Shows a 'left behind' notification on an iPhone, reminding the user about a forgotten item.

ONE TOUCH, INSTANT RING —FIND EASILY!



Image: Demonstrates using the tag to quickly locate luggage at an airport.

Maintenance

The Boomcore Tags are designed for long-lasting use with up to 12 months of battery life. An extra replacement battery is included in your 4-pack.

Battery Replacement

When the battery level is low, you will be notified via the Find My app. To replace the battery:

1. Open the back cover of the tag using a small prying tool (not included, but similar to a guitar pick).
2. Remove the old CR2032 coin cell battery.
3. Insert a new CR2032 battery with the positive (+) side facing up.
4. Align the battery cover and press firmly to close until it clicks securely.


CONNECT THE BOOMCORE TAG

01




Turn on Bluetooth and the "Find My" App.

02



Tap "Other Supported Items".

03



Press the Boomcore Tag, connection is successful when you hear the tone.

Image: Instructions for replacing the CR2032 battery in the Boomcore Tag.

Troubleshooting

- **Tag Not Connecting:** Ensure Bluetooth is enabled on your iOS device and the tag's battery is active. Try resetting the tag by removing and reinserting the battery.
- **Sound Not Loud Enough:** Check for any obstructions around the tag that might muffle the sound. Ensure the tag is not deeply buried in soft materials.
- **Inaccurate Location:** Location accuracy depends on the proximity of other iOS devices in the Find My network. In areas with fewer Apple devices, location updates might be less frequent or precise.
- **Battery Life Issues:** Ensure you are using a fresh CR2032 battery. Extreme temperatures can affect battery performance.
- **Compatibility:** Boomcore Tags are compatible with iPhone, iPad, and iPod touch models running iOS 14.5 or later. Multi-User Sharing requires iOS 17/iPadOS 17/macOS 14 or later. These tags are not compatible with Android devices.

Specifications

Model Number	IF401
Product Dimensions	1.53 x 0.35 x 1.28 inches (38.86 x 9.01 x 32.46 mm)
Item Weight	0.28 ounces
Color	Black
Material	Plastic
Battery Type	CR2032 Coin Cell

Battery Life	Up to 12 months
Sound Volume	Up to 108 dB
Bluetooth Range	Over 262 feet (80 meters)
Compatibility	iOS 14.5 or later (iOS 17+ for Multi-User Sharing)



Image: Detailed dimensions and included accessories of the Boomcore Tag.

Safety Information

- The Boomcore Tag is Apple MFi certified, ensuring secure and private communication within the Find My network. Location data and history are never stored on the tracker itself.
- **WARNING:** This product contains a coin cell battery. Keep batteries away from children and pets. Ingestion of a coin cell battery can cause severe internal chemical burns and can be fatal within 2 hours. Seek immediate medical attention if swallowed.

Warranty and Support

Boomcore products are covered by a manufacturer's warranty. For specific warranty details, technical support, or customer service inquiries, please refer to the contact information provided with your purchase or visit the official Boomcore website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question