



[Manuals.plus](#) /

› [Zichen](#) /

› Zichen Haswing Wireless Foot Control Instruction Manual for 50700-V18, 50718D-V08, and 50706-V03 Trolling Motors

Zichen 50805

Zichen Haswing Wireless Foot Control Instruction Manual

For 50700-V18, 50718D-V08, and 50706-V03 Trolling Motors

1. PRODUCT OVERVIEW

The Zichen Haswing Wireless Foot Control provides convenient, hands-free operation for compatible Haswing trolling motors. This manual outlines the features, setup, and operation to ensure optimal performance and user experience.



Image: Zichen Haswing Wireless Foot Control unit.

2. COMPATIBILITY INFORMATION

This Wireless Foot Control is exclusively compatible with the following Haswing trolling motor series:

- Haswing 50700-V18
- Haswing 50718D-V08
- Haswing 50706-V03

Before purchase, verify your motor's serial number. The serial number is typically located on the inside of the side door, on the rear of the gearbox, or on the mounting bracket of your trolling motor.

3. WHAT'S IN THE BOX

The package includes:

- Zichen Haswing Wireless Foot Control unit
- USB Charging Cable
- Comes with housing

4. PRODUCT FEATURES AND CONTROLS




Image: Diagram illustrating the layout and function of the Wireless Foot Control buttons.

The Wireless Foot Control features intuitive buttons for comprehensive motor control:

- **Power Off Button / Charging Port:** Located at the top of the unit.
- **Control Display:** Shows current settings and status.
- **Speed Up (Rabbit icon):** Increases motor speed.
- **Speed Down (Turtle icon):** Decreases motor speed. This button also functions as the pairing button.
- **Turn Left:** Steers the motor to the left.
- **Turn Right:** Steers the motor to the right.
- **Motor On/Off:** Activates or deactivates the motor.
- **Spinning Footrest:** Allows for precise directional control.




Image: Close-up view of the Speed Up (Rabbit) and Speed Down (Turtle) buttons, along with the Motor On/Off button.



Image: Close-up view of the Turn Left and Turn Right directional control buttons.

5. SETUP AND CHARGING

5.1 Charging the Wireless Foot Control

Charge the wireless foot control using the provided USB cable. The charging indicator will show red during charging and turn green when fully charged. If no light appears, check the cable connection or try using a mobile power bank. For optimal performance, use charging equipment that meets standard specifications.




Image: Diagram illustrating the USB charging port on the Wireless Foot Control and the connection to a DC 5V 500mA USB charging cable.

5.2 Pairing Instructions

Before pairing the wireless foot controller with your Haswing trolling motor, ensure the trolling motor is already paired with any wireless remote control you are using.

The pairing button on the wireless foot control is the same as the "Turtle" (speed down) button.

1. Ensure your trolling motor is powered on.
2. Simultaneously press and hold the "magnifying glass" button (located below the power reader on the motor) and the "Turtle" button (on the wireless foot control).
3. Hold both buttons for 3 seconds, or until you hear three beeps, indicating a successful connection.




Image: Diagram illustrating the simultaneous pressing of the "magnifying glass" button on the trolling motor and the "Turtle" button on the foot control for pairing.

Your browser does not support the video tag.

Video: This video demonstrates the pairing process for the 2.4G Wireless Foot Control with the trolling motor. It shows how to connect the battery, then press and hold the remote and motor pairing buttons for 5 seconds until 3 beeps indicate a successful connection.

Your browser does not support the video tag.

Video: This video demonstrates the pairing process for the 2.4G Remote with the trolling motor. While this video specifically shows the remote, the initial pairing of the remote is a prerequisite for pairing the foot control, as mentioned in the instructions.

6. OPERATING INSTRUCTIONS

The Wireless Foot Control allows for precise and responsive operation of your trolling motor:

- **Speed Control:** Use the "Rabbit" button to increase speed and the "Turtle" button to decrease speed.
- **Directional Control:** Press the "Turn Left" or "Turn Right" buttons to steer the motor. The spinning footrest can also be used for fine-tuning direction.
- **Motor On/Off:** Use the dedicated Motor On/Off button to engage or disengage the propeller.




Image: Illustration of a foot operating the Wireless Foot Control, demonstrating the use of the spinning footrest for steering.

The foot control allows you to operate your motor from up to 32.8 feet away, whether you are on the boat or on the shoreline.

Your browser does not support the video tag.

Video: This video provides a general overview of the Wireless Foot Control's functions and how it interacts with the trolling motor.

7. MAINTENANCE

To ensure the longevity and optimal performance of your Zichen Haswing Wireless Foot Control, follow these maintenance guidelines:

- **Cleaning:** Regularly wipe down the foot control with a damp cloth to remove dirt, salt, and debris. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, store the foot control in a dry, cool place away from direct sunlight and extreme temperatures.
- **Charging Port:** Keep the USB charging port clean and free of moisture. Ensure the waterproof plug is securely in place when not charging.
- **Cable Inspection:** Periodically inspect the USB charging cable for any signs of wear, fraying, or damage. Replace if necessary.

8. TROUBLESHOOTING

If you encounter issues with your Wireless Foot Control, consider the following:

- **Not Responding:** Ensure the foot control is charged and powered on. Re-attempt the pairing process as described in Section 5.2.
- **Charging Indicator Not Lighting Up:** Check the USB cable connection. Try using a different USB power source or mobile power bank.
- **Limited Control Distance:** Ensure there are no obstructions between the foot control and the trolling motor. The maximum control distance is 32.8 feet.
- **Intermittent Connection:** Check for potential interference from other wireless devices. Ensure the trolling motor's remote control is properly paired first.

If problems persist, consult the full product manual for your Haswing trolling motor or contact Zichen customer support.

9. SPECIFICATIONS

Feature	Specification
Brand	Zichen
Model Number	50805
Item Model Number	wireless foot control
Control Distance	Up to 32.8 feet (10 meters)
Charging Method	USB Cable
Color	Black
UPC	722487401421

10. WARRANTY AND SUPPORT

For warranty information, technical support, or any product-related inquiries, please refer to the documentation included with your Haswing trolling motor or contact Zichen customer service directly. Keep your purchase receipt for warranty claims.