

## Keurig K-Mini Go

# Keurig K-Mini Go Single Serve Coffee Maker

## Instruction Manual

### IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

1. Read all instructions before use.
2. Do not touch hot surfaces. Use handles or knobs.
3. To protect against fire, electric shock, and personal injury, do not immerse cord, plugs, or the appliance in water or other liquid.
4. Close supervision is necessary when any appliance is used by or near children.
5. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
6. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
7. The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or personal injury.
8. Do not use outdoors.
9. Do not let cord hang over edge of table or counter, or touch hot surfaces.
10. Do not place on or near a hot gas or electric burner, or in a heated oven.
11. Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off," then remove plug from wall outlet.
12. Do not use appliance for other than intended use.

### WHAT'S IN THE BOX

Your Keurig K-Mini Go Single Serve Coffee Maker package includes:

- Keurig K-Mini Go Brewer
- User Guide

## SETUP

Follow these steps for initial setup of your Keurig K-Mini Go coffee maker.

### 1. Plug In

Plug the brewer into a grounded outlet. The brewer will automatically turn on.

### 2. Fill Water Reservoir

Remove the water reservoir lid and fill the reservoir with fresh water up to the MAX fill line (1.24 L capacity). Replace the lid.



Image: Water being poured into the 1.24 L removable water reservoir of the Keurig K-Mini Go coffee maker. This reservoir allows for multiple brews without constant refilling.

### 3. Cleansing Brew

Place a large mug (at least 10 oz) on the drip tray. Lift and lower the handle to open and close the K-Cup pod holder. Do not insert a K-Cup pod. Press the 8 oz brew button. The brewer will dispense hot water. Discard the hot water. Your brewer is now ready for use.

## OPERATING INSTRUCTIONS

Brewing with your Keurig K-Mini Go is simple:

1. **Add Water:** Ensure the 1.24 L removable water reservoir is filled with fresh water.
2. **Insert K-Cup Pod:** Lift the handle and place a K-Cup pod into the K-Cup pod holder. Lower the handle completely to puncture the pod.
3. **Place Mug:** Place a mug on the drip tray. For travel mugs, remove the drip tray to accommodate taller cups (up to 17.8 cm tall).



Image: The Keurig K-Mini Go coffee maker shown with its drip tray removed, demonstrating its ability to accommodate a tall travel mug for on-the-go convenience.

4. **Select Brew Size:** Choose your desired brew size from 8 oz (237 ml), 10 oz (296 ml), or 12 oz (355 ml) by pressing the corresponding button.
5. **Strong Brew (Optional):** For a bolder cup, press the **STRONG** button before selecting your brew size.



Image: Close-up of the Keurig K-Mini Go's control panel, highlighting the 8, 10, and 12 oz brew size selection buttons, along with the 'STRONG' brew option for a more intense coffee flavor.

6. **Brew:** The selected brew button will illuminate, and the brewing process will begin. Once brewing is complete, the button will turn off.
7. **Enjoy:** Carefully remove your mug and enjoy your freshly brewed coffee.

## MAINTENANCE

Regular cleaning and maintenance ensure optimal performance and longevity of your Keurig K-Mini Go.

### Cleaning the Exterior

Wipe the exterior of the brewer with a damp, non-abrasive cloth. Do not immerse the brewer in water or other liquids.

### Cleaning the Drip Tray

The drip tray can accumulate coffee spills. Remove the drip tray and wash it with warm, soapy water. Rinse thoroughly and dry. The drip tray is not dishwasher safe.

### Descaling

Over time, calcium deposits (scale) can build up in your brewer, affecting performance. The 'DESCALE' indicator light will illuminate when descaling is recommended. Follow these general steps for descaling:

1. Empty the water reservoir.
2. Pour a full bottle of Keurig Descaling Solution into the water reservoir.
3. Place a large mug on the drip tray.
4. Perform a cleansing brew without a K-Cup pod. Repeat until the reservoir is empty.
5. Rinse the reservoir thoroughly and fill with fresh water.
6. Perform several fresh water cleansing brews until the descaling solution is completely flushed out.

Refer to the official Keurig website or contact customer support for detailed descaling instructions specific to your model.

## TROUBLESHOOTING

If you encounter issues with your Keurig K-Mini Go, refer to the following common problems and solutions:

| Problem                  | Possible Cause                              | Solution                                                                                 |
|--------------------------|---------------------------------------------|------------------------------------------------------------------------------------------|
| Brewer does not turn on. | No power.                                   | Ensure the brewer is securely plugged into a grounded outlet. Check the circuit breaker. |
| Coffee not brewing.      | Insufficient water in reservoir.            | Fill the water reservoir to the MAX fill line.                                           |
| Coffee not brewing.      | K-Cup pod not properly seated or punctured. | Lift and lower the handle completely to ensure the K-Cup pod is punctured.               |
| Weak coffee.             | Brew size too large for desired strength.   | Select a smaller brew size or use the Strong Brew button.                                |
| Coffee grounds in cup.   | K-Cup pod filter issue or needle blockage.  | Remove and rinse the K-Cup pod holder. Clean the exit needle with a paper clip.          |
| DESCALE light is on.     | Calcium buildup.                            | Perform a descaling procedure as outlined in the Maintenance section.                    |

## SPECIFICATIONS

- Brand: Keurig
- Model Name: K-Mini Go
- Model Number: 611247409237
- Capacity: 1.24 Liters (removable reservoir)
- Color: Gray
- Product Dimensions (D x W x H): 28.7 cm x 11.4 cm x 42.7 cm

Image: A visual representation of the Keurig K-Mini Go coffee maker's dimensions, including its height with the handle closed (30.7 cm) and open (42.7 cm), width (11.4 cm), and depth (28.7 cm).

Special Features: Strong Brew Button, Portable, Space-Saving Design

Image: The Keurig K-Mini Go coffee maker highlighting its compact, space-saving design, measuring only 11.4 cm in width, ideal for small counter spaces.

- Coffee Maker Type: Drip Coffee Machine
- Material: Plastic
- Operation Mode: Semi-Automatic
- Coffee Input Type: Pods (K-Cup compatible)
- Included Components: Brewer, User Guide
- Country of Origin: China

## WARRANTY AND SUPPORT

Keurig provides a limited warranty for its brewers. For specific warranty details, registration, and customer support, please visit the official Keurig website or contact their customer service department.

Keurig Customer Support:

- Website: [www.Keurig.ca](http://www.Keurig.ca)
- Refer to your product packaging or the Keurig website for phone numbers and hours of operation.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**