Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

BLUEING NP14Y

BLUEING NP14Y 14-inch Pink Laptop User Manual

Model: NP14Y | Brand: BLUEING

Introduction

This manual provides essential information for setting up, operating, and maintaining your BLUEING NP14Y 14-inch Pink Laptop. Please read it thoroughly to ensure proper use and to maximize your product's performance and longevity.

Safety Information

Observe the following safety precautions to prevent damage to the device or personal injury:

- Do not expose the laptop to extreme temperatures, direct sunlight, or high humidity.
- Avoid placing heavy objects on the laptop.
- Keep liquids away from the device to prevent electrical shock or damage.
- Use only the provided power adapter and accessories.
- Do not attempt to disassemble or repair the laptop yourself. Contact qualified service personnel for assistance.

Package Contents

Verify that all items are present in the package:

- 1 × BLUEING NP14Y 14-inch Pink Laptop
- 1 × Power Adapter
- 1 × User Manual

Product Overview

The BLUEING NP14Y is a 14-inch laptop designed for everyday computing tasks, featuring a vibrant Full HD IPS display and a powerful Gold 6500Y processor.



Image: The BLUEING NP14Y 14-inch Pink Laptop, showcasing its sleek design and vibrant display.

Key Features

- **Processor:** Gold 6500Y (2-Core, 4-Threaded, Up to 3.4GHz)
- **Memory:** 16GB DDR3 RAM
- **Storage:** 512GB M.2 NVMe SSD
- **Display:** 14.0-Inch 1920x1080 Full HD IPS
- **Operating System:** Windows 11
- **Connectivity:** Wi-Fi 5, Bluetooth 5.2, Type-C, HDMI, USB 3.2 Gen 1, USB 2.0
- **Special Features:** Backlit Keyboard, Fingerprint Reader, HD Camera with Privacy Slider



Image: An overview of the laptop's key features including the Gold 6500Y CPU, 16GB RAM, 512GB SSD, 1080P FHD IPS screen, WiFi 5G+2.4G, Bluetooth 5, HD Camera, and 5000mAH 38Wh battery.

Ports and Connectors

The laptop is equipped with various ports for versatile connectivity:

- 1 x Type-C Full-Function Port
- 1 x HDMI 1.4 Port
- 2 x USB 3.2 Gen 1 (5Gbps) Type-A Ports
- 1 x USB 2.0 Type-A Port
- 1 x 3.5mm Audio Jack
- 1 x TF Card Slot
- 1 x Kensington Lock Slot



Image: A detailed view of the laptop's multiple ports, including USB, HDMI, Type-C, headphone jack, and TF card slot.

Setup

Initial Power-On

1. Unpack the laptop and power adapter.
2. Connect the power adapter to the laptop's charging port and a power outlet.
3. Open the laptop lid. The laptop may power on automatically or you may need to press the power button.
4. Follow the on-screen instructions to complete the Windows 11 initial setup, including language, region, network connection, and user account creation.

Connecting to Wi-Fi

During initial setup or anytime thereafter, connect to a Wi-Fi network:

- Click the Wi-Fi icon in the taskbar.
- Select your desired network from the list.

- Enter the network password if prompted and click **Connect**.

Operating Instructions

Power Management

- **Power On:** Open the lid or press the power button.
- **Sleep Mode:** Close the lid or press the power button briefly.
- **Shut Down:** Click the Start button, then Power, and select **Shut down**.

Keyboard and Touchpad

The laptop features a full-size keyboard and a large touchpad for comfortable navigation.

Video: Demonstrates the laptop's backlit keyboard and touchpad functionality, including navigation and interaction with the operating system.

- **Keyboard Backlight:** Press **Fn + F5** to adjust the keyboard backlight brightness or turn it off.
- **Touchpad Gestures:** The large trackpad supports multi-touch gestures for scrolling, zooming, and switching applications.

Webcam and Privacy Slider

The integrated HD camera is located above the display. A manual privacy slider is provided for enhanced security.

- To activate the privacy shield, slide the cover over the camera lens.
- To use the camera, slide the cover away from the lens.

Fingerprint Reader

The fingerprint reader allows for quick and secure login.

- To set up, navigate to Windows Settings > Accounts > Sign-in options > Fingerprint recognition (Windows Hello).
- Follow the on-screen instructions to register your fingerprint.

Display and Visuals

The 14.0-inch Full HD IPS display offers clear and vibrant visuals.



Image: The laptop display showcasing clear vision and lasting comfort with Full HD IPS technology.

The display can open up to 180 degrees, allowing for flexible viewing angles and easy screen sharing.

Video: Highlights the laptop's 180-degree hinge, allowing the screen to lay completely flat for easy sharing.

Maintenance

Cleaning the Laptop

- Use a soft, lint-free cloth dampened with water or a screen cleaner to wipe the display.
- For the keyboard and chassis, use a soft, dry cloth. Avoid abrasive cleaners.

Software Updates

Regularly update your Windows operating system and drivers to ensure optimal performance and security.

- Go to **Settings > Windows Update** to check for and install updates.

Battery Care

To prolong battery life:

- Avoid fully discharging the battery frequently.
- Store the laptop in a cool, dry place when not in use for extended periods.
- Optimize power settings in Windows to conserve battery.



Image: Illustrates the laptop's large capacity 38Wh (5000mAH) lithium-polymer battery, designed for extended use.

Troubleshooting

Common Issues and Solutions

- **Laptop does not power on:** Ensure the power adapter is securely connected and the battery has sufficient charge. Try a different power outlet.
- **No Wi-Fi connection:** Check if Wi-Fi is enabled in Windows settings. Restart your router and the laptop.
- **Slow performance:** Close unnecessary applications, check for background updates, and ensure sufficient free storage space.

- **Keyboard backlight not working:** Press Fn + F5 to cycle through brightness levels or turn it on.

Specifications

Feature	Specification
Brand	BLUEING
Model Name	NP14Y
Screen Size	14 Inches
Screen Resolution	1920 x 1080 pixels (Full HD IPS)
Processor	Pentium Gold 6500Y (Up to 3.4 GHz)
RAM	16 GB DDR3 (1866 MHz)
Hard Drive	512 GB SSD (M.2 2280 PCIe 3.0 NVMe/SATA)
Graphics Coprocessor	UHD Graphics 615
Operating System	Windows 11
Wireless Type	802.11a/b/g/n/ac (Wi-Fi 5), Bluetooth 5.2
USB 3.0 Ports	2
USB 2.0 Ports	1
Video Output	HDMI 1.4
Charging Port	Type-C PD Charging
Audio Interface	3.5mm CTIA Jack
Extended Storage	TF Card Slot
Camera	0.3MP with Privacy Camera Lock
Battery Life (Average)	5 Hours (38Wh / 5000mAH)
Item Weight	3.5 pounds (1400g)
Product Dimensions	12.7 x 0.8 x 8.3 inches
Color	Pink

Warranty and Support

BLUEING provides comprehensive support for your laptop.

- **Warranty:** One year after-sales service for BLUEING laptops.
- **Technical Support:** Permanent technical support is available.
- **Customer Service:** Quick reply within 24 hours.
- **Returns:** No reason to return within 30 days.

For assistance, log in to your Amazon buyer account, find the order, and click "Get Help" or refer to the support email provided in your order details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FQTHLGXP

More documents and user manuals: **https://manuals.plus/**