

- Manuals.plus /
- › SakerPlus /
- › SakerPlus 3-in-1 Portable High Speed USB 3.0 Memory Storage 128GB User Manual

SakerPlus B0FQTP9911

SakerPlus 3-in-1 Portable High Speed USB 3.0 Memory Storage 128GB User Manual

Model: B0FQTP9911

1. INTRODUCTION

This manual provides comprehensive instructions for the SakerPlus 3-in-1 Portable High Speed USB 3.0 Memory Storage 128GB. This device is designed to expand storage and facilitate high-speed data transfer between various devices, including iPhones, iPads, Android phones, and computers (Mac/Windows).

2. PRODUCT OVERVIEW

The SakerPlus 3-in-1 Flash Drive features a compact, retractable design with multiple connectors for broad compatibility.



Figure 2.1: SakerPlus 3-in-1 Portable High Speed USB 3.0 Memory Storage 128GB. This image shows the overall design of the flash drive, highlighting its compact and portable nature.

Key Features:

- **3-in-1 Connectivity:** Equipped with Lightning, USB-A 3.0, and Micro USB connectors.
- **High-Speed Data Transfer:** Utilizes USB 3.0 technology for fast file transfers.
- **Space Expansion:** Provides additional storage for mobile devices.
- **File Management:** Supports basic file operations via a companion app.
- **Advanced Security:** Features password and Touch ID protection for data.
- **Retractable Design:** Protects connectors when not in use.



Figure 2.2: The flash drive connected to both an iPhone and a laptop, demonstrating its versatile connectivity options.

Your browser does not support the video tag.

Video 2.1: This video demonstrates the various ports (Type-C, USB-A 3.0, Micro USB) of a similar 3-in-1 flash drive, showcasing its multi-device compatibility.

3. SETUP

1. **Download the Companion App:** For mobile device functionality (iPhone/iPad/Android), download the "Easy Flash Pro" app from your device's app store.
2. **Connect the Flash Drive:**
 - **For iPhone/iPad:** Slide the toggle button to reveal the Lightning connector and plug it into your device.
 - **For Android (Micro USB):** Slide the toggle button to reveal the Micro USB connector and plug it into your device.
 - **For PC/Laptop (USB-A 3.0):** Slide the toggle button to reveal the USB-A 3.0 connector and plug it into your computer's USB port.
3. **Initial Recognition:** Your device should automatically recognize the flash drive. If prompted, allow the companion app to access the drive.



Figure 3.1: An iPhone with the SakerPlus flash drive connected, illustrating the 'Plug and Play' functionality for instant storage expansion.

4. OPERATING INSTRUCTIONS

4.1. File Transfer and Management (via App)

1. Open the "Easy Flash Pro" app on your mobile device.
2. Select "Internal Storage" to access your device's files or "External Storage" to access the flash drive.
3. To transfer files from your device to the flash drive:
 - Navigate to the desired files on your device.
 - Select the files you wish to transfer.
 - Choose the "Copy" or "Move" option and select a destination folder on the "External Storage" (flash drive). You can create new folders as needed.
4. To transfer files from the flash drive to your device:
 - Navigate to the desired files on the "External Storage".
 - Select the files you wish to transfer.
 - Choose the "Copy" or "Move" option and select a destination folder on your "Internal Storage" (device).
5. The app also supports basic file operations such as creating new folders, copying, cutting, and deleting files directly on the flash drive.

4.2. Using the In-App Camera/Recorder

1. Within the "Easy Flash Pro" app, select the "Camera" or "Recorder" icon.
2. You can directly capture photos or record videos/audio, and these will be saved directly to the flash drive, bypassing

your device's internal storage.



Figure 4.1: An iPhone using the in-app camera feature to capture a photo directly to the connected SakerPlus flash drive, saving internal phone storage.

4.3. Security Features

The companion app allows you to protect your data on the flash drive:

- **Password Protection:** Set a 6-digit password for the flash drive to prevent unauthorized access.
- **Touch ID:** For compatible devices, enable Touch ID for quick and secure access to your protected files.

Your browser does not support the video tag.

Video 4.1: This video demonstrates the process of connecting a 3-in-1 USB 3.0 flash drive to an Android phone and an iPhone, showing file transfer and backup functionalities through a companion app.

5. MAINTENANCE

- Keep the flash drive in a dry environment and avoid extreme temperatures.
- Ensure connectors are fully retracted when not in use to prevent damage.
- Regularly back up important data to multiple locations for added security.
- Avoid physical impact or dropping the device.

6. TROUBLESHOOTING

6.1. Device Not Recognized

- **Check Connection:** Ensure the flash drive is fully and correctly inserted into the device port.

- **Toggle Switch:** Verify the correct connector (Lightning, Micro USB, USB-A) is extended using the toggle switch.
- **Restart Device:** Try restarting your phone, tablet, or computer.
- **App Permissions:** For mobile devices, ensure the "Easy Flash Pro" app has necessary permissions to access external storage.
- **Compatibility:** Confirm your device's operating system and hardware are compatible with the flash drive.

6.2. Slow Transfer Speeds

- **USB 3.0 Port:** For optimal speeds, ensure you are connecting to a USB 3.0 port on your computer (usually indicated by a blue insert).
- **File Size:** Transferring many small files can be slower than transferring one large file of the same total size.
- **Device Performance:** The speed of your host device (phone/computer) can affect transfer rates.



Figure 6.1: An illustration detailing typical read/write speeds for USB 3.0, Lightning, and Micro USB connections, emphasizing the high-speed capability of USB 3.0.

6.3. App Issues

- **Update App:** Ensure the "Easy Flash Pro" app is updated to the latest version.
- **Reinstall App:** If issues persist, try uninstalling and reinstalling the app.

7. SPECIFICATIONS

Feature	Detail
Brand	SakerPlus
Model	B0FQTP9911

Memory Storage Capacity	128 GB
Hardware Interface	USB 3.0
Hardware Connectivity Technology	Lightning, USB Type A
Special Feature	Dual USB Connector, Retractable Design
Compatible Devices	iPhone, iPad, Android, Mac, Windows

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the product packaging or contact SakerPlus directly through their official channels. Keep your purchase receipt for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question