

CHiQ L43QST

CHiQ L43QST 43-inch Full HD QLED Google Smart TV User Manual

1. INTRODUCTION

This manual provides essential instructions for the setup, operation, and maintenance of your CHiQ L43QST 43-inch Full HD QLED Google Smart TV. Please read this manual thoroughly before using your television and retain it for future reference. Following these instructions will ensure proper use and extend the lifespan of your device.

2. SAFETY INFORMATION


To reduce the risk of electric shock, fire, or injury, always observe the following safety precautions:

- Do not expose the TV to rain or moisture.
- Do not open the TV casing; refer all servicing to qualified personnel.
- Ensure proper ventilation around the TV. Do not block ventilation openings.
- Place the TV on a stable, level surface to prevent it from falling.
- Unplug the TV from the power outlet during lightning storms or when unused for long periods.
- Keep small parts and batteries out of reach of children.

3. PACKAGE CONTENTS

Verify that all items are present in the packaging:

- CHiQ L43QST 43-inch Smart TV
- Remote Control (requires 2 AAA batteries, not always included)
- TV Stand (assembly required)
- Wall Mount Components (for optional wall mounting)
- Power Cable
- User Manual (this document)



A front view of the CHIQ L43QST 43-inch Smart TV, showcasing its slim bezel design.

4. SETUP

4.1. Stand Assembly or Wall Mounting

Stand Assembly: Carefully place the TV screen-down on a soft, clean surface. Attach the provided stand components to the designated slots on the bottom of the TV using the screws included. Ensure the stand is securely fastened.

Wall Mounting: If you intend to wall mount the TV, refer to the instructions provided with your wall mount kit. Ensure the wall mount is compatible with the TV's VESA mounting pattern and that the wall can support the TV's weight. Professional installation is recommended for wall mounting.

4.2. Connecting Devices

Your CHIQ L43QST TV offers various connectivity options:

- **HDMI Ports:** Connect external devices such as Blu-ray players, game consoles, or set-top boxes.
- **USB Ports:** Insert USB drives for media playback (photos, videos, music).
- **Ethernet Port:** For a stable wired internet connection.
- **Wi-Fi:** Connect to your home wireless network for internet access.
- **Bluetooth:** Pair wireless headphones, soundbars, or other compatible accessories.

4.3. Initial Power On and Google TV Setup

After connecting the power cable and any desired devices, press the power button on the TV or remote control. Follow the on-screen instructions to complete the initial setup, including language selection, network connection, and Google account sign-in for Google TV features.

5. OPERATING INSTRUCTIONS

5.1. Google TV Interface

Navigate the Google TV interface using your remote control. The home screen provides access to streaming apps, live TV, and personalized content recommendations. Use the directional pad and 'OK' button to select items.

5.2. Key Features

- **QLED Technology:** Experience vibrant and accurate colors due to the Quantum Dot film, enhancing the purity of the backlight.
- **Full HD Resolution (1920 x 1080):** Enjoy clear and sharp images with a resolution higher than standard HD.
- **HDR10 Support:** Benefit from improved contrast and finer details in both bright and dark scenes, providing a more realistic viewing experience.
- **Dolby Audio:** The integrated professional audio decoding technology enhances stereo and surround sound, delivering clear, powerful, and rich audio.
- **Chromecast Built-in:** Easily cast movies, shows, photos, and more from your phone or tablet directly to your TV.
- **Smart Voice Recognition:** Use voice commands through the remote control for convenient navigation and content search.
- **Parental Control:** Manage and restrict access to certain content or applications for younger viewers.
- **DLNA:** Share media content from compatible devices on your home network directly to your TV.

6. MAINTENANCE

To maintain your TV's performance and appearance:

- **Cleaning the Screen:** Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, slightly dampen the cloth with water or a specialized screen cleaner. Do not spray liquid directly onto the screen.
- **Cleaning the Casing:** Use a soft, dry cloth to wipe the TV casing. Avoid abrasive cleaners or solvents.
- **Ventilation:** Ensure the ventilation openings on the back of the TV are not blocked by dust or objects.
- **Power Off:** Always turn off and unplug the TV before cleaning or performing any maintenance.

7. TROUBLESHOOTING


If you encounter issues with your TV, refer to the following common solutions:

Problem	Possible Solution
No Power	Check if the power cable is securely plugged into the TV and the wall outlet. Try a different outlet.
No Picture/Sound	Ensure the correct input source is selected. Check cable connections to external devices.
Remote Control Not Working	Replace the batteries (2 AAA). Ensure there are no obstructions between the remote and the TV's IR sensor.
Network Connection Issues	Restart your router and modem. Check Wi-Fi password. For wired connections, ensure the Ethernet cable is properly connected.
Picture Quality Issues	Adjust picture settings (brightness, contrast, color). Ensure the content source is high quality.

8. SPECIFICATIONS

Feature	Detail
Brand	CHiQ
Model Number	L43QST
Screen Size	43 inches (108 cm)
Display Technology	QLED, LED
Resolution	Full HD (1920 x 1080p)
Refresh Rate	60 Hz
Operating System	Android, Google TV
Connectivity	Bluetooth, Ethernet, HDMI, USB, Wi-Fi
Special Features	Chromecast, Parental Control, DLNA, Smart Voice Recognition
Audio Technology	Dolby Audio
HDR Support	HDR10
Energy Efficiency Class	E
Power Consumption (SDR)	42 kWh/1000h
Power Consumption (HDR)	42 kWh/1000h
Product Dimensions (DxWxH)	20P x 95l x 58.3H cm

Feature	Detail
Aspect Ratio	16:9
Remote Control Batteries	2 AAA (not always included)









The EU energy efficiency label for the CHIQ L43QST television, indicating an energy class E and a consumption of 42 kWh per 1000 hours for both standard and HDR modes. It also shows the screen resolution as 1920x1080 pixels and a diagonal size of 43 inches (108 cm). For more details, visit the [EPREL database](#).

9. WARRANTY AND SUPPORT

For detailed warranty information, please refer to the warranty card included with your product or visit the

official CHiQ website. For technical support or service inquiries, please contact CHiQ customer service through their official channels.

Related Documents - L43QST

	<p>CHI Q 32" HD Google TV L32M9P - Portable Entertainment</p> <p>Explore the CHI Q 32" HD Google TV (L32M9P), a portable TV featuring Google Assistant, Google TV, Netflix, YouTube, and Amazon Prime Video. Learn about its specifications, features, and powering options, including an optional 5000mAh power bank.</p>
	<p>CHI Q U50QM10 User Manual</p> <p>User manual for the CHI Q U50QM10 television, covering setup, operation, safety instructions, and troubleshooting.</p>
	<p>CHI Q U65QM8V User Manual: Setup, Features, and Troubleshooting</p> <p>Comprehensive user manual for the CHI Q U65QM8V TV, covering safety instructions, setup, features like Smart TV, PVR, Bluetooth, Google Assistant, Chromecast, dbx-tv sound, and troubleshooting tips.</p>
	<p>CHI Q U43QM10 Google TV User Manual - Features and Settings</p> <p>User manual for the CHI Q U43QM10 Google TV, detailing remote control functions, app access, recording features, picture settings like 120Hz DLG mode, and sound options.</p>
	<p>CHI Q L40M10 User Manual</p> <p>User manual for the CHI Q L40M10 television, providing detailed instructions on setup, operation, safety precautions, troubleshooting, and features like Google Assistant and Chromecast Built-in.</p>
	<p>CHI Q L32M10 User Manual: Setup, Operation, and Troubleshooting</p> <p>Comprehensive user manual for the CHI Q L32M10 TV, covering initial setup, connecting devices, smart TV features, troubleshooting, and safety instructions.</p>