

[Manuals.plus](#) /

› [Mxnsewr](#) /

› Mxnsewr Vacuum Steamer for Clothes, Model Y518 - Instruction Manual

Mxnsewr Y518

Mxnsewr Vacuum Steamer for Clothes - Instruction Manual

Model: Y518 | Brand: Mxnsewr

1. INTRODUCTION

Thank you for choosing the Mxnsewr Vacuum Steamer for Clothes. This device is designed to provide efficient and convenient garment care, combining powerful steam with vacuum suction technology to remove wrinkles and refresh fabrics. Please read this manual thoroughly before use to ensure safe and optimal operation.



Image 1.1: Mxnsewr Vacuum Steamer for Clothes, highlighting its sleek design.

2. SAFETY INFORMATION

To avoid electric shock, fire, or accidental injuries, please carefully read and follow these safety guidelines:

- Always unplug the device before filling or emptying the water tank, or performing any maintenance.
- Do not immerse the product in water or other liquids. If the product falls into water, immediately unplug it and allow it to dry completely before using again.
- Use only distilled or purified water to prevent mineral buildup and extend product life.
- Keep the steam outlet away from heat sources and areas that could compromise its protective insulation.
- Do not touch the steam outlet or any hot surfaces during use or immediately after shutdown to avoid burns.
- This product is not intended for use by individuals with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the product by a person responsible for their safety.

- Do not allow children to operate or play with this product.
- Use this product only with the specified rated power supply (110-120V).

3. PACKAGE CONTENTS

Verify that all items are included in your package:

- Mxnsewr Vacuum Steamer (Model Y518)
- Removable Water Tank (400ml capacity)
- Measuring Cup
- Over-the-door Hooks (x4)
- Replacement Filter Sponges (x2)
- Storage Bag



Easy to operate with one hand

automatically pick up clothes without tugging. Hard-to-handle areas such as collars, sleeves, and pant legs can also be easily managed, making it very convenient.

Image 3.1: All included accessories for the Mxnsewr Vacuum Steamer.

4. SETUP

1. **Fill Water Tank:** Detach the 400ml water tank from the main unit by pressing the release button. Open the rubber stopper and fill the tank with distilled or purified water using the provided measuring cup. Close the stopper securely and reattach the tank until it clicks into place.



Image 4.1: Detaching and filling the water tank.

2. **Place Steamer:** Ensure the steamer is placed on a stable, heat-resistant surface or hung securely using the provided hooks.
3. **Plug In:** Plug the steamer into a 110-120V power outlet.

5. OPERATING INSTRUCTIONS

1. **Power On:** Long press the power button (usually indicated by a universal power symbol) for 3 seconds. The indicator light will flash red and green, indicating preheating.
2. **Preheating:** The steamer will heat up in approximately 30 seconds. Once ready, the indicator light will turn solid red, and steam will begin to emit.
3. **Select Mode:**
 - **Dry Ironing:** For sharp creases and shaping collars without steam.
 - **Low Steam Mode:** Ideal for delicate fabrics like silk and synthetics.
 - **High Steam Mode:** Suitable for heavier fabrics such as denim and linen.



Image 5.1: Steamer with multiple mode adjustments for different fabric types.

4. **Activate Vacuum Suction (Optional):** Press the vacuum button (often indicated by a fan symbol) once to activate the 3500Pa vacuum suction feature. This pulls the fabric flat against the steamer plate, allowing for hands-free, one-handed operation and more efficient wrinkle removal. Press again to deactivate.



Image 5.2: Demonstrating the 3500Pa vacuum suction mode for single-handed operation.

5. Steaming Techniques:

- **Vertical Steaming:** Hold the garment taut and move the steamer plate slowly from top to bottom. The vacuum feature is particularly useful here.
- **Horizontal Ironing:** Lay the garment flat on a heat-resistant surface and use the steamer like a traditional iron.



Image 5.3: Versatile use for vertical steam pressing and horizontal ironing.

6. **Intelligent Temperature Control:** The advanced aluminum-coated panels and smart thermostat automatically adjust temperature, ensuring safety for all fabric types and preventing water splashing.



Image 5.4: Steamer with intelligent temperature control for safe use.

7. **Pause/Resume:** Short press the power button to pause steaming (green light flashing). Short press again to resume.
8. **Power Off:** Long press the power button to turn off the device. The device will automatically power off after 10 minutes of inactivity.

Official Product Videos

Mxnsewr 3500Pa Vacuum Steamer for Clothes

Your browser does not support the video tag.

Video 5.5: An official video showcasing the Mxnsewr 3500Pa Vacuum Steamer for Clothes, demonstrating its features and ease of use.

Vacuum Suction Portable Garment Steamer

Your browser does not support the video tag.

Video 5.6: This video highlights the portable design and vacuum suction capabilities of the garment steamer.

6. MAINTENANCE

1. **Cleaning the Filter Sponge:** The steam plate contains a filter sponge that collects loose fibers and lint. Depending on usage frequency, it needs to be cleaned every 3 to 6 months. If you notice reduced suction power, open the side slot of the steam plate, remove the filter sponge, rinse it with water, let it dry completely, and then reinstall it. Press the steam plate to ensure it's securely in place.
2. **Descaling:** Regular use of distilled or purified water minimizes mineral buildup. If hard water is used, descaling may be required periodically. Consult the manufacturer's website or support for specific descaling instructions.
3. **Storage:** After use, ensure the steamer is cool and empty the water tank. Store it in the provided storage bag in a cool, dry place.

7. TROUBLESHOOTING

- **No Steam:** Check if the water tank is filled and properly attached. Ensure the device is fully preheated (solid red light).
- **Water Leakage/Splashing:** Ensure the water tank stopper is securely closed and the tank is correctly seated. Use distilled water to prevent mineral buildup that can cause blockages.
- **Reduced Suction Power:** Clean the filter sponge as described in the Maintenance section.
- **Device Not Turning On:** Check if the power cord is securely plugged into a working outlet. Ensure a long press is used for power on.

8. SPECIFICATIONS

Feature	Specification
Brand	Mxnsewr
Model Number	Y518
Suction Power	3500Pa
Wattage	1200 watts
Voltage	120 Volts
Heat Time	30 Seconds
Water Tank Capacity	400ml
Item Weight	2.99 pounds
Package Dimensions	9.61 x 7.05 x 5.94 inches

9. WARRANTY & SUPPORT

For warranty information, technical support, or any product-related inquiries, please refer to the contact information provided with your purchase or visit the Mxnsewr official website. Keep your purchase receipt as proof of purchase.

