

[Manuals.plus](#) /

› [ReIndoo](#) /

› ReIndoo TAB9 12-inch Android 15 Tablet User Manual

ReIndoo TAB9

ReIndoo TAB9 12-inch Android 15 Tablet User Manual

Model: TAB9

INTRODUCTION

Thank you for choosing the ReIndoo TAB9 12-inch Android 15 Tablet. This device is designed to provide a versatile and powerful computing experience, whether for work, entertainment, or communication. This user manual will guide you through the setup, operation, maintenance, and troubleshooting of your new tablet, ensuring you can fully utilize its features.

WHAT'S IN THE BOX

Carefully unpack your ReIndoo TAB9 tablet and check for the following items:

- 1 x ReIndoo TAB9 12-inch Android Tablet
- 1 x Bluetooth Keyboard
- 1 x Wireless Mouse
- 1 x Stylus Pen
- 1 x Foldable Protective Case
- 1 x Screen Protector (pre-applied or separate)
- 1 x Charging Adapter
- 1 x USB-C Charging Cable
- 1 x User Manual (this document)



Image: The RelIndoo TAB9 tablet shown with its complete accessory bundle, including the keyboard, mouse, stylus, and protective case.

PRODUCT OVERVIEW

Familiarize yourself with the physical components and ports of your RelIndoo TAB9 tablet.

Tablet Layout

Store ALL Your Favorite



256 GB
UFS



Max 24GB
8GB+16GB Expansion



Up to 2TB
Micro SD




Image: Front and rear views of the RelIndoo TAB9 tablet, highlighting the camera, speakers, and various ports.

Front Camera: Located at the top center when held vertically, used for video calls and selfies.

Rear Camera: Located on the back, used for high-resolution photos and videos.

Power Button: Typically on the side, press and hold to power on/off or restart. Short press to sleep/wake.

Volume Buttons: Adjust the audio volume.

USB-C Port: For charging the tablet and connecting to a computer for data transfer.

3.5mm Headphone Jack: For connecting wired headphones or external speakers.

MicroSD Card Slot: Expand storage capacity up to 2TB.

Speakers: Dual stereo speakers for enhanced audio output.

SETUP GUIDE

1. Initial Charging

Before first use, fully charge your tablet. Connect the USB-C charging cable to the tablet's USB-C port and the charging

adapter to a power outlet. The battery indicator on the screen will show charging progress.

2. Powering On/Off

To power on, press and hold the Power button until the screen lights up. To power off, press and hold the Power button, then select "Power off" from the options. A short press of the Power button will put the tablet to sleep or wake it up.

3. Wi-Fi Connection

1. Go to **Settings > Network & internet > Wi-Fi**.
2. Toggle Wi-Fi **On**.
3. Select your desired Wi-Fi network from the list.
4. Enter the password if prompted and tap **Connect**.

4. Google Account Setup

During initial setup or later via Settings, sign in with your Google account. This is essential for accessing the Google Play Store, Gmail, Google Drive, and other Google services.

5. Inserting a MicroSD Card

Locate the MicroSD card slot on the side of the tablet. Gently insert a compatible MicroSD card (up to 2TB, FAT32 format) into the slot until it clicks into place. The tablet will recognize the new storage.

6. Connecting Accessories (Keyboard, Mouse, Stylus)

The included keyboard and mouse connect via Bluetooth. The stylus may also connect via Bluetooth or be passive.

Bluetooth Keyboard & Mouse:

1. Ensure the keyboard/mouse are charged and in pairing mode (refer to their individual manuals if needed).
2. On your tablet, go to **Settings > Connected devices > Pair new device**.
3. Select the keyboard or mouse from the list of available devices and follow on-screen prompts to complete pairing.

Stylus Pen:


The stylus pen is typically ready for use upon removal from its holder or may require a simple Bluetooth pairing as described above if it's an active stylus.

New Android 15 OS

Smarter, Secure, and Multitasking-ready




More Secure Private Space




Smarter Screen Recording




Faster Multitasking with App Pairs



Better Taskbar Customization



Flexible Split-Screen Workspaces



Eye-Comfort Color Temperature Control



Instant Three-Finger Command Triggers

Image: The RelIndoo TAB9 tablet configured in laptop mode with the Bluetooth keyboard and wireless mouse.

OPERATING INSTRUCTIONS

1. Android 15 Interface

Your tablet runs on Android 15, offering an intuitive and secure user experience. Navigate using touch gestures: swipe, tap, pinch, and spread. The home screen can be customized with widgets and app shortcuts.

Widevine L1 & High Definition Screen



Image: Overview of key features in the Android 15 operating system, such as enhanced privacy, multitasking, and customization options.

2. Multitasking with Split-Screen

To use split-screen mode for efficient multitasking:

1. Open an app.
2. Swipe up from the bottom of the screen and hold to view recent apps.
3. Tap the app icon at the top of the app's card and select **Split screen**.
4. Choose a second app from your recent apps or app drawer to open alongside the first.

3. Camera Operation

The tablet features an 8MP front camera and a 16MP rear camera.

1. Open the **Camera** app.
2. Tap the shutter button to take a photo.
3. Switch between front and rear cameras using the camera flip icon.
4. Select video mode to record videos.

Seamlessly Connected To The World

Built-in **2.4G+5G dual-band WiFi**, with high-speed **5G WiFi** reaching up to a peak rate of **433Mbps**, providing you with a smoother online surfing experience; Low-power **Bluetooth 5.2** enables convenient connections for more wireless devices with lower latency.



AC dual-band WiFi



BT5.2 Bluetooth



433Mbps Peak rate




Image: Details of the tablet's dual cameras, highlighting the 16MP rear and 8MP front cameras, along with Google Lens integration.

4. Display Settings and Eye Protection

Adjust display settings for optimal viewing comfort:

1. Go to **Settings > Display**.
2. Adjust **Brightness level**.
3. Enable **Night Light** or **Reading Mode** to reduce blue light for eye comfort.
4. Activate **Dark Mode** for a darker interface.




Image: The tablet's display features, including Widevine L1 certification for HD streaming and various eye-protection modes.

5. Audio and Entertainment

The tablet features dual stereo speakers for an immersive audio experience. Connect headphones via the 3.5mm jack for private listening.

With Widevine L1 certification, you can stream 1080P HD content from platforms like Netflix, YouTube, HBO, and Amazon Prime Video.

6. GPS Navigation

The built-in GPS provides precise location services. Use navigation apps for travel and outdoor activities.

7. Face Unlock

Set up Face Unlock for convenient and secure access to your tablet:

1. Go to **Settings > Security & privacy > Face unlock**.
2. Follow the on-screen instructions to register your face.

8. Gemini AI Integration

The tablet integrates Gemini AI for enhanced functionality, including content creation, information retrieval, image analysis, code development, language learning, and intelligent assistance.




Image: An overview of the Gemini AI features integrated into the tablet, enhancing productivity and user interaction.

9. Parental Controls

Utilize built-in parental controls to create a safe browsing and usage environment for children. Access these settings via **Settings > Digital Wellbeing & parental controls**.

MAINTENANCE

1. Cleaning the Tablet

Use a soft, lint-free cloth to clean the screen and body of the tablet. For stubborn smudges, slightly dampen the cloth with water or a screen cleaner designed for electronics. Avoid harsh chemicals or abrasive materials.

2. Software Updates

Regularly check for and install system updates to ensure optimal performance, security, and access to new features. Go to **Settings > System > System update**.

3. Storage Management

To maintain performance, periodically review and manage your tablet's storage. Delete unnecessary files, uninstall unused apps, and move large media files to the expandable MicroSD card or cloud storage. Go to **Settings > Storage**.

4. Battery Care

To prolong battery life:

- Avoid extreme temperatures.
- Do not let the battery fully discharge frequently.
- Use the provided charging adapter and cable.
- Enable battery saver mode when needed.

True-to-Life Display & Widevine L1 Support

With Widevine L1 support, the tablet let you immerse yourself in a wide range of entertainment content, including movies, TV shows, sports events, and more.

hulu

You Tube

prime video

NETFLIX



Image: Details on the tablet's 8000mAh battery and 18W fast charging capabilities, including estimated usage durations.

TROUBLESHOOTING

If you encounter issues with your ReIndoo TAB9 tablet, refer to the following common solutions:

Tablet Not Powering On

- Ensure the tablet is sufficiently charged. Connect it to the charger for at least 30 minutes.
- Press and hold the Power button for 10-15 seconds to force a restart.

Wi-Fi Connectivity Issues

- Toggle Wi-Fi off and on in Settings.
- Restart your Wi-Fi router.
- Forget the network and reconnect, entering the password again.
- Ensure the tablet is within range of the Wi-Fi signal.

Slow Performance or Freezing

- Close unused apps running in the background.
- Clear cache for frequently used apps (**Settings** > **Apps** > select app > **Storage & cache** > **Clear cache**).
- Restart the tablet.
- Check for system updates.
- Ensure sufficient storage space is available.

Battery Drains Quickly

- Reduce screen brightness.
- Disable Wi-Fi, Bluetooth, and GPS when not in use.
- Close power-intensive apps.
- Check battery usage in **Settings** > **Battery** to identify apps consuming the most power.
- Enable Battery Saver mode.

Accessories Not Connecting

- Ensure Bluetooth is enabled on the tablet.
- Put the accessory (keyboard, mouse) into pairing mode.
- Ensure accessories are charged.
- Remove previously paired accessories from the tablet's Bluetooth settings and try pairing again.

If problems persist, contact customer support for further assistance.

SPECIFICATIONS

Below are the detailed technical specifications for the ReIndoo TAB9 12-inch Android 15 Tablet:

Feature	Detail
Model Name	TAB9
Operating System	Android 15 (GMS Certified)
Processor	Unisoc T615 Octa-Core (ARM Cortex-A75)
RAM Memory	24GB (8GB physical + 16GB extended)
Internal Storage	256GB
Expandable Storage	Up to 2TB via MicroSD (FAT32 format)
Screen Size	12 Inches
Display Resolution	1200*2000 Pixels (2K Display)
Wireless Connectivity	5G Wi-Fi (2.4G/5G AC), Bluetooth 5.0
Cellular Technology	5G (Refers to 5G Wi-Fi, not cellular data)
GPS	Built-in GPS/Beidou/Glonass
Front Camera	8MP
Rear Camera	16MP
Battery Capacity	8000mAh Lithium Polymer
Charging	USB-C, 18W Fast Charging
Audio	Dual Stereo Speakers, 3.5mm Headphone Jack
Special Features	Widevine L1, Face Unlock, Gemini AI, Parental Controls
Dimensions (L x W x Thickness)	17.5"L x 6"W x 16.2"Th (Note: These dimensions may refer to packaging or an error in listing. Please refer to the product page for precise tablet dimensions.)

Color	Pink (Tablet itself is blue, case is pink)
-------	--

WARRANTY AND SUPPORT

Warranty Information

The ReIndoo TAB9 tablet comes with a limited warranty. For specific details regarding the warranty period and coverage, please refer to the warranty card included in your product packaging or visit the official ReIndoo website.

Customer Support

If you require technical assistance, have questions about your product, or need to report an issue, please contact ReIndoo customer support through their official website or the contact information provided in your product documentation.

© 2025 ReIndoo. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FQV895RD>

More documents and user manuals: <https://manuals.plus/>