

Dreamegg D47-GREY-US

Dreamegg Vibe 1 White Noise Sound Machine User Manual

Brand: Dreamegg | Model: D47-GREY-US

1. INTRODUCTION

The Dreamegg Vibe 1 White Noise Sound Machine is designed to create a peaceful and calming environment, promoting faster and deeper sleep for adults and babies. Its advanced sound technology effectively masks disruptive noises such as snoring, traffic, and office chatter, ensuring a more restorative rest. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to help you maximize your device's potential.

2. PRODUCT FEATURES

- **Faster, Deeper Sleep:** Advanced sound machine technology reduces noise interruptions by up to 90%, blocking sudden disruptions for improved sleep quality.
- **29 Soothing Sounds:** Offers a wide selection of premium audio options, including 7 white noises, 7 fan sounds, 8 nature tracks, 5 lullabies, and 2 meditation tones for relaxation, focus, or calming.
- **Professional Noise Shield:** Engineered with a robust 10W driver and studio-grade acoustic design for rich, room-filling, non-looping sound with deep bass, effectively masking unwanted noise.
- **Auto Timer & Volume Control:** Features continuous play or auto-off timer settings (1, 2, or 8 hours). Memory function retains last settings. Wide 46–87 dB volume range for fine-tuning.
- **Bluetooth Pairing:** Instantly pair your smartphone to use the Vibe 1 as a high-quality wireless speaker for streaming music, podcasts, or audiobooks.

3. PACKAGE CONTENTS

- Dreamegg Vibe 1 White Noise Sound Machine

- USB Type-C Power Cable
- User Manual

4. SETUP INSTRUCTIONS

1. **Power Connection:** Plug in the device using the provided USB Type-C cable.
2. **Placement:** For optimal results, place the sound machine 3-6 feet from your head, positioned between you and the primary noise source.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

- Press the power button () to turn the machine on or off.

5.2 Volume Control

- Use the volume up (+) and volume down (-) buttons to adjust the sound level. The device offers a wide range from 46–87 dB.

5.3 Sound Selection

- Press the sound category buttons (e.g., music note for lullabies, fan icon for fan sounds, waveform for white noise) to cycle through the 29 available sounds.

5.4 Timer Function

- Press the timer button (⏰) to set the auto-off timer for 1, 2, or 8 hours. The device will automatically turn off after the selected duration.
- To disable the timer and allow continuous play, cycle through the timer options until no timer indicator light is active.

5.5 Night Light Function

- Press the light button (💡) to turn the night light on or off.
- Some models may offer a gentle fade-in/fade-out light option.

5.6 Bluetooth Pairing (Wireless Speaker Mode)

- To use the device as a wireless speaker, activate Bluetooth on your smartphone or other audio device.
- Select