

Sundu DF-288

Sundu 1600W Steam Station Iron Steamer DF-288 User Manual

Model: DF-288

IMPORTANT SAFETY INSTRUCTIONS

When using your steam iron, basic safety precautions should always be followed, including the following:

- Read all instructions before use.
- Use the iron only for its intended purpose.
- To protect against risk of electric shock, do not immerse the iron in water or other liquids.
- Always turn the iron OFF before plugging or unplugging from the electrical outlet.
- Never yank cord to disconnect from outlet; instead, grasp plug and pull to disconnect.
- Do not allow cord to touch hot surfaces. Let iron cool completely before putting away. Loop cord loosely around iron when storing.
- Always disconnect iron from electrical outlet when filling with water or emptying, and when not in use.
- Do not operate iron with a damaged cord or if the iron has been dropped or damaged. To avoid risk of electric shock, do not disassemble the iron. Contact qualified service personnel for examination and repair. Incorrect reassembly can cause a risk of electric shock when the iron is used.
- Close supervision is necessary for any appliance being used by or near children. Do not leave iron unattended while connected or on an ironing board.
- Burns can occur from touching hot metal parts, hot water, or steam. Use caution when you turn a steam iron upside down – there may be hot water in the reservoir.
- The iron must be used and rested on a stable surface.
- When placing the iron on its stand, ensure that the surface on which the stand is placed is stable.

PRODUCT OVERVIEW

The Sundu 1600W Steam Station Iron Steamer (Model DF-288) is designed for efficient and professional garment care. It features a powerful 1600W heating element, a 44 oz (1.3L) removable water tank, a ceramic soleplate with over 400 microsteam holes, and continuous steam output of 40g/min.



Image: The Sundu Steam Station Iron Steamer, showing the iron unit separated from its water tank base.

Key Features:

- **1600W Power:** Rapid heat-up and consistent high heat for effective wrinkle removal.
- **40g/min Continuous Steam:** High-pressure steam penetrates deep into fibers.
- **44 oz (1.3L) Removable Water Tank:** Large capacity for extended ironing sessions, easy to refill.
- **Ceramic Soleplate:** Smooth gliding, scratch-resistant, with over 400 steam holes for even steam distribution.
- **Versatile Fabric Care:** Precision temperature dial suitable for synthetics, silk, wool, cotton, and linen.
- **Iron Lock:** For safe carrying and storage.
- **Anti-Calc System:** Prevents scaling and ensures long-lasting performance.
- **Anti-Drip Technology:** Prevents water leakage and stains on garments.

SETUP

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Placement:** Place the steam station on a stable, heat-resistant surface, such as an ironing board or heat-resistant mat. Ensure adequate space around the unit.

3. Filling the Water Tank:

- Remove the 44 oz (1.3L) transparent water tank from the base unit.
- Fill the tank with clean tap water. Distilled or demineralized water is recommended to prolong the life of the appliance and prevent mineral buildup, especially in hard water areas. Do not use perfumed water, vinegar, or other chemical additives.
- Replace the water tank securely into the base unit.



44 oz Removable Water Tank

Continuous Ironing, Easy to Refill



Image: A person pouring water into the removable water tank of the steam station.

4. **Connecting Power:** Plug the power cord into a grounded electrical outlet. Ensure the voltage matches the specifications of the appliance.

OPERATING INSTRUCTIONS

1. Power On and Heat Up:

- Once plugged in, the iron will begin to heat up. The indicator light will illuminate.
- Allow approximately 25 seconds for the iron to reach the desired temperature. The indicator light will turn off when heating is complete.

2. Select Temperature:

Adjust the precision temperature dial on the iron to the appropriate setting for your fabric type. Refer to the fabric guide below:

- Synthetics/Silk/Polyester: 230-284°F (110-140°C)
- Wool: 284-356°F (140-180°C)
- Cotton/Linen: 356-410°F (180-210°C)

Suitable for All Kinds of Fabrics



Image: The iron's temperature dial with recommended settings for various fabric types.

3. Steam Ironing:

- Press the steam button on the iron handle to activate continuous steam.
- Glide the iron over the fabric. The 40g/min continuous steam will help remove wrinkles effectively.
- For stubborn wrinkles, you may hold the steam button for a short burst of extra steam.

40g/min Continuous Steam

High pressure continuous steam wrinkle removal



1600W
Continuous Steam

Image: An illustration showing the iron emitting continuous steam from its soleplate.

4. **Dry Ironing:** If dry ironing is preferred, do not press the steam button. The iron will function as a standard dry iron.
5. **Vertical Steaming:** The iron can also be used for vertical steaming of hanging garments. Hold the iron vertically and press the steam button.
6. **Iron Lock:** When finished or for transport, use the Iron Lock feature to secure the iron to its base. This prevents accidental detachment and makes carrying safer.

Safety & Convenience



Image: A person carrying the Sundu Steam Station Iron Steamer by the iron's handle, demonstrating the iron lock feature.

7. **Power Off:** After use, turn the temperature dial to the minimum setting, unplug the iron from the electrical outlet, and allow it to cool completely before storing.

MAINTENANCE

Cleaning the Soleplate:

- Ensure the iron is unplugged and completely cool before cleaning.
- Wipe the ceramic soleplate with a damp cloth and a non-abrasive cleaner if necessary. Do not use harsh scouring pads or metallic cleaners, as these can damage the soleplate.
- For starch residue, wipe with a cloth dampened with a mild vinegar solution, then wipe with a clean damp cloth.

Draining the Water Tank:

- After each use, or before storing, ensure the iron is unplugged and cool.
- Remove the water tank and empty any remaining water.
- Allow the tank to air dry before replacing it.

Anti-Calc System (Self-Cleaning):

The Sundu Steam Station features a built-in anti-calc system to prevent mineral buildup. Regular use of distilled water will further minimize scale. For specific self-cleaning instructions, refer to the detailed guide in the included printed manual, as procedures can vary.

Professional

Ironing, Automatic Filtration



No dripping



Calcium
collection system

Image: An internal diagram illustrating the calcium collection system and anti-drip mechanism.

Storage:

- Ensure the iron is completely cool and empty of water.
- Lock the iron onto its base using the Iron Lock feature.
- Store the appliance in a dry, safe place, away from children. The built-in cable storage helps keep the cord tidy.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Iron does not heat up.	Not plugged in; power outlet malfunction; temperature dial set to OFF/minimum.	Check power connection; test outlet with another appliance; turn temperature dial to desired setting.
No steam or insufficient steam.	Water tank empty; temperature too low for steam; steam button not pressed; mineral buildup.	Fill water tank; set temperature to steam-appropriate level (e.g., Cotton/Linen); press steam button; perform anti-calc cleaning.
Water leaks from soleplate.	Temperature too low for steam (water not fully vaporized); water tank overfilled; anti-drip system malfunction.	Increase temperature setting; do not overfill water tank; if problem persists, contact support.
Brown stains on fabric.	Mineral deposits in water; starch residue on soleplate.	Use distilled water; clean soleplate as per maintenance instructions.

SPECIFICATIONS

- **Model:** DF-288
- **Brand:** Sundu
- **Power:** 1600W
- **Water Tank Capacity:** 44 oz (1.3 Liters)
- **Steam Output:** 40g/min (Continuous)
- **Soleplate Material:** Ceramic
- **Steam Holes:** Over 400 microsteam holes
- **Product Dimensions:** 12"L x 7"W (approximate, based on product info)
- **Item Weight:** 7.11 pounds
- **Special Features:** Extra large steam, Built-In Pump, Iron Lock, Anti-Calc System, Anti-Drip Technology

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your product or visit the official Sundu website. Keep your purchase receipt as proof of purchase for any warranty claims. You can also visit the [Sundu Store on Amazon](#) for additional product information and support resources.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question