Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MOVHEIYL YS-TL23064

MOVHEIYL Remote Control User Manual

For AUSDOM YS-TL23064 and APMIEK H108201-APUS-BLACK LED Desk Lamps

Introduction

Thank you for choosing the MOVHEIYL replacement remote control. This manual provides essential information for the proper setup, operation, and maintenance of your new remote. This remote is designed for seamless compatibility with the AUSDOM YS-TL23064 and APMIEK H108201-APUS-BLACK LED desk lamps, offering convenient control over your lighting experience.

Setup

Battery Installation

The remote control requires two 1.5V AAA batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open the compartment.
3. Insert two AAA batteries, ensuring that the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



The remote control requires two 1.5V AAA batteries. Open the battery compartment cover on the back of the remote and insert the batteries, ensuring correct polarity (+/-) as indicated inside the compartment. Close the cover securely.

Initial Use

This remote control is designed for immediate use with compatible lamps. No programming or pairing is required. Simply install the batteries, and it is ready to operate your LED desk lamp.


Operating Instructions

Basic Functions

The remote control provides intuitive buttons for various lamp functions:

- **Power Button ( ):** Press to turn the lamp on or off.
- **Brightness Adjustment (☀+ / ☀-):** Increase or decrease the lamp's brightness level.

- **Color Temperature Adjustment (❄+ / ❄-):** Adjust the color temperature from warm to cool light.
- **Night Mode (☾):** Activates a low-light setting suitable for nighttime use.
- **Reading Mode ( ):** Sets the lamp to an optimal brightness and color temperature for reading.
- **Coffee Mode (☕):** Provides a warm, ambient light setting.
- **Computer Mode ( ):** Adjusts light to reduce eye strain during computer use.
- **Gaming Mode ( ):** Offers a dynamic lighting setting for gaming environments.



The remote control features various buttons for controlling your LED desk lamp. These include power on/off, brightness increase/decrease, color temperature adjustment, and preset mode selections (e.g., night mode, reading mode, coffee mode, computer mode, gaming mode). Press the corresponding button to activate the desired function.

Operating Range

The remote control communicates with the lamp using infrared technology. For optimal performance, ensure a clear line of sight between the remote and the lamp's receiver. The typical operating range is up to 8 meters, though specifications indicate a maximum range of 10 meters under ideal conditions.



The remote control operates effectively within an 8-meter range from the LED desk lamp. Ensure a clear line of sight between the remote and the lamp's receiver for optimal performance.

Maintenance

To ensure the longevity and proper functioning of your remote control, follow these maintenance guidelines:

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Avoid using abrasive cleaners, solvents, or harsh chemicals, as these can damage the surface and internal components.
- **Battery Replacement:** If the remote's performance degrades (e.g., reduced range, unresponsive buttons), replace both AAA batteries with new ones. Do not mix old and new batteries or different types of batteries.
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, remove the batteries to prevent leakage.
- **Material Quality:** The remote is constructed from high-quality ABS material with soft silicone buttons, designed for durability and a comfortable feel.



The remote control is made from high-quality ABS material with soft silicone buttons for durability and comfortable use.

Troubleshooting

If you encounter issues with your remote control, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Remote control is unresponsive.	Dead or incorrectly installed batteries.	Check battery polarity and replace with fresh AAA batteries.
Remote control has limited range or intermittent response.	Weak batteries; Obstruction between remote and lamp.	Replace batteries. Ensure a clear line of sight to the lamp's receiver.
Specific buttons do not work.	Button malfunction; Compatibility issue.	Ensure the remote is compatible with your specific lamp model. If the issue persists, contact customer support.

Specifications

Feature	Detail
Brand	MOVHEIYL
Model Compatibility	AUSDOM YS-TL23064, APMIEK H108201-APUS-BLACK LED Desk Lamps
Dimensions (L x W x H)	17.27 x 5.59 x 2.79 cm
Weight	63.5 g
Connectivity Technology	Infrared (IR)
Maximum Operating Range	10 Meters
Power Source	2 x 1.5V AAA Batteries (not included)
Material	High-quality ABS with soft silicone buttons
Special Feature	Ergonomic design

Warranty and Support

MOVHEIYL is committed to providing high-quality products and customer satisfaction. If you have any questions, concerns, or require assistance with your remote control, please do not hesitate to contact us. We are dedicated to helping you resolve any issues and ensure a positive experience with our product.
Please refer to your purchase documentation or the retailer's website for specific warranty details and contact information.

© 2024 MOVHEIYL. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FQZNDFVW

More documents and user manuals: **https://manuals.plus/**