

[Manuals.plus](#) /

› [Pursonic](#) /

› Pursonic Portable Juicer & Blender Cup JB3 Instruction Manual

Pursonic JB3

Pursonic Portable Juicer & Blender Cup JB3 Instruction Manual

1. INTRODUCTION

Thank you for choosing the Pursonic Portable Juicer & Blender Cup JB3. This compact and powerful personal blender is designed for convenience, allowing you to prepare fresh smoothies, shakes, and juices anywhere. Please read this manual carefully before use to ensure safe and optimal operation.



Image: The Pursonic Portable Juicer and Blender Cup, ready for use on a kitchen counter with fresh fruits.

2. PRODUCT FEATURES

- **Powerful Motor & Blades:** Equipped with a 50W motor and a 12-blade power system, spinning up to 22,000 RPM for smooth blending.
- **USB-C Fast Charging:** Recharges in 3-4 hours, providing up to 12 blends per charge.
- **3 Speeds:** Adjustable speeds to handle various ingredients, from soft fruits to ice.
- **Compact & Travel-Ready:** 15.2 oz capacity, lightweight design ideal for home, office, gym, or travel.
- **Easy to Use & Clean:** Detachable parts for simple and quick cleanup. Doubles as a smoothie cup.



22,000 RPM
High-Speed Motor



Up to 12 Blends
Per Charge



Image: A detailed view of the Pursonic blender's powerful 12-blade system and 22,000 RPM motor, highlighting its blending capabilities with various fruits.

3. WHAT'S IN THE BOX

- Pursonic Portable Juicer & Blender Cup (Juicer Base and Cup)

- USB-C Charging Cable
- Instruction Manual

4. SETUP

4.1 Initial Charge

Before first use, fully charge the blender using the provided USB-C cable. The battery indicator on the base will show charging status.

4.2 Initial Cleaning

Wash all detachable parts (cup, lid) with warm, soapy water. Rinse thoroughly and dry completely before assembly. Do not immerse the motor base in water.

4.3 Assembly

Ensure the cup is securely twisted onto the motor base. A red arrow on the base should align with a red arrow on the cup to indicate proper locking. The blender will not operate if not correctly assembled.

5. OPERATING INSTRUCTIONS

5.1 Adding Ingredients

1. Chop fruits and vegetables into small pieces (approximately 1 inch or smaller).
2. Add ingredients to the cup. For optimal blending, fill ingredients up to the first marked line on the cup.
3. Pour liquid (water, milk, juice, etc.) into the cup, filling up to the second marked line. Ensure total ingredients do not exceed the MAX fill line.

5.2 Blending

1. Securely attach the lid to the cup and the cup to the motor base.
2. Press the power button to turn on the blender. The display will show the current battery level.
3. Press the 'M' button to cycle through the 3 blending modes (P1, P2, P3).
4. For best results, especially with harder ingredients or ice, gently tilt the blender at a 45-degree angle during operation to ensure ingredients come into contact with the blades.
5. The blender will automatically stop after the selected cycle duration. You can also press the power button to stop it manually.

BLEND IN 1-2-3

Your favorite drinks in just a few easy steps—no cords, no hassle.



1. Fill & Secure: Add ingredients, lock the lid, and get ready to blend.



2. Blend: Choose your speed and let the powerful blades do the work.



3. Sip & Enjoy: Pour into a glass or drink straight from the cup, then rinse for easy cleanup.

Image: A visual guide demonstrating the three simple steps to use the Pursonic blender: filling and securing ingredients, blending, and then sipping or pouring.

6. CLEANING AND MAINTENANCE

Proper cleaning and maintenance ensure the longevity of your Pursonic blender.

- Always clean the blender immediately after each use.
- Unscrew the cup from the motor base.
- The cup and lid are dishwasher safe. For manual cleaning, wash with warm, soapy water and a soft brush.
- Wipe the motor base with a damp cloth. Do not submerge the motor base in water or rinse it under running water.
- Ensure all parts are completely dry before reassembling or storing.

CHARGE. BLEND. REPEAT.

Powerful performance, sleek design.



50W Motor Power

Smooth, consistent blending in seconds

12-Blade System

Spins up to 22,000 RPM for silky results

USB-C Fast Charging

Ready in 3-4 hours, blends up to 12 times per charge

15.2 oz Capacity

Perfect for smoothies, shakes, and baby food

Image: A graphic illustrating key benefits including easy cleaning with detachable parts, sleek design, ultra-portability, and safe, secure operation.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Blender does not turn on	Low battery; Cup not securely attached; Overload protection activated	Charge the blender; Ensure cup is twisted on correctly (arrows aligned); Reduce ingredients and restart.
Ingredients not blending smoothly	Too many ingredients; Not enough liquid; Ingredients too large; Hard ingredients (ice) without tilting	Reduce ingredient quantity; Add more liquid; Chop ingredients smaller; Tilt blender during operation.
Leakage from cup	Lid not properly sealed; Cup not securely attached to base	Ensure lid is tightly screwed on; Reattach cup to base, aligning arrows.

8. SPECIFICATIONS

- **Brand:** Pursonic
- **Model:** JB3
- **Capacity:** 15.2 Fluid Ounces (450ml)
- **Maximum Power:** 50 Watts
- **Number of Speeds:** 3
- **Power Source:** Battery Powered (USB-C Rechargeable)
- **Material:** Plastic, Stainless Steel (blades)

- **Special Feature:** Dishwasher Safe Parts (cup and lid)
- **UPC:** 810144931654

9. SAFETY INFORMATION

- Keep out of reach of children.
- Do not operate the blender when empty.
- Avoid contact with moving parts.
- Ensure the lid is securely fastened before operating.
- Do not attempt to blend hot liquids.
- Only use the provided USB-C cable for charging.
- Do not disassemble the motor base.

10. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the product packaging or contact Pursonic customer service directly. Keep your purchase receipt as proof of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

