Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LUXOAK CNS183

LUXOAK CNS183 47-inch Makeup Vanity Desk User Manual

Model: CNS183 | Brand: LUXOAK

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your LUXOAK CNS183 47-inch Makeup Vanity Desk. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Image: The LUXOAK CNS183 47-inch Makeup Vanity Desk, showcasing its mirror, LED lights, and multiple drawers.

Important Safety Information

- Always assemble with two people to avoid injury.
- Be cautious of sharp edges during assembly and usage.
- Do not exceed the weight limit of the vanity.
- Keep electrical components dry and away from water.
- Do not leave the vanity unattended while in use.

Package Contents

Before assembly, ensure all parts are present and undamaged. Refer to the included parts list for specific quantities and identification. The package typically includes:

- Various engineered wood panels for the desk frame, drawers, and mirror unit.

- Hardware kit (screws, dowels, cam locks, drawer slides, handles).
- Mirror with integrated LED lights.
- Tempered glass top panels.
- Charging station (USB, Type-C, AC outlets).
- Hair dryer holder.
- Wall anti-tipping kit.

DIMENSIONS

Overall: 47.2"W*15.7"D*53.7"H
Packaging Dimensions & Weight: 52"*20"*11", 111.7 lbs



2 AC outlets, 1 USB, & 1 Type-C port with 59" cable



Image: Detailed dimensions of the vanity desk and its components, including drawer sizes and overall measurements.

Assembly Instructions

For a visual guide to assembly, please refer to the official assembly video below. Follow the steps carefully to ensure proper construction.

Your browser does not support the video tag.

Video: Official assembly instructions for the LUXOAK Vanity Desk, demonstrating each step of the construction process.

1. **Prepare Drawer Slides:** Attach the L-CR (right cabinet member) drawer slides to panel 4 and L-CL (left cabinet member) slides to panel 2 using screws (D).
2. **Install Cam Bolts:** Insert cam bolts (B) into the designated holes on panels 4 and 2.
3. **Prepare Additional Drawer Slides:** Attach L-CL drawer slides to panel 11 using screws (D).
4. **Prepare Remaining Drawer Slides:** Attach L-CR drawer slides to panel 3 using screws (D).
5. **Install Cam Bolts for Panels 11 and 3:** Insert cam bolts (B) into the designated holes on panels 11 and 3.
6. **Assemble Side Supports:** Attach panels 7 and 10 to panel 8 using cam bolts (B) and wooden dowels (C), then secure with cam locks (A).
7. **Assemble Left Side Cabinet:** Connect panels 3, 6, 7, 8, and 9 using cam locks (A).
8. **Assemble Right Side Cabinet:** Connect panels 2, 6, 8, 9, and 10 using cam locks (A).
9. **Connect Side Cabinets to Center:** Use wooden dowels (C) to connect panels 27, 28, and 29 to the side cabinets. Secure with screws (F).
10. **Prepare Top Panels:** Insert cam bolts (B) and wooden dowels (C) into panels 26 and 31. Secure panels 31 with cam locks (A) and cover caps (N).
11. **Assemble Left Top Panel:** Insert wooden dowels (C) into panel 24. Connect panel 24 to panel 26 using cam locks (A) and cover caps (N).
12. **Prepare Right Top Panel:** Insert cam bolts (B) and wooden dowels (C) into panels 30 and 32. Connect panels 32 to panel 30 using cam locks (A) and cover caps (N).
13. **Assemble Right Top Panel:** Insert wooden dowels (C) into panel 25. Connect panel 25 to panel 30 using cam locks (A) and cover caps (N).
14. **Install Back Panels and Shelves:** Attach the back panels (30, 12, 26) to the mirror unit using fasteners (I) and screws (E). Insert the small shelves.
15. **Assemble Mirror Unit Base:** Insert wooden dowels (C) into the base of the mirror unit. Attach the frame (1) using screws (F) and cam bolts (B).
16. **Attach Mirror Unit to Base:** Carefully align the mirror unit with the assembled base. Connect them using wooden dowels (C) and secure with cam locks (A) and cover caps (N).
17. **Install Wall Anti-Tipping Kit:** Attach the anti-tipping bracket (Q) to the top rear of the vanity using screws. Mark and drill holes in the wall, insert wall anchors, and secure the other bracket to the wall. Connect the vanity to the wall using the strap.
18. **Install Hair Dryer Holder and Charging Station:** Attach the hair dryer holder (K) using screws (H). Install the charging station (M) into the pre-drilled hole and secure with screws (E).
19. **Assemble Drawers (Repeat for 6 drawers):** Connect panels 13, 14, and 16 using screws (F). Attach the handle (J) to panel 15 using screws (D). Insert cam bolts (B) into panel 15. Connect panel 15 to the drawer box. Secure with cam locks (A).
20. **Assemble Large Drawer (Repeat for 1 drawer):** Connect panels 18, 19, and 21 using screws (F). Insert cam bolts (B) into panel 20. Attach the handle (J) to panel 20 using screws (D). Connect panel 20 to the drawer box. Secure with cam locks (A).
21. **Install Drawer Slides on Drawers:** Attach the L-DL (left drawer member) and L-DR (right drawer member) slides to the assembled drawer boxes using screws (D).
22. **Install LED Lights:** Attach the LED light bulbs (P) around the mirror frame.
23. **Connect LED Wiring:** Connect the LED light wires to the main power cable, ensuring all connections are secure.
24. **Place Tempered Glass Top:** Carefully place the tempered glass panel (33) into the designated recess on the vanity top.

25. **Insert Drawers:** Slide all assembled drawers into their respective slots in the vanity frame.

Operating Instructions

LED Lights

The vanity mirror features integrated LED lights with adjustable settings:

- **Power On/Off:** Use the inline control button to turn the lights on or off.
- **3 Lighting Modes:** Cycle through Cool White (3000K), Natural Light (4500K), and Warm Light (9000K) by pressing the mode button.
- **Stepless Dimming:** Press and hold the dimming buttons to adjust the brightness to your preference.



Image: A user demonstrating the three light modes (Cool, Natural, Warm) and adjustable brightness feature of the LED mirror lights.

Charging Station

The built-in charging station provides convenient power access for your devices:

- **AC Outlets:** Two standard AC outlets are available for powering hair dryers, curling irons, or other small appliances.
- **USB Port:** One USB port is provided for charging smartphones and other USB-powered devices.
- **Type-C Port:** One Type-C port offers fast charging for compatible devices.
- Ensure the vanity is plugged into a wall outlet for the charging station to function.



Image: Close-up of the integrated charging hub, showing 2 AC outlets, 1 USB port, and 1 Type-C port.

Hair Dryer Holder

The vanity includes a dedicated holder to keep your hair dryer easily accessible and organized.

Keep Your Hair Dryer Within Easy Reach



Image: A hair dryer conveniently placed in its designated holder on the side of the vanity.

Your browser does not support the video tag.

Video: A brief overview highlighting the fluted design, tempered glass top, and integrated features of the vanity desk.

Maintenance

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish or tempered glass.
- **Tempered Glass Care:** The tempered glass top is durable but can be scratched. Use soft cloths for cleaning and avoid placing heavy or sharp objects directly on it.
- **Drawer Slides:** Periodically check drawer slides for smooth operation. If needed, apply a small amount of silicone lubricant.
- **Electrical Components:** Ensure all electrical connections remain secure. If any part of the charging station or LED lights appears damaged, discontinue use and contact customer support.



Image: A close-up of the clear tempered glass top, designed for easy cleaning and visibility of stored items.

Troubleshooting

- **LED Lights Not Working:** Check if the power cable is securely plugged into a wall outlet and the vanity. Ensure all LED light connections are firm. Test the inline control button.
- **Charging Station Not Functioning:** Verify the vanity is plugged into a live wall outlet. Check the power cable for any damage. Try a different device to confirm the issue is with the station and not the device.
- **Drawers Sticking/Not Sliding Smoothly:** Ensure drawer slides are correctly installed and aligned. Check for any obstructions within the drawer tracks. A small amount of lubricant can improve movement.
- **Vanity Wobbles:** Confirm all cam locks and screws are tightened securely. Ensure the vanity is placed on a level surface. Use the wall anti-tipping kit for added stability.

Specifications

Feature	Detail

Feature	Detail
Model Number	CNS183
Brand	LUXOAK
Product Dimensions	15.7"D x 47.2"W x 53.7"H
Item Weight	111.7 pounds
Material	Engineered Wood
Frame Material	Engineered Wood
Assembly Required	Yes
Color	White
Mirror Type	Integrated with LED Lights
LED Light Modes	Cool White (3000K), Natural Light (4500K), Warm Light (9000K)
Charging Station	2 AC outlets, 1 USB, 1 Type-C port
Number of Drawers	7
Top Material	Tempered Glass

Warranty and Support

For warranty information or technical support, please contact LUXOAK customer service through the retailer where the product was purchased. Keep your purchase receipt and model number (CNS183) handy for faster service.

© 2025 LUXOAK. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FR1YHPC6

More documents and user manuals: **https://manuals.plus/**