

- [Manuals.plus](#) /
- › [LUXOAK](#) /
 - › LUXOAK 47-inch Fluted Makeup Vanity Desk with Mirror, LED Lights, and Charging Station (Model CNS183) - User Manual

LUXOAK CNS183

**LUXOAK 47-inch Fluted Makeup Vanity Desk with Mirror, LED
Lights, and Charging Station (Model CNS183)**

User Manual

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your LUXOAK 47-inch Fluted Makeup Vanity Desk. Please read all instructions carefully before assembly and use to ensure safe and proper functionality. Keep this manual for future reference.



Figure 1: LUXOAK 47-inch Fluted Makeup Vanity Desk (Model CNS183)

2. SAFETY INFORMATION

- Always assemble the vanity on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not overload drawers or shelves. Distribute weight evenly.
- Keep small parts and hardware away from children to prevent choking hazards.
- Use the provided anti-tip kit to secure the vanity to a wall, especially if children are present. This prevents accidental tipping.
- Do not stand or climb on the vanity.
- Keep electrical components (LED lights, charging station) away from water.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. Refer to the assembly video for a visual guide to all parts and hardware.

Main Components:

- Vanity Desk Panels (various sizes for frame, drawers, shelves)
- Mirror with LED Light Sockets
- Tempered Glass Top
- Charging Station (Power Strip)
- Hair Dryer Holder

Hardware:

- Cam Locks (A)
- Cam Dowels (B)
- Wood Dowels (C)
- Various Screws (D, E, F, G, H)
- Drawer Slide Brackets (I)
- Drawer Handles (J)
- Hair Dryer Holder Ring (K)
- Drawer Slides (L - CL, CR, DL, DR)
- LED Light Bulbs (P)
- Anti-Tip Kit (Q)
- Cam Covers (N)

DIMENSIONS

Overall: 47.2"W*15.7"D*53.7"H

Packaging Dimensions & Weight: 52"*20"*11", 111.7 lbs



2 AC outlets, 1 USB, & 1 Type-C port with 59" cable



Figure 2: Product Dimensions and Charging Station Details

4. ASSEMBLY INSTRUCTIONS

Assembly typically requires two people and approximately one hour. Follow the steps below and refer to the official assembly video for visual guidance.

Assembly Video Guide:

Video 1: Official Assembly Instructions for LUXOAK Vanity Desk. This video provides a step-by-step visual guide for assembling the vanity, including identifying parts and hardware, and demonstrating each connection.

Step-by-Step Assembly Overview:

- 1. Prepare Drawer Slides:** Attach the appropriate drawer slide components (L-CR, L-CL) to the designated side panels (e.g., boards 2, 3, 4, 11) using small screws (D).
- 2. Insert Cam Dowels:** Secure cam dowels (B) into the pre-drilled holes on the side panels.

3. **Assemble Crossbars:** Connect the crossbar pieces (e.g., boards 7, 8, 10) using wood dowels (C) and cam locks (A).
4. **Construct Side Frames:** Assemble the left and right side frames of the vanity base by connecting the side panels and crossbars using cam locks (A).
5. **Attach Back Panels and Supports:** Secure the back panels and internal supports (e.g., boards 27, 28, 29) to the main frame using wood dowels (C) and long screws (F).
6. **Assemble Top Shelf Supports:** Construct the various top shelf supports (e.g., boards 24, 25, 26, 30, 31, 32) by inserting cam dowels (B) and wood dowels (C), then securing with cam locks (A) and cam covers (N).
7. **Install Drawer Slide Brackets:** Attach the drawer slide brackets (I) to the back panel of the vanity using medium screws (E).
8. **Connect Top Frame:** Attach the main top frame (board 1) to the assembled top structure using long screws (F) and cam dowels (B).
9. **Join Top and Base Sections:** Carefully align and connect the assembled top mirror section to the vanity base using wood dowels (C), cam locks (A), and cam covers (N).
10. **Secure Back Panels and Accessories:** Attach the remaining back panels (e.g., board 5) to the side sections using short screws (G). Install the hair dryer holder (K) using its designated screws (H).
11. **Install Charging Station:** Mount the power strip (M) into its designated slot using medium screws (E).
12. **Assemble Drawers:** Construct all seven drawers (six small, one large) by connecting the drawer sides and bottoms using screws (F, D), cam dowels (B), and cam locks (A). Attach the drawer handles (J).
13. **Attach Drawer Slides to Drawers:** Secure the remaining drawer slide components (L-DL, L-DR) to the assembled drawers using small screws (D).
14. **Install LED Lights:** Insert the LED light bulbs (P) into their sockets around the mirror. Connect the LED light wiring as shown in the video.
15. **Final Touches:** Place the tempered glass top (33) onto the vanity. Carefully slide all assembled drawers into their respective slots.
16. **Wall Mounting:** Secure the vanity to the wall using the anti-tip kit (Q) to prevent accidental tipping. Follow the instructions provided with the anti-tip kit for proper installation.

5. OPERATING INSTRUCTIONS

LED Lights:

The vanity mirror is equipped with LED lights offering three lighting modes and adjustable brightness.

1. **Power On/Off:** Locate the inline control button on the LED light cable. Press the power button to turn the lights on or off.
2. **Change Lighting Mode:** Press the mode button to cycle through the three color temperature settings: Cool White (3000K), Natural Light (4500K), and Warm Light (9000K).
3. **Adjust Brightness:** Use the '+' and '-' buttons to increase or decrease the brightness of the LED lights.

▶ 3 Light Modes & Adjustable Brightness ◀



Figure 3: LED Light Control and Modes

Charging Station:

The integrated charging station provides convenient power access for your electronic devices.

1. **Connect Power:** Ensure the vanity's main power cord is plugged into a standard wall outlet.
2. **Use Outlets:** The charging station includes 2 AC outlets, 1 USB port, and 1 Type-C port. Plug your devices directly into the appropriate port.

Charge Everything Right Here


FCC & UL Certified Charging Hub with 59" Heavy-duty Cable



2 AC Outlets



1 USB
1 Type-C port



4.9-Foot
Power Cord Length

Figure 4: Integrated Charging Station

6. MAINTENANCE

Cleaning:

- **Wood Surfaces:** Wipe with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish. Dry immediately with a clean cloth.
- **Tempered Glass Top:** Clean with a glass cleaner and a soft, lint-free cloth.
- **Mirror:** Use a standard glass cleaner and a soft cloth. Do not spray cleaner directly onto the mirror; apply to the cloth first.
- **LED Lights:** Gently wipe bulbs with a dry, soft cloth when cool.

General Care:

- Avoid direct sunlight and extreme temperature changes to prevent warping or fading.
- Do not place hot items directly on the surface without protection.
- Periodically check all fasteners and re-tighten if loose.

7. TROUBLESHOOTING

- **LED Lights Not Working:** Ensure the power cord is securely plugged into a working outlet and the inline control button is pressed. Check for any loose connections in the wiring.
- **Charging Station Not Providing Power:** Verify the vanity's main power cord is plugged in. Test the outlet with another device. Check if the charging station itself has a reset button or indicator light.
- **Drawers Sticking or Not Sliding Smoothly:** Ensure the drawer slides are properly aligned and free of obstructions. Check that all screws securing the slides are tight. Apply a silicone-based lubricant to the slides if necessary.
- **Vanity Feels Unstable:** Confirm all assembly screws and cam locks are fully tightened. Ensure the anti-tip kit is correctly installed and secured to a wall stud.

8. SPECIFICATIONS

Feature	Detail
Brand	LUXOAK
Model Number	CNS183
Color	Black
Material	Engineered Wood
Frame Material	Engineered Wood
Product Dimensions (D x W x H)	15.7" x 47.2" x 53.7" (40cm x 120cm x 136.5cm)
Item Weight	111.7 pounds (50.6 kg)
Assembly Required	Yes
LED Light Modes	Cool White (3000K), Natural Light (4500K), Warm Light (9000K)
Charging Station	2 AC Outlets, 1 USB Port, 1 Type-C Port
Manufacturer	boliyang

9. WARRANTY AND SUPPORT

For warranty information, product support, or to order replacement parts, please contact LUXOAK customer service through the retailer where the product was purchased. Please have your model number (CNS183) and purchase date available when contacting support.

© 2025 LUXOAK. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question