Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Zilan 8945

Zilan H20 Water Filter Vacuum Cleaner User Manual

Model: 8945

1. Introduction

Thank you for choosing the Zilan H20 Water Filter Vacuum Cleaner. This high-performance appliance is designed for efficient cleaning, offering versatility for both indoor and outdoor use. Its innovative water filtration system ensures cleaner air, making it ideal for allergy sufferers. With a powerful 2000W motor, it effectively tackles stubborn dirt, liquids, and fine dust.

This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your new vacuum cleaner. Please read it thoroughly before first use and keep it for future reference.



Figure 1: Zilan H20 Water Filter Vacuum Cleaner in use.

2. Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury.

- Read all instructions before using the appliance.
- Do not leave the appliance unattended when plugged in. Unplug from outlet when not in use and before servicing.
- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.

- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce airflow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Use extra care when cleaning on stairs.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up toxic material (chlorine bleach, ammonia, drain cleaner, etc.).
- Do not use in an enclosed space where vapors are present from oil base paint, paint thinner, some mothproofing substances, flammable dust, or other explosive or toxic vapors.
- Do not pick up hard or sharp objects such as glass, nails, screws, coins, etc.
- Always disconnect from electrical outlet before connecting or disconnecting hose.
- Store the appliance indoors. After use, put the appliance away to prevent tripping accidents.
- Always turn off this appliance before connecting or disconnecting vacuum hose.
- Do not use without water filter and/or dust bag (if applicable) in place.

3. Package Contents

Please check that all items are present and in good condition:

- Zilan H20 Water Filter Vacuum Cleaner Unit
- Flexible Hose
- Telescopic Tube
- Floor Brush
- Upholstery Brush
- Crevice Tool (2 nozzles included)
- User Manual



Figure 2: Included accessories and nozzles.

4. Setup

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Attaching the Hose:** Insert the flexible hose into the suction inlet on the main unit until it clicks securely into place.
3. **Assembling the Tube and Nozzle:**
    - Connect the telescopic tube to the handle end of the flexible hose.
    - Attach the desired cleaning nozzle (floor brush, upholstery brush, or crevice tool) to the end of the telescopic tube.
4. **Preparing for Wet Operation (Water Filtration):**
    - Open the main unit and locate the water tank.
    - Fill the water tank with clean tap water up to the indicated MAX fill line. Do not overfill.
    - Ensure the water tank is correctly seated and the lid is securely closed before operation.



Figure 3: Innovative water filtration system.

5. **Preparing for Dry Operation (with optional bag):**
    - If you prefer to use the vacuum with a dust bag for dry cleaning, ensure the water tank is empty and clean.
    - Insert a compatible dust bag into the designated compartment (refer to the diagram in the full manual for exact location).

5. Operating Instructions

1. **Power Connection:** Plug the power cord into a suitable electrical outlet (230V / 50Hz).
2. **Power On/Off:** Press the power button located on the main unit to turn the vacuum cleaner on or off. The soft-start function ensures a gentle power-up.
3. **Adjusting Suction Power:** Some models may feature a suction control on the hose handle. Adjust as needed for different surfaces.
4. **Cleaning Surfaces:**
    - **Hard Floors and Carpets:** Use the floor brush. For carpets, ensure the brush setting is appropriate (some

floor brushes have adjustable settings).

- **Upholstery:** Use the upholstery brush for furniture, curtains, and other fabric surfaces.
- **Crevices and Tight Spaces:** Attach the crevice tool for corners, edges, and narrow gaps.



Figure 4: Flexible dry or wet cleaning options.

5. **Wet Vacuuming (for liquids):**
    - Ensure the water tank is properly filled and sealed.
    - Use the appropriate nozzle for liquid pickup.
    - Move the nozzle slowly over the liquid spill. The water filter will trap the liquid and debris.
    - Do not overfill the water tank during wet vacuuming; empty it as soon as it reaches the MAX fill line.
6. **After Use:** Turn off the vacuum cleaner and unplug it from the power outlet.

6. Maintenance

Regular maintenance ensures optimal performance and extends the life of your Zilan H20 vacuum cleaner.

1. **Emptying and Cleaning the Water Tank:**
    - After each use, especially after wet vacuuming, carefully remove the water tank.
    - Pour out the dirty water and rinse the tank thoroughly with clean water.
    - Clean any debris from the tank and ensure it is dry before reassembling or storing.
2. **Filter Maintenance:**
    - The water filter system is designed to be easy to clean. Regularly inspect and clean the internal filter components as per the full manual's instructions.
    - If using a dust bag for dry operation, replace it when full.
3. **Cleaning the Exterior:** Wipe the exterior of the vacuum cleaner with a soft, damp cloth. Do not use abrasive cleaners or solvents.
4. **Hose and Nozzle Cleaning:** Check the hose and nozzles for blockages and clean them as needed.
5. **Cord Storage:** Use the integrated cord winder on the appliance for neat storage.

7. Troubleshooting

If you encounter issues with your vacuum cleaner, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Vacuum does not turn on.	Not plugged in; power outlet faulty; power button not pressed.	Check power cord connection; test outlet with another appliance; press power button firmly.
Low suction power.	Water tank overfilled/empty; hose/nozzle blocked; filters dirty; water tank not sealed properly.	Adjust water level; clear blockages; clean/replace filters; ensure water tank is securely closed.
Water leaking from unit.	Water tank overfilled; water tank not properly sealed; damaged tank/seal.	Do not overfill water tank; ensure tank is correctly seated and sealed; inspect for damage and contact support if necessary.
Unusual noise during operation.	Blockage in hose/nozzle; motor issue.	Check and clear any blockages. If noise persists, discontinue use and contact customer support.

If the problem persists after trying these solutions, please contact Zilan customer support.

8. Specifications

Brand: Zilan

Model Number: 8945

Max Power: 2000 W

Nominal Power: 1500 W

Water Tank Capacity: Approx. 8 liters

Suction Power: 2300 mm H2O (196 mbar)

Air Flow: 45 l/s

Power Supply: 230 V / 50 Hz

Filter Type: Water Filter

Special Features: Soft-start function, Motor protected against water ingress, Carry handle, Cord winder, Dry/Wet operation, Hypoallergenic, HEPA-like filtration (water filter system filters up to 99.96% of particles).

Recommended Surface: All floors

Included Components: Upholstery brush, Crevice tool (2 nozzles)

Dimensions (L x W x H): Approx. 35 x 35 x 55 cm



Figure 5: Product dimensions.



Figure 6: Key performance specifications.

9. Warranty and Support

For warranty information, please refer to the documentation provided with your purchase or contact the retailer directly. Zilan products are designed for durability and performance.

If you require technical assistance or have questions not covered in this manual, please contact Zilan customer support or the seller from whom you purchased the product. The seller for this product is **Enstore Deutschland**.

© 2025 Zilan. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FR2DD9JH

More documents and user manuals: **https://manuals.plus/**