Haier HDPR1618CNPK

Haier 2D 60 Series 1 PRO HDPR1618CNPK Refrigerator Instruction Manual

Model: HDPR1618CNPK

Introduction

This manual provides essential information for the safe and efficient use of your Haier 2D 60 Series 1 PRO HDPR1618CNPK Combi Refrigerator. Please read these instructions carefully before installation, operation, and maintenance. Keep this manual for future reference.

Safety Information

Your safety and the safety of others are paramount. Follow all safety warnings and precautions to prevent personal injury or property damage.

- Ensure the appliance is properly grounded.
- Do not damage the refrigerant circuit.
- Do not use electrical appliances inside the food storage compartments unless they are of the type recommended by the manufacturer.
- Unplug the appliance before cleaning or performing maintenance.
- Keep ventilation openings clear of obstruction.
- This appliance is intended for household use only.
- Children should be supervised to ensure they do not play with the appliance.

Setup and Installation

1. Unpacking

Carefully remove all packaging materials. Inspect the appliance for any damage during transit. Retain packaging materials for potential future transport or return.

2. Placement

This is a free-standing appliance. Place the refrigerator on a firm, level surface away from direct sunlight, heat sources (e.g., oven, radiator), and extreme cold. Ensure adequate air circulation around the appliance for optimal performance. The dimensions are 66.7 cm (D) x 59.5 cm (W) x 185 cm (H).



Image: The Haier HDPR1618CNPK refrigerator positioned in a modern kitchen, illustrating its free-standing placement.

3. Door Reversal

The door hinges are reversible, allowing you to change the door opening direction from right to left, or vice versa, to suit your kitchen layout. Refer to the detailed instructions in the included user manual for the specific steps required for door reversal.

4. Power Connection

Connect the appliance to a dedicated 230 Volt power outlet. The refrigerator uses a Type F - 2 pin plug (German and Spanish standard). Ensure the socket is properly grounded. Wait at least 4 hours after installation before plugging in the appliance to allow the refrigerant to settle.

Operating Instructions

1. Temperature Control

The refrigerator features adjustable temperature control. The internal display allows you to set the desired temperature for both the refrigerator and freezer compartments. Typically, the refrigerator temperature is set between 2°C and 8°C, and the freezer at -18°C or lower.



Image: Close-up of the internal LED lighting and control panel, showing temperature settings.

2. Refrigerator Compartment

The refrigerator compartment has a net capacity of 235 liters. It includes 4 glass shelves, 5 door balconies, and a dedicated vegetable drawer. The **Circular AirFlow** system ensures even cooling throughout, while **Total No Frost** technology prevents ice buildup. The **Super Cool** function rapidly cools newly added items.





Image: The refrigerator and freezer doors open, revealing the interior layout with shelves, drawers, and door storage.



Image: Visual representation of the Circular AirFlow system, showing air circulation around food items on shelves.

0° Fresh Zone Drawer

The dedicated **0° Fresh Zone** drawer is designed to maintain a temperature close to 0°C, ideal for storing fresh meat, fish, and dairy products, preserving their freshness for longer.



Image: A close-up of the Fresh Zone drawer, containing fresh salmon and other delicate food items.

3. Freezer Compartment

Located at the bottom, the freezer compartment has a net capacity of 120 liters. It features **Total No Frost** technology, eliminating the need for manual defrosting. It has a freezing capacity of 7 kg/24h and an autonomy of 13 hours in case of power failure.



Image: The freezer compartment with its transparent drawers, showing frozen food items.

Maintenance and Care

1. Cleaning

Always unplug the appliance before cleaning. Clean the interior and exterior surfaces regularly with a soft cloth and mild detergent. Avoid abrasive cleaners or solvents. The glass shelves and door balconies can be removed for easier cleaning.

2. Defrosting

Both the refrigerator and freezer compartments feature an automatic defrosting system (**Total No Frost**). This means manual defrosting is not required. Ensure the drain hole for defrost water in the refrigerator compartment is not blocked.

3. Power Saving Tips

- Do not place hot food directly into the refrigerator or freezer.
- Avoid opening the doors too frequently or for extended periods.
- Ensure the door seals are clean and intact.
- Keep the condenser coils at the back of the appliance clean for efficient operation.

Troubleshooting

Before contacting customer service, refer to the following common issues and solutions:

Problem	Possible Cause & Solution

Problem	Possible Cause & Solution
Appliance does not operate	No power supply; plug not inserted correctly; fuse blown. **Solution:** Check power supply; ensure plug is firmly inserted; check household fuse.
Temperature is not cold enough	Door opened too frequently; large amount of warm food added; temperature setting too high; poor ventilation. **Solution:** Reduce door openings; allow food to cool before storing; adjust temperature setting; ensure proper ventilation.
Unusual noises	Appliance not level; contact with wall; normal operating sounds (e.g., refrigerant flow). **Solution:** Adjust leveling feet; move appliance away from wall; understand that some sounds are normal.
Water on the floor	Defrost water drain blocked. **Solution:** Clear the drain hole in the refrigerator compartment.

Specifications

Feature	Value
Model Name	HDPR1618CNPK
Product Type	Combi Refrigerator
Installation Type	Free-standing
Color	Stainless Steel (Inox)
Total Net Capacity	352 Liters
Refrigerator Net Capacity	235 Liters
Freezer Net Capacity	120 Liters
Dimensions (D x W x H)	66.7 cm x 59.5 cm x 185 cm
Weight	79 Kilograms
Defrost System	Automatic (Total No Frost)
Special Features	Circular AirFlow, 0° Fresh Zone, Inverter Compressor, LED Lighting
Energy Consumption	172 kWh/annum
Noise Emission	35 dB (Class B)
Voltage	230 Volt
Plug Type	Type F - 2 pin (German and Spanish)
Door Reversibility	Yes
Number of Shelves (Refrigerator)	4 (Glass)

Feature	Value
Number of Door Balconies	5
Freezing Capacity	7 kg/24h
Autonomy (Power Failure)	13 hours




Image: The EU Energy Label for the Haier HDPR1618CNPK, showing energy class C, 172 kWh/annum consumption, and noise level 35 dB.

For more detailed product information, refer to the EPREL database.

Warranty Information

This product comes with a manufacturer's warranty:

- **Private Consumers:** 2 years warranty.
- **Businesses:** 1 year warranty.

Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects under normal use conditions. For full terms and conditions, please refer to the warranty card included with your product or contact Haier customer service.

Support and Contact

For technical assistance, spare parts, or further information, please contact Haier customer support or visit the official Haier website.
You can also visit the official Haier store on Amazon for product information and accessories:Haier Store.

© 2024 Haier. All rights reserved.