

[Manuals.plus](#) /

› [GREVA](#) /

› GREVA X88 PRO T1 Android TV Stick 4K Ultra HD Streaming Device User Manual

GREVA X88 PRO T1

GREVA X88 PRO T1 Android TV Stick User Manual

4K Ultra HD Streaming Device

INTRODUCTION

The GREVA X88 PRO T1 Android TV Stick is a compact 4K Ultra HD streaming device designed to transform your television into a smart entertainment hub. Featuring the latest Android 14.0 operating system, a powerful RK3518 Quad-Core processor, Wi-Fi 6, and Bluetooth 5.0, this device provides access to a wide range of streaming services and applications. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device.

PACKAGE CONTENTS

Please verify that all items listed below are included in your package:

- GREVA X88 PRO T1 Android TV Stick
- Remote Control
- Product Manual (this document)
- Power Adapter (USB cable)
- HD Cable (HDMI extension cable)

Package Contents



Image: Contents of the GREVA X88 PRO T1 Android TV Stick package.

SETUP INSTRUCTIONS

Follow these steps to set up your GREVA X88 PRO T1 Android TV Stick:

1. **Connect the TV Stick to your TV:** Insert the GREVA X88 PRO T1 Android TV Stick directly into an available HDMI port on your television. If space is limited, use the provided HDMI extension cable.
2. **Power the Device:** Connect the provided USB power cable to the TV Stick's power input and then plug the other end into a wall power adapter (not included, but recommended) or a dedicated USB power port on your TV. *Note: Using a TV's USB port for power may not provide sufficient power for stable operation. A wall adapter is recommended.*
3. **Select HDMI Input:** Turn on your TV and use your TV remote to select the correct HDMI input source to which the TV Stick is connected.
4. **Initial Setup:** Follow the on-screen instructions to pair your remote control, connect to your Wi-Fi network, and log in with your Google account.
5. **Start Streaming:** Once setup is complete, you can begin downloading and enjoying your favorite streaming applications.

Get up and running in 3 simple steps

STEP 01

Connect TV Box to TV



STEP 02

Connect to internet



STEP 03

Start in streaming



Image: Visual guide for the three-step setup process.

OPERATING INSTRUCTIONS

Remote Control and Voice Assistant

The included remote control allows for easy navigation. Utilize the built-in voice assistant by pressing the dedicated voice button and speaking your commands. This enables quick searches for content, app launches, and other functions.

Smart Voice Remote Control

Hold down the voice button to search for popular apps, such as PrimeVideo, Netflix, Disney+.



Image: Using the smart voice remote control to interact with the TV Stick.

Accessing Streaming Services

The GREVA X88 PRO T1 comes with Android 14.0, providing access to a wide array of applications through the Google Play Store. Popular services like Netflix, YouTube, Prime Video, Hulu, and Disney+ can be downloaded and installed.

Built-in Android 14.0 system

Smart Android TV Stick: built with multiple apps, enjoy massive shows freely!



Image: The Android 14.0 system interface with available applications.

Wireless Screen Projection (Casting)

The device supports wireless screen projection, allowing you to cast content from your smartphone, tablet, or PC directly to your television screen. Refer to your device's casting instructions for specific steps.

Enjoy a rich variety of ports.



Image: Demonstrating screen casting functionality from a mobile device to the TV.

Mouse Assistance Feature

For applications that benefit from mouse interaction, the TV Stick offers a mouse assistance feature. This allows you to control a cursor on the screen using your remote's directional buttons, enabling easier navigation in certain apps like web browsers.

Mouse Assistance

Support mouse page flip function, through the mouse assistance, you can realize the sliding page flip effect when using Chrome or Netflix and other applications.




Image: Configuration screen for the Mouse Assistance feature.

MAINTENANCE

To ensure the longevity and optimal performance of your GREVA X88 PRO T1 Android TV Stick, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the device and remote control. Avoid using liquid cleaners or abrasive materials.
- **Ventilation:** Ensure the device is placed in a well-ventilated area to prevent overheating. Do not cover the device or place it in enclosed spaces.
- **Storage:** When not in use for extended periods, store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Software Updates:** Periodically check for system updates in the device settings to ensure you have the latest features and security patches.

TROUBLESHOOTING

If you encounter issues with your GREVA X88 PRO T1 Android TV Stick, refer to the following common problems and solutions:

Problem	Possible Solution
Device does not power on or is unstable.	Ensure the device is connected to a reliable power source. It is highly recommended to use a wall power adapter (5V/2A) instead of a TV's USB port, as TV USB ports may not supply sufficient power.
Remote control is unresponsive.	Check the batteries in the remote control and replace them if necessary. Try re-pairing the remote control with the TV Stick by following the on-screen instructions during initial setup or in the device's Bluetooth settings.
No display or poor video quality.	Verify that the TV Stick is securely connected to the HDMI port. Ensure your TV is set to the correct HDMI input. Check your TV's display settings and the TV Stick's display settings for resolution compatibility.
Wi-Fi connection issues.	Ensure your Wi-Fi router is on and within range. Re-enter your Wi-Fi password in the device's network settings. Restart both your Wi-Fi router and the TV Stick.
Certain applications do not work or update.	Some applications may have specific system requirements or may not be fully optimized for all Android TV versions. Check the app's compatibility and ensure the TV Stick's software is up to date. Clear the app's cache and data in the device settings, or reinstall the app.

SPECIFICATIONS

Key technical specifications for the GREVA X88 PRO T1 Android TV Stick:

Feature	Detail
Model Name	X88 PRO T1
Operating System	Android 14.0 TV OS
Processor	RK3518 Quad-Core 64bit Cortex-A53 CPU with Mali-450 GPU
RAM Memory	2 GB
Internal Storage	16 GB EMMC (expandable via Micro SD card, max 64G)
Connectivity	2.4G/5G Wi-Fi 6, Bluetooth 5.0, HDMI 2.1, Ethernet (100M RJ-45)
Video Output Resolution	4K Ultra HD (3840 Pixels) @ 60fps
Video Codecs	H.264, H.265/HEVC
Special Features	DLNA, Voice Assistant Remote Control, Wireless Screen Projection
Compatible Devices	Television
Dimensions (L x W x H)	Approx. 10cm x 3.3cm x 1.4cm (4.5 Ounces)



Image: Interface and dimensions of the GREVA X88 PRO T1 Android TV Stick.

WARRANTY AND SUPPORT

Warranty: This product does not come with an explicit manufacturer's warranty as per available information.

Customer Support: For further assistance or inquiries, please refer to the GREVA brand store on Amazon or contact your retailer.

GREVA Brand Store: <https://www.amazon.com/stores/GREVA/page/7D0A0AD2-A5AB-4035-A76A-4DF8EB7AA149>