

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Gitelsnour](#) /

› [Gitelsnour Cat Tree GCT006SG User Manual](#)

Gitelsnour GCT006SG

Gitelsnour Cat Tree GCT006SG User Manual

Model: GCT006SG | Brand: Gitelsnour

1. INTRODUCTION

This document provides detailed instructions for the assembly, safe operation, and maintenance of your Gitelsnour Cat Tree Model GCT006SG. Designed specifically for small cats and kittens, this multi-level cat tree offers various features for play, rest, and scratching. Please read this manual thoroughly before assembly and use to ensure the safety and enjoyment of your pet.



Image: The Gitelsnour Cat Tree GCT006SG in dark gray, showcasing its various platforms, cat condo, and scratching areas. Three cats are seen enjoying different parts of the tree.

2. SAFETY INSTRUCTIONS

- **Indoor Use Only:** This cat tree is designed for indoor use. Do not place it outdoors.

- **Stability:** Ensure all components are securely tightened during assembly. Utilize the provided anti-tip device by fixing it to a wall to prevent accidental tipping, especially with active cats.
- **Weight Limit:** This cat tree is specifically designed for small cats and kittens. It is not recommended for large or multiple heavy cats to ensure stability and safety.
- **Material Safety:** All plush fabric and engineered wood boards used have passed international safety certifications.
- **Regular Inspection:** Periodically check for loose parts, damaged components, or excessive wear. Tighten screws and replace worn parts as needed.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all parts listed below are present and undamaged. Refer to the assembly video for visual identification of components.

Components:

- Base Plates (separated for stability)
- Multi-level Platforms (various shapes and sizes)
- Cat Condo (enclosed resting space)
- Hanging Cat Basket (supported by inner iron ring)
- Scratching Posts (sisal rope wrapped)
- Plush Balls (hanging toys)
- Sisal Ramp (for climbing and scratching)

Hardware & Tools:

- Screws and Bolts (various sizes)
- Allen Wrench (for assembly)
- Anti-tip Device (strap and wall anchor)

4. ASSEMBLY INSTRUCTIONS

Follow the steps below carefully. It is recommended to watch the official assembly video for a visual guide.

Video: Official assembly guide for the WANG XIN Cat Tree, demonstrating step-by-step construction of a similar cat tree model. This video provides a visual walkthrough of connecting posts, platforms, and accessories.

1. **Step 1: Attach Base Posts.** Secure the initial scratching posts (A and B) to the main base plate using the provided screws. Ensure they are firmly attached.
2. **Step 2: Install First Platform.** Attach the first platform (Board 2) to the top of the posts from Step 1. Use the appropriate screws and tighten them.
3. **Step 3: Assemble Cat Condo.** Place the cat condo (Board 3) onto the designated posts on the first platform. Secure it from underneath with screws.
4. **Step 4: Add Intermediate Platforms and Posts.** Continue building upwards by attaching additional posts (J) and platforms (Board 4) as indicated in the diagram. Ensure all connections are stable.
5. **Step 5: Install Hammock and Top Perch.** Attach the hanging cat basket (Board 5) and the top removable perch (Board 6) to their respective posts. Secure them with screws.

- Step 6: Attach Sisal Ramp.** Connect the sisal ramp (Board 8) to the lower platform, ensuring it is angled correctly for easy climbing.
- Step 7: Attach Hanging Toys.** Secure the plush balls to the designated points on the cat tree.
- Step 8: Install Anti-Tip Device.** For enhanced safety, attach the anti-tip strap to the top of the cat tree and secure it to a sturdy wall stud using appropriate hardware.

5. OPERATING INSTRUCTIONS

Your Gitelsnour Cat Tree is designed to provide a stimulating and comfortable environment for your small cats and kittens. Here's how they can utilize its features:

- **Removable Top Platform:** This spacious platform is ideal for resting or observing surroundings. The attached plush balls provide entertainment. The platform is detachable for easy cleaning.
- **Comfort Cat Condo:** The enclosed cat house, covered in soft plush fabric, offers a private and cozy space for your cat to sleep or hide.
- **Hanging Cat Basket:** Supported by an inner iron ring, this basket provides a secure and comfortable spot for curling up.
- **Stepped Activity Route:** The multi-level design with stepped structures allows cats to easily climb, jump, and explore the entire tree, promoting physical activity.
- **Scratching Posts and Ramp:** Multiple posts and a ramp are covered with durable sisal rope, providing designated areas for your cat to satisfy their natural scratching instincts, helping to protect your furniture.



Image: A cat navigating the stepped platforms of the cat tree, illustrating the ease of movement between levels.

6. MAINTENANCE

Regular maintenance will extend the life of your cat tree and keep it hygienic for your pet.

- **Cleaning:** The removable top platform can be detached for easy cleaning. For other plush surfaces, use a soft brush or vacuum cleaner to remove loose fur and debris. Spot clean any soiled areas with a damp cloth and mild, pet-safe detergent. Avoid harsh chemicals.
- **Check Connections:** Periodically inspect all screws and bolts to ensure they remain tight. Re-tighten

any loose connections to maintain stability.

- **Inspect Scratching Surfaces:** Monitor the sisal rope for excessive wear. While durable, sisal can fray over time. If severely worn, consider replacing the affected posts to encourage continued scratching on the tree rather than on household items.
- **Toy Inspection:** Check hanging toys for damage. Replace if they become a choking hazard.

7. TROUBLESHOOTING

- **Tree Wobbles:** Ensure all screws are fully tightened. Verify the base plates are on a flat, even surface. Re-check the anti-tip device installation.
- **Cat Not Using Tree:** Try placing catnip on various levels of the tree. Position the tree near a window or a favorite resting spot. Encourage play with the hanging toys.
- **Excessive Shedding from Plush:** This is normal for new plush items. Vacuum regularly to remove loose fibers.

8. SPECIFICATIONS

Feature	Detail
Brand	Gitelsnour
Model Name	GCT006SG
Product Dimensions (LxWxH)	19.6"L x 15.7"W x 47.24"H
Item Weight	19.27 pounds
Color	Dark gray
Material	Engineered Wood, Faux Fur, Iron
Breed Recommendation	Small
Age Range Description	Kitten



Image: A detailed diagram illustrating the overall dimensions of the cat tree (49.2 inches high, 19.7 inches wide) and the proper method for attaching the anti-tip device to a wall for enhanced stability.

9. WARRANTY AND SUPPORT

This Gitelsnour Cat Tree Model GCT006SG comes with a **half-year warranty** from the date of purchase. This warranty covers manufacturing defects and material flaws under normal use. Please retain your proof of purchase for any warranty claims.

For support, questions, or warranty claims, please refer to the contact information provided with your product packaging or visit the official Gitelsnour website.