Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bonnlo B0FR4QL2M7

Bonnlo 47.2"W x 42"H Freestanding Electric Fireplace Stove User Manual

Model: B0FR4QL2M7

1. Introduction

This instruction manual provides important information for the safe and efficient operation of your Bonnlo 47.2"W x 42"H Freestanding Electric Fireplace Stove. Please read this manual thoroughly before installation and use, and retain it for future reference.

This electric fireplace with a mantel adds warmth and charm to your living space. It features stunningly realistic flame effects, which can create a cozy atmosphere in any room—whether it's your living room, bedroom, or office. The powerful 1400W heater quickly warms up your space, and the remote control allows you to easily adjust the temperature, flame brightness, and timer settings. Combining comfort and style, this fireplace perfectly blends functionality with aesthetics.

2. Safety Information

WARNING: To reduce the risk of fire, electric shock, or injury, read all instructions before using this appliance.

- Ensure the fireplace is placed on a firm, level surface.
- Do not operate the fireplace if the power cord is damaged.
- Keep combustible materials such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the heater and away from the sides and rear.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- The electric fireplace is CSA certified, ensuring it meets applicable safety and performance standards in North America.
- Features double overheat protection and tip-over protection, which automatically shut off the unit to prevent potential accidents.

3. Package Contents

Please check to ensure all components are present and undamaged:

- 1 x Electric Fireplace Insert

- 1 x Wooden Cabinet
- 1 x Remote Control
- 1 x User's Manual (this document)
- 1 x Mounting Screw Pack

4. Specifications

Feature	Specification
Brand	Bonnlo
Model Number	B0FR4QL2M7
Power Source	AC
Power Output	1400W
Temperature Range	62°F to 82°F
Heating Coverage	Up to 400 sq ft
Timer Range	0.5 - 6 Hours
Flame Colors	6 options
Flame Brightness Levels	5 options
Operation Method	Control Panel & Remote Control
Safety Features	Auto-Shutoff, Overheat Protection, Tip-over Protection
Certifications	CSA
Material	Wooden, Iron & Glass
Overall Dimensions	47.2"W x 13.58"D x 41.93"H
Fireplace Insert Dimensions	23.1"W x 4.33"D x 17.16"H
Weight	73 lb

5. Setup and Assembly

The Bonnlo Electric Fireplace Stove is designed for simple installation and operation. Detailed instructions, durable brackets, and high-quality mounting hardware are included in the package. Please follow the step-by-step assembly guide provided with your product for proper setup.

General Assembly Steps:

1. Unpack all components and verify against the package contents list.
2. Assemble the wooden cabinet structure according to the provided diagrams.
3. Carefully insert the electric fireplace unit into the assembled cabinet.
4. Secure the fireplace insert using the provided mounting screws.
5. Place the assembled fireplace in your desired location, ensuring it is near a suitable power outlet and on a stable surface.



Figure 1: Bonnlo 47.2"W x 42"H Freestanding Electric Fireplace Stove.



Figure 2: Detailed product dimensions for the Bonnlo Electric Fireplace and its insert.

6. Operating Instructions

Your Bonnlo Electric Fireplace can be operated using either the control panel on the unit or the included remote control.

6.1. Remote Control Functions

The remote control provides convenient access to all fireplace functions from a distance.



Figure 3: Remote control layout and button functions.

- **Power Button:** Turns the fireplace ON/OFF.
- **Heat Control Button:** Activates/deactivates the heating function. The powerful 1400W heater can quickly warm spaces up to 400 sq ft.
- **Flame Control Button:** Cycles through 6 flame colors and 5 flame brightness levels. You can enjoy the realistic flame effect independently without heat.
- **Timer Button:** Sets the automatic shut-off timer from 0.5 to 6 hours.
- **Temperature UP/DOWN Buttons:** Adjusts the desired temperature between 62°F and 82°F.

6.2. Flame Effects

The fireplace offers a variety of flame effects to suit your preference:

- 6 distinct flame colors.
- 5 levels of flame brightness.
- An auto-cycling color mode for dynamic display.



Figure 4: Visual representation of the 6 flame colors and 5 brightness levels.

6.3. Heating Function

The 1400W heater provides supplemental heating for areas up to 400 square feet. The temperature can be adjusted from 62°F to 82°F. The unit features a digital display for easy temperature monitoring.

7. Maintenance

To ensure the longevity and optimal performance of your fireplace, follow these maintenance guidelines:

- Always unplug the unit before cleaning or performing any maintenance.
- Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Regularly check the air inlet and outlet for dust or debris and clean as necessary to maintain proper airflow.
- Ensure the power cord is not pinched or damaged.

8. Troubleshooting

If you encounter any issues with your fireplace, refer to the following common problems and solutions:

- **No Power:** Check if the power cord is securely plugged into a working outlet. Verify the circuit breaker has not tripped.
- **No Heat:** Ensure the heating function is activated via the control panel or remote. Check the temperature setting; it might be set lower than the ambient room temperature.
- **Flames Not Visible:** Confirm the flame effect is turned on. Adjust flame brightness settings.
- **Unit Shuts Off Automatically:** This is likely due to the overheat protection or tip-over protection being activated. Unplug the unit, allow it to cool for 10-15 minutes, and ensure it is on a stable surface with clear ventilation before restarting.

If problems persist, please contact customer support.

9. Warranty and Support

This Bonnlo Electric Fireplace Stove comes with a**1-Year Limited Warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use.

For warranty claims, technical support, or any questions not covered in this manual, please contact Bonnlo Customer Service. Have your model number (B0FR4QL2M7) and proof of purchase ready.

© 2025 Bonnlo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FR4QL2M7

More documents and user manuals: **https://manuals.plus/**