



[Manuals.plus](#) /

› [WE-VIBE](#) /

› We-Vibe Chorus Pro Couples Vibrator Instruction Manual

WE-VIBE Chorus Pro

We-Vibe Chorus Pro Couples Vibrator Instruction Manual

Model: Chorus Pro

INTRODUCTION

Thank you for choosing the We-Vibe Chorus Pro. This manual provides essential information for the safe and effective use, care, and maintenance of your device. Please read it thoroughly before first use.

weVIBE

Chorus Pro

For your most exciting couples play yet

New!



MORE POWER
AND DEEPER
SENSATION



INTUITIVE
CONTROL

In 3
stylish
colors



Image: The We-Vibe Chorus Pro device, showcasing its ergonomic design.

IMPORTANT SAFETY INFORMATION

- Consult a healthcare professional before use if you have any medical conditions or concerns.
- Discontinue use immediately if you experience any discomfort or pain.
- Do not use with silicone-based lubricants, as this may damage the product's silicone material. Use only water-based lubricants.
- Keep out of reach of children.
- This product is for adult use only.

PACKAGE CONTENTS

The We-Vibe Chorus Pro package typically includes:

- We-Vibe Chorus Pro device
- Haptic Squeeze Remote
- Travel-friendly charging case
- USB charging cable
- Instruction manual (this document)



Image: An overview of the We-Vibe Chorus Pro device and its accessories, including the charging case and cable.

SETUP

1. Charging the Device

Before first use, fully charge your We-Vibe Chorus Pro and its remote. Both devices charge discreetly within the provided travel-friendly charging case.

1. Place the Chorus Pro and its remote into the charging case.
2. Connect the USB charging cable to the charging case and a suitable USB power source.
3. Allow approximately 90 minutes for a full charge, which provides up to 2 hours of continuous use.



Image: The We-Vibe Chorus Pro and remote inside the charging case, with the USB cable connected.

2. Connecting to the We-Vibe App

For enhanced control and customizable patterns, download the We-Vibe App.

1. Download the "We-Vibe App" from your device's app store (available on Google Play and the App Store).
2. Ensure your Chorus Pro device is charged and powered on.
3. Open the We-Vibe App and follow the on-screen instructions to pair your device via Bluetooth.




Image: The We-Vibe App icon, indicating its availability for download.

OPERATING INSTRUCTIONS

Basic Operation

- **Power On/Off:** Press and hold the power button on the device or remote until it vibrates.
- **Adjusting Intensity:** Use the '+' and '-' buttons on the device or remote to cycle through 10 intensity levels.
- **Haptic Squeeze Remote:** The remote allows instant intensity adjustment by squeezing it.



we VIBE



Insert the Toy
with help of a bit
of Lubricant



Triple stimulation
for Clitoral, G-spot & Penis

Your Bodies. Your Rhythm.

Designed to be worn during play

Image: Close-up of the We-Vibe Chorus Pro device, showing the control buttons.

Fusion Wave Technology

The Chorus Pro features Fusion Wave Technology with two synchronized motors. This technology creates wave-like pulses and flowing vibrations for clitoral and G-Spot stimulation.



Image: Diagram showing the internal motors and the dual stimulation points of the Fusion Wave Technology.

Touch Sense & Flexible Fit

The device incorporates motion-responsive touch sensors and a flexible hinge, allowing it to adapt to your body for a comfortable and tailored fit.

we VIBE

CHORUS PRO

Berlin

Sydney

No limits

More closeness despite long distance

VIA APP & INTERNET
Connect worldwide
VIA APP & INTERNET

Image: Visual representation of the device's flexibility and touch-sensitive areas.

App Control Features

The We-Vibe App unlocks additional features for personalized experiences:

- **Touch Sense Mode:** Individually adjustable vibrations that respond to your touch.
- **Beat Mode:** Synchronize vibrations to the rhythm of music.
- **Chat Function:** For shared experiences and long-distance play.
- **Fusion Wave Patterns:** Explore additional pre-set patterns.

we VIBE

Your App

For intuitive control



Touch Sense Mode
individually adjustable



Beat Mode
vibration to the
rhythm of music



Chat-Funktion
for shared fun



Fusion Wave Patterns
3 additional patterns



Image: Screenshots of the We-Vibe App interface, highlighting different control modes and features.

CARE AND MAINTENANCE

Cleaning


The We-Vibe Chorus Pro is fully waterproof (IPX7 rated), making it easy to clean.

1. Wash the device thoroughly with warm water and mild soap or a specialized toy cleaner after each use.
2. Rinse thoroughly to remove all soap residue.
3. Pat dry with a lint-free cloth.



Touch Sense Mode

Vibrations that respond to your touch.



Touch sensor



Image: The We-Vibe Chorus Pro submerged in water, demonstrating its waterproof design.

Storage

Store your Chorus Pro and its remote in the provided travel-friendly charging case to keep them clean and protected.

- Store in a cool, dry place away from direct sunlight.
- Avoid storing with other toys made of different materials to prevent material degradation.

TROUBLESHOOTING

- **Device not turning on:** Ensure the device is fully charged. Connect it to the charging case and power source.
- **App connectivity issues:** Ensure Bluetooth is enabled on your smartphone and the device is within range. Try restarting both the device and the app.
- **Weak vibrations:** Check the battery level. If low, recharge the device.

If you encounter persistent issues not covered here, please refer to the official We-Vibe support website or contact

customer service.

SPECIFICATIONS

Feature	Detail
Product Dimensions	6.3 x 6.3 x 3.15 inches; 1.5 Pounds
Model Number	Chorus Pro
Batteries	1 Nonstandard Battery (included)
Material	Silicone
Color	Purple
Manufacturer	WOW Tech
Waterproof Rating	IPX7
Playtime	Up to 2 hours
Charge Time	Approx. 90 minutes

VIDEO GUIDE

Watch the official product video for a visual guide on using your We-Vibe Chorus Pro.

Your browser does not support the video tag.

Video: An official demonstration of the We-Vibe Chorus Pro, showcasing its features and usage.

WARRANTY AND SUPPORT

For warranty information, product support, or to contact customer service, please visit the official WE-VIBE website or refer to the contact details provided in your product packaging.

Manufacturer: WOW Tech

