



[Manuals.plus](#) /

› [LEGO](#) /

› [LEGO Editions Lionel Messi – Soccer Legend Building Set \(43015\) Instruction Manual](#)

## LEGO 43015

# LEGO Editions Lionel Messi – Soccer Legend Building Set (43015) Instruction Manual

Model: 43015

## INTRODUCTION

This manual provides detailed instructions for assembling and caring for your LEGO Editions Lionel Messi – Soccer Legend (43015) building set. This set allows you to construct a highly detailed display figure of Lionel Messi, offering two distinct poses. Please read through all sections to ensure proper assembly and maintenance of your model.



Image: The LEGO Lionel Messi Soccer Legend building set (43015) displayed in its victory pose, featuring the number 10 and 'MESSI' lettering.

## PRODUCT FEATURES

- **Iconic Athlete Representation:** Construct a detailed display figure of Lionel Messi.
- **Dual Posing Options:** Build Messi in his signature victory pose, pointing towards the sky, or in a dynamic running pose with a soccer ball.
- **Authentic Details:** Features a co-molded face, a soccer ball element, a large number 10, 'MESSI' lettering, and a printed name plaque.
- **Display Ready:** Designed for display on shelves, tables, or desks as collectible sports decor.
- **Interactive Building:** Utilize the LEGO Builder app for 3D instructions, progress tracking, and digital guidance.
- **Piece Count:** Contains 958 LEGO building elements.
- **Dimensions:** Measures over 10.5 inches (27 cm) high, 8 inches (21 cm) wide, and 5.5 inches (14 cm) deep when constructed in the victory pose.

## SETUP AND ASSEMBLY

### Unpacking the Set

Carefully open the packaging and ensure all LEGO building elements are present. Refer to the parts list in your printed instruction booklet or the LEGO Builder app to verify all 958 pieces are accounted for.

## Building Instructions

The LEGO Editions Lionel Messi – Soccer Legend set (43015) offers two primary building configurations: a victory pose and a running pose. Follow the step-by-step instructions provided in the included printed manual or via the LEGO Builder app.



## Use the LEGO® Builder app or printed instructions

Image: A child assembling the LEGO Lionel Messi set while referencing instructions on a tablet, highlighting the use of the LEGO Builder app.

### Using the LEGO Builder App

The LEGO Builder app provides an intuitive, interactive 3D building experience. Download the app on your smart device and search for model 43015. The app allows you to zoom, rotate, and track your building progress, offering a dynamic guide for assembly.

### Assembly Steps Overview

The assembly process involves connecting 958 LEGO elements to form the Lionel Messi figure and its display base. Pay close attention to the color and shape of each brick as indicated in the instructions.

- Begin by constructing the base structure.
- Assemble the main body of the Lionel Messi figure.
- Attach the head, arms, and legs, ensuring correct orientation for your chosen pose (victory or running).
- Integrate the specialized co-molded face and soccer ball elements.

- Add the decorative elements, including the large number 10, 'MESSI' lettering, and the printed name plaque.



Image: The LEGO Lionel Messi set showcasing both the victory pose and the dynamic running pose options.



**Includes a new  
co-molded face  
and soccer ball  
element**

Image: A detailed view of the LEGO Lionel Messi figure's co-molded face and the specialized soccer ball element.

Your browser does not support the video tag.

Video: A 360-degree spin of the LEGO Editions Lionel Messi - Soccer Legend (43015) model, providing a comprehensive view of the assembled figure.

## **OPERATING (DISPLAY OPTIONS)**

Once assembled, your LEGO Lionel Messi figure is designed for display. You can choose to present it in either the victory pose or the dynamic running pose.

### **Displaying Your Model**

Place the completed figure on a stable, flat surface such as a bookshelf, bedroom table, or desk. The integrated base ensures stability for both poses.

# Show off your creation as cool and collectible sports decor



Image: The LEGO Lionel Messi set in its victory pose, displayed as a decorative item on a shelf.

## Pose Adjustment

If you wish to change the pose, carefully disassemble the relevant sections (arms, legs) and reassemble them according to the instructions for the alternative pose. Avoid forcing connections to prevent damage to the bricks.

## MAINTENANCE

### Cleaning Your LEGO Model

To keep your LEGO Lionel Messi set looking its best, follow these cleaning guidelines:

- **Dusting:** Use a soft brush or a can of compressed air to gently remove dust from the model's surface.
- **Washing:** For deeper cleaning, disassemble the model into smaller sections. Wash LEGO bricks by hand using lukewarm water (not exceeding 40°C / 104°F) and a mild detergent. Rinse thoroughly with clear water.
- **Drying:** Air dry the bricks completely before reassembling. Avoid direct sunlight or high heat, as this can deform the plastic.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, alcohol, or chemical solvents, as these can damage the plastic.

## TROUBLESHOOTING

## Missing Pieces

If you find any pieces are missing from your new set, please contact LEGO Customer Service directly. They can assist with replacement parts.

## Difficulty Connecting Bricks

Ensure that bricks are aligned correctly before applying pressure. LEGO bricks are designed to fit together smoothly. If a brick is difficult to connect, check for any obstructions or incorrect orientation.

## Model Instability

If the assembled model feels unstable, review the assembly instructions for the base and key structural connections. Ensure all bricks are firmly pressed together.

## Damaged Bricks

If any bricks are damaged during assembly or handling, contact LEGO Customer Service for assistance with replacements.

## SPECIFICATIONS

Feature	Detail
Brand	LEGO
Model Name	Editions Sports 43015
Model Number	6590602
UPC	673419425322
Number of Pieces	958
Material Type	Plastic
Item Dimensions (Victory Pose)	Over 10.5 in. (27 cm) high, 8 in. (21 cm) wide, 5.5 in. (14 cm) deep
Recommended Age	12 years and up
Included Components	LEGO Building Elements

## SAFETY INFORMATION

### General Safety

This product contains small parts and is not suitable for children under 3 years of age due to choking hazards. Adult supervision is recommended for younger builders within the recommended age range (12+).

### Warning

No specific warning applicable beyond general small parts hazard.

## WARRANTY AND SUPPORT

### LEGO Customer Service

For any questions regarding missing parts, damaged elements, or assembly assistance, please visit the official LEGO customer service website or contact their support line. Refer to the packaging for specific contact details in your region.

### Online Resources

The LEGO Builder app and the official LEGO website offer additional resources, including digital instructions and building tips.