

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Estink](#) /
- › [Estink Tabletop Water Fountain Instruction Manual](#)

Estink Estinkg42a9qbcps

Estink Tabletop Water Fountain Instruction Manual

Model: Estinkg42a9qbcps

1. PRODUCT OVERVIEW

The Estink Tabletop Water Fountain is designed to create a tranquil and relaxing atmosphere in your home or office. Crafted from durable plastic, this compact fountain features a soothing water flow and an integrated LED light. It is powered via USB or AA batteries, offering flexible placement options.



Image 1: The Estink Tabletop Water Fountain displayed on an office desk, showcasing its compact design and decorative stones.

2. PACKAGE CONTENTS

Please verify that all items listed below are included in your package:

- 1 x Fountain Ornament
- 1 x Ball (for water flow)
- 1 x USB Power Cord
- 1 x Bag of Irregular Stones
- 1 x Instruction Manual

3. IMPORTANT SAFETY INSTRUCTIONS

- This product is designed for indoor use only.
- Keep the fountain away from electronic devices to prevent water damage.
- Ensure the power source (USB or batteries) matches the product's requirements (DC3V/250mA).
- Do not operate the fountain without sufficient water.

- Always unplug the fountain or remove batteries before cleaning or maintenance.
- Keep out of reach of children and pets.

4. SETUP GUIDE

Step 1: Unpacking

Carefully remove all components from the packaging. Inspect for any damage. Retain packaging for future storage or transport.

Step 2: Placing the Stones

Place the provided irregular stones into the base of the fountain. Arrange them as desired around the water reservoir.

Step 3: Filling with Water

Fill the fountain's reservoir with clean, distilled water. Ensure the water level is sufficient to cover the pump but not so high that it overflows when the fountain is operating. Do not overfill.

Step 4: Connecting Power

The fountain can be powered by either a USB cable or 2 AA batteries (not included).

- **USB Power:** Connect the included USB power cord to the port on the back of the fountain and plug the other end into a compatible DC3V/250mA USB adapter (not included) or a USB port.
- **Battery Power:** Open the battery compartment (usually on the bottom) and insert 2 x 1.5V AA batteries, ensuring correct polarity. Close the compartment securely.



Image 2: Rear view of the fountain, highlighting the power input port and on/off switch.



Image 3: The fountain shown alongside its USB power cable, illustrating the connection method.

5. OPERATING INSTRUCTIONS

Turning On/Off

Once powered, locate the ON/OFF switch, typically on the back or bottom of the fountain. Flip the switch to 'ON' to start the water flow and illuminate the LED light. Flip to 'OFF' to stop operation.

Water Flow and LED Light

The fountain features a gentle water flow that cascades over the ball, creating a soothing sound. A small yellow LED light is integrated to provide a warm, ambient glow, enhancing the relaxing atmosphere.



Image 4: The fountain in operation, with water gently flowing over the spherical top.




Image 5: The fountain illuminated by its small yellow LED light, creating a calming ambiance.

6. CARE AND MAINTENANCE

- **Water Changes:** Regularly change the water in the fountain to prevent algae buildup and maintain water clarity. Depending on usage, change water every 1-2 weeks.
- **Cleaning:** Periodically clean the fountain's interior and pump to remove any mineral deposits or debris. Use a soft brush and mild soap if necessary, then rinse thoroughly. Ensure no soap residue remains.
- **Pump Maintenance:** If water flow weakens, the pump may be clogged. Disassemble the pump according to its specific instructions (if provided) and clean any blockages.
- **Exterior Cleaning:** Wipe the exterior of the fountain with a soft, damp cloth to remove dust.
- **Storage:** When not in use for extended periods, drain all water, clean the fountain, and store it in a dry place.



Image 6: A close-up view of the fountain's base, showing its textured finish, which should be kept clean.

7. TROUBLESHOOTING

- **No Water Flow:**
 - Check if the power cord is securely connected or if batteries are correctly inserted and charged.
 - Ensure the ON/OFF switch is in the 'ON' position.
 - Verify that the water level is sufficient to cover the pump.
 - Clean the pump for any blockages or debris.

- **LED Light Not Working:**

- Ensure the fountain is powered on. The LED light operates with the water pump.
- Check power connection or battery status.

- **Excessive Noise:**

- Ensure the fountain is placed on a flat, stable surface.
- Check water level; low water can cause pump noise.
- Clean the pump for any debris that might be causing vibration.

- **Water Splashing:**

- Ensure the fountain is not overfilled.
- Adjust the placement of stones if they are disrupting water flow.

8. PRODUCT SPECIFICATIONS

Item	Specification
Model Number	Estinkg42a9qbcps
Material	Plastic
Product Dimensions	Approx. 14.5 x 11.5 x 11.5 cm (5.7 x 4.5 x 4.5 inches)
Item Weight	Approx. 496g (17.5 oz)
Power Source	USB (DC3V/250mA adapter) or 2 x 1.5V AA batteries (not included)
Light Color	Small yellow light
Manufacturer	Estink




Image 7: A visual representation of the fountain's dimensions for reference.

9. IMPORTANT NOTES

- Please allow a 1-2 inch error due to manual measurement.
- Item color displayed in photos may show slight variations from the real object due to monitor calibration differences. Please consider the actual product as standard.

- The number and style of irregular stones included may vary.

10. WARRANTY AND CUSTOMER SUPPORT

For warranty information or customer support inquiries regarding your Estink Tabletop Water Fountain, please refer to the seller's return policy or contact the retailer where the product was purchased. Keep your purchase receipt as proof of purchase.