

## OTTOCAST Mini 3.0

# OTTOCAST Mini 3.0 Wireless CarPlay & Android Auto Adapter User Manual

Model: Mini 3.0

## 1. INTRODUCTION

The OTTOCAST Mini 3.0 is a compact 2-in-1 wireless adapter designed to convert your car's wired CarPlay or Android Auto system into a wireless experience. This device offers seamless connectivity, dual-phone memory, and high-speed dual-band WiFi for an enhanced in-car infotainment experience.



Image: The OTTOCAST Mini 3.0 Wireless CarPlay & Android Auto Adapter.

## 2. COMPATIBILITY REQUIREMENTS

To ensure proper functionality, your vehicle and smartphone must meet the following criteria:

- **Vehicle:** Must have factory-installed wired Apple CarPlay or Android Auto.
- **iPhone:** Requires iOS 10.0 or higher.
- **Android Phone:** Requires Android 11.0 or higher.

## Wireless CarPlay

For iPhone



Works with  
iPhone (iOS 10.0+)

## Wireless Android Auto

For Android



Works with  
Android (Android 11.0+)

## Supports over 98% car models



Image: Visual representation of car model and phone OS compatibility for the OTTOCAST Mini 3.0.

### 3. SETUP INSTRUCTIONS

Follow these steps for a quick and effortless setup:

1. **Connect the Adapter:** Plug the OTTOCAST Mini 3.0 adapter into your car's USB port. Use the included USB-A to USB-C adapter if your car has a USB-C port.

2. **Activate Phone Settings:** On your smartphone, turn on both Wi-Fi and Bluetooth.
3. **Pair via Bluetooth:** Search for and select the Bluetooth device named "AUTO2-xxxx" (where xxxx are unique symbols) on your phone. Confirm the authorization request on your phone to complete the pairing.
4. **CarPlay/Android Auto Launch:** After successful pairing, your car's infotainment system will automatically launch Wireless CarPlay or Android Auto.

## Sleek & Cooling Design

The sleek exterior designed to seamlessly match your car's interior and maintain optimal temperature for smooth, reliable performance.



Image: Step-by-step visual guide for connecting the OTTOCAST Mini 3.0 adapter.

## Setup Video Guide

Video: A detailed user guide for setting up the OTTOCAST Mini 3.0 adapter in a car. This video demonstrates the connection process and initial pairing steps.

## 4. OPERATING INSTRUCTIONS

Once connected, the OTTOCAST Mini 3.0 provides a seamless wireless experience:

- **Automatic Reconnection:** The adapter automatically reconnects to the last used phone within 5 seconds of starting the car. It also supports dual-phone memory, automatically switching to the second saved device if the primary is unavailable.
- **High-Speed Connectivity:** Utilizes 5GHz dual-band Wi-Fi for low latency, ensuring stable navigation, music streaming, and call quality.
- **Integrated Controls:** Maintain full functionality with your car's original controls, including steering wheel buttons, dashboard knob, touchscreen, and voice assistants (Siri/Google Assistant).
- **Superior Audio:** Experience Hi-Fi sound quality with reduced lag compared to standard Bluetooth car adapters.





Image: Hands-free control with smart voice assistance for safer driving.

Smaller,  
More  
stable

Ottocast Mini Cube

**MINI POT 3.0**

Wireless CarPlay and  
wireless Android Auto adapters

Auto  
Reconnect

Wireless CarPlay  
& Android Auto

Luxury Meets  
Precision Tech

High-gloss finish with a refined aluminum alloy  
body Blends perfectly with Your Interior

Mainstream Map

Make a Call

Siri /Google  
Control

Online Music

Image: The adapter automatically reconnects within 5 seconds after the first connection.

## 5. MAINTENANCE

To ensure optimal performance and longevity of your OTTOCAST Mini 3.0 adapter:

- **Software Updates (OTA):** The device supports Over-The-Air (OTA) upgrades. Regularly check for and install available firmware updates to benefit from new features, performance improvements, and bug fixes.
- **Keep Clean:** Gently wipe the adapter with a dry, soft cloth to remove dust or debris. Avoid using liquid cleaners.
- **Optimal Temperature:** The sleek design helps maintain an optimal temperature. Ensure the device is not obstructed or placed in areas with extreme heat to prevent overheating.



Image: The OTTOCAST Mini 3.0 supports online OTA upgrades for continuous improvement.

## 6. TROUBLESHOOTING

If you encounter issues with your OTTOCAST Mini 3.0, try the following solutions:

- **No Connection:**

- Ensure your car has factory-wired CarPlay/Android Auto.
- Verify Wi-Fi and Bluetooth are enabled on your phone.
- Unplug the adapter and plug it back in.
- Restart your phone and your car's infotainment system.

- **Intermittent Connection:**

- Check for any physical obstructions around the adapter or phone.
- Ensure your phone's operating system is up to date.
- Perform an OTA update on the OTTOCAST Mini 3.0 if available.

- **Audio Issues (e.g., buzzing):**

- Ensure the adapter is securely plugged into the USB port.
- Check for any electrical interference from other devices in the car.
- Test with a different USB port if available.

- **Dual-Phone Switching Issues:**

- Ensure both phones are properly paired and saved in the adapter's memory.
- Confirm only one phone is actively trying to connect at a time for initial connection.

## 7. SPECIFICATIONS

Feature	Detail
Model Number	Mini 3.0

Color	Silver
Package Dimensions	3.7 x 2.99 x 1.34 inches
Item Weight	1.44 ounces (0.04 Kilograms)
Compatible Devices	Android Phone, iPhone
Connector Type	USB (USB-A with A-to-C adapter included)
Manufacturer	OTTOCAST

## 8. WARRANTY AND SUPPORT

Your OTTOCAST Mini 3.0 adapter comes with comprehensive support:

- **Returns:** 30-day return policy.
- **Warranty:** 24-month warranty.
- **Support:** US-based customer support is available for assistance.
- **Online Resources:** For additional information and support, please visit the [OTTOCAST Store on Amazon](#).

