

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Hatteker](#) /

› [Hatteker Hair Trimmer-Clipper Guide Comb Set User Manual for RFC-69031 and RFC-69001](#)

Hatteker Guide Comb Set

Hatteker Hair Trimmer-Clipper Guide Comb Set User Manual

Model: Guide Comb Set for RFC-69031 and RFC-69001 Trimmers

Brand: Hatteker

INTRODUCTION

This manual provides instructions for the proper use and care of your Hatteker Guide Comb Set. These combs are designed to be used with Hatteker Hair Trimmer-Clipper models RFC-69031 and RFC-69001. Please read this manual thoroughly before first use and retain it for future reference.

SAFETY INFORMATION

- Keep out of reach of children.
- Always ensure the guide comb is securely attached to the trimmer before operation.
- Inspect combs for damage before each use. Do not use damaged combs.
- Refer to your Hatteker Hair Trimmer-Clipper manual for additional safety guidelines related to the trimmer itself.

PACKAGE CONTENTS

The Hatteker Guide Comb Set includes the following sizes:

- 3 mm Guide Comb
- 4-6 mm Guide Comb
- 7-9 mm Guide Comb
- 10-12 mm Guide Comb
- 16-18 mm Guide Comb
- 22-24 mm Guide Comb



This image displays the complete set of six Hatteker guide combs, ranging from smaller sizes with visible teeth to larger, more enclosed designs, each designed for specific hair lengths.

COMPATIBILITY

These guide combs are specifically designed for use with Hatteker Hair Trimmer-Clipper models RFC-69031 and RFC-69001. Ensure your trimmer model matches for proper fit and function. Using these combs with incompatible trimmers may result in improper attachment, damage to the comb or trimmer, or an unsatisfactory cutting experience.

INSTALLATION AND SETUP

- 1. Select Comb:** Choose the desired guide comb size based on the hair length you wish to achieve. The size is typically marked on the comb.
- 2. Attach Comb:** Align the guide comb with the trimmer blade. Gently push the comb onto the blade until it clicks securely into place. Ensure it is firmly seated and does not wobble.
- 3. Verify Attachment:** Before turning on the trimmer, lightly tug on the comb to confirm it is securely fastened. A properly attached comb will not easily detach.
- 4. Remove Comb:** To remove, gently pull the comb away from the trimmer blade. Avoid using excessive force to prevent damage to the comb or trimmer.

OPERATING INSTRUCTIONS

Once the guide comb is securely attached to your Hatteker trimmer (RFC-69031 or RFC-69001), you can proceed with trimming hair.

- Hair Preparation:** Ensure hair is clean and dry for best results, unless your trimmer manual specifies wet use.
- Starting Length:** If you are unsure about the desired length, always start with a longer guide comb size and gradually switch to shorter combs if needed.
- Trimming Technique:** Hold the trimmer with the comb flat against the head or body. Move the trimmer slowly and steadily against the direction of hair growth for an even cut. Overlap strokes to avoid missed spots.
- Cleaning During Use:** Periodically brush off accumulated hair from the comb and trimmer blade

during extended trimming sessions to maintain optimal performance.

Maintenance

Proper maintenance ensures the longevity and performance of your guide combs.

- **Cleaning After Each Use:** Remove the guide comb from the trimmer. Use a small cleaning brush (often included with trimmers) to remove any trapped hair from the comb's teeth and body.
- **Washing:** If necessary, rinse the guide comb under cool running water. Ensure all hair and debris are removed.
- **Drying:** Thoroughly dry the guide comb with a soft cloth or allow it to air dry completely before storing. Do not reattach a wet comb to your trimmer.
- **Storage:** Store the clean, dry guide combs in a safe place, away from direct sunlight, extreme temperatures, and potential damage.

Troubleshooting

- **Comb does not attach securely:** Ensure the comb is correctly aligned with the trimmer blade and pushed firmly until it clicks. Check for any debris obstructing the attachment points on both the comb and the trimmer.
- **Uneven cut:** Verify the comb is fully attached and not loose. Ensure you are moving the trimmer against the direction of hair growth consistently and overlapping your strokes. Clean the trimmer blade and comb for optimal performance, as clogged teeth can affect cutting.
- **Comb appears damaged:** If a comb is bent, cracked, or has broken teeth, discontinue use immediately. A damaged comb can lead to an uneven cut or potential skin irritation. Replace with a new comb from the set or a compatible replacement.

Specifications

- **Product Type:** Hair Trimmer Guide Comb Set
- **Manufacturer:** Hatteker
- **Compatible Trimmer Models:** Hatteker RFC-69031, Hatteker RFC-69001
- **Comb Sizes Included:** 3 mm, 4-6 mm, 7-9 mm, 10-12 mm, 16-18 mm, 22-24 mm
- **Package Dimensions:** 3.94 x 2.76 x 1.97 inches
- **Package Weight:** 7.05 ounces

Warranty and Support

For warranty information or product support regarding your Hatteker Guide Comb Set, please refer to the documentation provided with your Hatteker Hair Trimmer-Clipper or contact Hatteker customer service directly through their official website or contact channels.