

[Manuals.plus](#) /

› [Bathgate](#) /

› Bathgate Portable WiFi Router MF800 User Manual

Bathgate MF800

Bathgate Portable WiFi Router MF800 User Manual

Model: MF800 (XC11533)

1. PRODUCT OVERVIEW

The Bathgate Portable WiFi Router MF800 is a compact and lightweight 4G LTE mobile hotspot designed for travel and on-the-go internet access. It features a SIM card slot, allowing you to connect to the internet using a cellular data plan. This device supports up to 10 users simultaneously and is powered by a 2100mAh lithium-ion battery, offering extended standby time.

Mobile WiFi Router



The image shows a group of five young adults (three women and two men) sitting on a grassy lawn outdoors, smiling and using tablets. A white mobile WiFi router is shown in the foreground, with a blue Wi-Fi signal icon above it. The router has a black screen and a 'WiFi' button. Below the router, there are six icons and their corresponding specifications:

Icon	Specification
Wireless Portable	Wireless Portable
Supports 8 to 10 Users	Supports 8 to 10 Users
4G Fast internet Speed	4G Fast internet Speed
50 Mbps Upload Speed	50 Mbps Upload Speed
150 Mbps Download Speed	150 Mbps Download Speed
2100mAh Battery Capacity	2100mAh Battery Capacity

Image 1.1: The Bathgate Portable WiFi Router MF800 in use, highlighting its wireless portability, support for 8-10 users, 4G fast internet speed, 50 Mbps upload, 150 Mbps download, and 2100mAh battery capacity.

Instant Hotspot for Outdoor Travel




Image 1.2: The portable WiFi hotspot is suitable for various scenarios including outdoor activities, camping, beach, vehicles, caravan, and rural areas, providing instant internet access.

2. SETUP GUIDE

Follow these steps to set up your Bathgate Portable WiFi Router MF800:

- 1. Remove the Back Cover:** Locate the small opening in the bottom left corner of the back of the device. Carefully remove the back cover.
- 2. Insert SIM Card:** Remove the battery. Insert your activated SIM card into the designated SIM card slot. Ensure the SIM card is correctly oriented and fits securely within its holder to ensure proper recognition.
- 3. Reinsert Battery and Cover:** Place the original battery back into the device, ensuring the battery contacts align correctly. Replace the back cover.
- 4. Power On:** Press and hold the power button to turn on the device. Wait approximately one minute for the screen to illuminate and the device to initialize.
- 5. Access Network Information:** The default Wi-Fi network name (SSID) and password (WIFIKEY) are located on a sticker on the device itself, typically under the battery. Each device has unique account and password information.

Note: A SIM card is not included with the device and must be purchased separately from a mobile network provider.

Mobile WiFi Usage Tutorial

You will need to insert the SIM card to use it and the account and PIN are on the device (visible when you remove the battery) or on a sticker




Image 2.1: Visual guide for inserting the SIM card and accessing network credentials. Step 1 shows removing the cover and battery, Step 2 shows inserting the SIM card, Step 3 shows the device displaying SSID and password, and Step 4 shows multiple devices connected to the hotspot.

3. OPERATING INSTRUCTIONS

Once the device is powered on and a valid SIM card is inserted, you can connect your devices to the Wi-Fi network.

- **Connecting Devices:** On your smartphone, laptop, tablet, or other Wi-Fi enabled device, search for available Wi-Fi networks. Select the SSID (network name) found on your router's sticker. Enter the WIFIKEY (password) when prompted.
- **Multiple Connections:** The MF800 supports connecting up to 10 devices simultaneously, providing internet access for a small group or multiple personal devices.
- **Network Speed:** Experience download speeds of up to 150 Mbps and upload speeds of up to 50 Mbps, depending on your network provider's signal strength and coverage.
- **Battery Life:** The integrated 2100mAh battery provides reliable power for extended use, with up to 72 hours of standby time.
- **Compatibility:** The router is compatible with various operating systems, including Linux, Windows 7, Windows 8, and Windows 10.

Wide Compatibility

The account and password for each device are different.

Portable WiFi is mainly targeted at car users, business travelers and outdoor travelers, and can support up to 10 users. It supports Linux, Windows7, 8 and 10



Image 3.1: The router offers wide compatibility, supporting various devices such as laptops, smartphones, tablets, gaming consoles, desktops, and smartwatches.

4. MAINTENANCE

To ensure the longevity and optimal performance of your Bathgate Portable WiFi Router MF800, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the device. Avoid using liquid cleaners or abrasive materials.
- **Charging:** Charge the device using the provided charging cable. Avoid overcharging or completely draining the battery frequently to prolong its lifespan.
- **Storage:** When not in use for extended periods, store the router in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Physical Damage:** Protect the device from drops, impacts, and exposure to water or excessive moisture.

5. TROUBLESHOOTING

If you encounter issues with your Bathgate Portable WiFi Router MF800, try the following troubleshooting steps:

- **No Internet Connection:**
 - Ensure your SIM card is properly inserted and activated with a data plan.
 - Check if there is network coverage in your current location.
 - Restart the router by turning it off and then on again.
 - Verify that your connected device is using the correct Wi-Fi password.
- **Slow Connection Speed:**
 - Move to an area with better cellular signal strength.
 - Reduce the number of connected devices.
 - Ensure no background applications on your connected devices are consuming excessive bandwidth.
- **Device Not Powering On:**
 - Ensure the battery is charged. Connect the router to a power source using the charging cable.
 - Check if the battery is correctly inserted.

6. SPECIFICATIONS

Detailed technical specifications for the Bathgate Portable WiFi Router MF800:

Feature	Specification
Model	MF800 (XC11533)
Material	ABS
Color	White
Battery Type	2100mAh Li-battery (included)
4G LTE Frequency Bands	B1, B3, B5, B7, B8, B20, B40
3G UMTS WCDMA	B1
Peak Download Speed	150 Mbps
Peak Upload Speed	50 Mbps
Wi-Fi Standard	802.11 b/g/n
Max Users Supported	10
Connectivity Technology	Wi-Fi
Compatible Devices	Desktop, Laptop, Smartphone, Tablet
Operating System Compatibility	Linux, Windows 7, 8, 10
Package Dimensions	11.9 x 7.5 x 2.7 cm
Weight	100 g

Pocket WiFi Hotspot

Can be easily carried anywhere.




Image 6.1: The compact dimensions of the Bathgate Portable WiFi Router MF800, measuring 9.8cm (3.86in) in length and 5.8cm (2.28in) in width and height, making it highly portable.

7. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided with your purchase or contact the retailer where the product was acquired. Specific warranty terms and support channels may vary by region and retailer.