

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Inandon](#) /

› [InAndOn 4-in-1 Karaoke Machine User Manual: 21.5" HD Touchscreen KTV System](#)

Inandon B0FR9F52GR

InAndOn 4-in-1 Karaoke Machine User Manual

Model: B0FR9F52GR

[Introduction](#) [Safety](#) [Contents](#) [Overview](#) [Setup](#) [Operation](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#)

1. INTRODUCTION

Thank you for choosing the InAndOn 4-in-1 Karaoke Machine. This all-in-one system integrates a 21.5-inch HD touchscreen, dual speakers, and a mixer, providing a comprehensive KTV experience. This manual provides essential information for safe operation, setup, and maintenance of your device. Please read it thoroughly before use.

2. IMPORTANT SAFETY INFORMATION

- Power Source:** Use only the provided power adapter. Ensure the voltage matches your local power supply.
- Ventilation:** Do not block ventilation openings. Ensure adequate airflow around the unit to prevent overheating.
- Water and Moisture:** Keep the device away from water, rain, and high humidity. Do not operate with wet hands.
- Cleaning:** Disconnect from power before cleaning. Use a soft, dry cloth. Avoid liquid cleaners.
- Placement:** Place the unit on a stable, flat surface. Avoid direct sunlight, heat sources, or extreme temperatures.
- Servicing:** Do not attempt to repair the device yourself. Refer all servicing to qualified personnel.
- Microphones:** The wireless microphones are rechargeable. Use appropriate charging methods as described in this manual.

3. PACKAGE CONTENTS

Please check that all items are present in your package:

- InAndOn 4-in-1 Karaoke Machine (Main Unit with 21.5" HD Touchscreen)
- Floor Stand Components
- 2 x UHF Wireless Microphones
- Power Adapter
- User Manual (this document)
- Other accessories (e.g., audio cables, USB cable - if included)

4. PRODUCT OVERVIEW

4.1 Main Unit

The main unit features a 21.5-inch HD touchscreen for intuitive navigation and song selection. It integrates a karaoke system, mixer, and dual speakers for an immersive audio experience.




Figure 4.1: InAndOn 4-in-1 Karaoke Machine with two wireless microphones and floor stand.

4.2 Wireless Microphones

Two rechargeable UHF wireless microphones are included, designed for clear vocal pickup and stable connectivity. They feature durable metal mesh heads and adjustable UHF frequencies to minimize interference.

MULTIPLE CONNECTIONS

Choose songs easily via mobile/tablet/iPad, Karaoke app, or touchscreen for a faster, more convenient experience



Figure 4.2: Close-up view of the two InAndOn UHF wireless microphones.

4.3 Internal Components and Features

The system is powered by a dual-core DSP, runs on Android 10.0, and includes 2GB RAM with 32GB ROM, plus a 500GB hard disk for song storage. It supports both 2.4G and 5G WiFi for robust network connectivity.

INANDON ALL-IN-ONE KARAOKE MACHINE

Turn your living room into a private KTV - Unlimited songs, stunning HD, professional sound

 Dual-core DSP

 UHF Wireless Mics

 WiFi 2.4G & 5G

 Android 10.0

 2G RAM +32G ROM

 500GB Hard Disk




Figure 4.3: Overview of the internal components and key features.

5. SETUP GUIDE

5.1 Assembling the Floor Stand

1. Carefully unpack all components of the floor stand.
2. Attach the base to the main vertical pole using the provided screws.
3. Securely mount the karaoke machine unit onto the top of the vertical pole. Ensure all connections are tight and stable.

3IN1 KARAOKE PLAYER WITH FLOOR STAND

Touchscreen, Karaoke system, and mixer in one compact unit. Save space and easy control, connect to your speakers, and sing your heart out.



Figure 5.1: The InAndOn Karaoke Machine assembled on its floor stand.

5.2 Power Connection

1. Connect the power adapter to the DC input port on the back of the karaoke machine.
2. Plug the power adapter into a suitable electrical outlet.

5.3 Microphone Setup

1. Insert AA batteries into the wireless microphones or ensure they are charged if using rechargeable batteries.
2. The microphones should automatically pair with the main unit. If not, refer to the troubleshooting section for manual pairing instructions.

5.4 Connecting to External Audio (Optional)

For enhanced sound, connect the karaoke machine to active speakers or a soundbar using an appropriate audio cable (e.g., HDMI, RCA, or optical, depending on your external audio system's inputs and the machine's outputs).

5.5 Network Connection

1. Power on the device.
2. Navigate to the 'Settings' menu on the touchscreen.
3. Select 'Wi-Fi' and choose your desired network. Enter the password if prompted.

6. OPERATING INSTRUCTIONS

6.1 Powering On/Off

Press the power button located on the unit to turn it on or off. A short press typically puts it into standby, while a long press performs a full shutdown.

6.2 Touchscreen Navigation

The 21.5-inch HD touchscreen allows for intuitive control. Tap icons to select functions, swipe to scroll, and use pinch-to-zoom gestures where applicable.

20.5" HD TOUCH SCREEN

360° wide viewing with crystal-clear HD quality from every angle for a more lifelike playback experience




Figure 6.1: The 20.5-inch HD touchscreen in operation.

6.3 Song Selection and Playback

1. **Cloud Server:** Access over 650,000 songs with monthly updates. Navigate to the 'Cloud' section to browse and select songs.
2. **YouTube:** Use the integrated YouTube app to stream karaoke videos directly.
3. **Local Storage:** Play songs stored on the internal 500GB hard disk.
4. **USB Playback:** Connect a USB drive to play music or 4K movie files.

BUILT-IN PRO KARAOKE SYSTEM - TRUE KTV AT HOME

Original Vocal & Accompaniment Modes – Switch easily between singing with the artist or performing solo with instrumental tracks



Figure 6.2: Karaoke system interface for song selection.

6.4 Microphone Usage

- **Volume Control:** Adjust microphone volume using the on-screen controls or physical knobs if available.
- **Vocal/Accompaniment Modes:** Switch between original vocal and accompaniment modes for songs from the built-in hard disk or cloud music libraries.
- **Effects:** Apply echo or other vocal effects through the system settings.

6.5 Multiple Connection Options

Control song selection and playback using the touchscreen, a mobile phone, tablet, or the dedicated Karaoke app.

SCREEN PROJECTION ACROSS DEVICES

Sync the Screen to the TV via HDMI Or APP




Figure 6.3: Multiple ways to connect and control the karaoke machine.

6.6 Screen Projection

Sync the screen to an external TV or monitor via HDMI or through a compatible app for a larger display.

UPGRADED UHF PROFESSIONAL WIRELESS MICROPHONE

Crisp Sound, No Dropouts – Sing with Confidence



Durable Metal Mesh Head:

Strong, drop-resistant, and built to last



Battery Powered :

Compatible with AA batteries or rechargeable batteries



Adjustable UHF Frequencies:

Multiple channels to avoid interference and ensure stable transmission



Figure 6.4: Screen projection to an external display.

6.7 Language Support

The system supports over 16 languages. Change the language setting in the system menu to your preferred language.

7. MAINTENANCE

- Cleaning the Screen:** Use a soft, lint-free cloth specifically designed for electronic screens. Do not use abrasive cleaners or sprays directly on the screen.
- General Cleaning:** Wipe the exterior of the unit and microphones with a dry, soft cloth.
- Storage:** When not in use for extended periods, store the machine in a cool, dry place, away from direct sunlight and extreme temperatures.
- Software Updates:** Periodically check for system software updates through the settings menu to ensure optimal performance and access to new features.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power cable not connected; power outlet faulty.	Ensure power cable is securely connected. Try a different power outlet.
No sound from speakers	Volume too low; external speakers not connected/powered.	Increase volume. Check connections to external speakers and ensure they are powered on.
Microphone not working	Microphone off; low battery; not paired.	Turn on microphone. Replace/recharge batteries. Re-pair microphones via system settings.

Problem	Possible Cause	Solution
Cannot connect to Wi-Fi	Incorrect password; out of range; router issue.	Verify Wi-Fi password. Move closer to router. Restart router.
Screen projection not working	HDMI cable loose/faulty; incorrect input on TV.	Check HDMI cable connection. Select correct HDMI input on your TV.

9. SPECIFICATIONS

- Model:** B0FR9F52GR
- Display:** 21.5-inch HD Touchscreen
- Operating System:** Android 10.0
- Processor:** Dual-core DSP
- Memory:** 2GB RAM + 32GB ROM
- Storage:** 500GB Hard Disk
- Connectivity:** Wi-Fi (2.4G & 5G), HDMI
- Microphones:** 2 x UHF Wireless Microphones
- Speaker Count:** 9 (integrated)
- Power Source:** Plug In Electric
- Product Dimensions:** 19.29 x 30.31 x 5.91 inches

10. WARRANTY AND SUPPORT

Your InAndOn Karaoke Machine is covered by a limited manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions. For technical support, troubleshooting assistance, or warranty claims, please contact InAndOn customer service through the contact information provided on the official InAndOn website or your purchase platform.

© 2025 InAndOn. All rights reserved.

Related Documents - B0FR9F52GR

	<p>KOD Karaoke Machine KV-904S Operation Guide</p> <p>Comprehensive operation guide for the KOD Karaoke Machine KV-904S, covering functions, setup, song ordering, recording, network connectivity, troubleshooting, and specifications. Learn how to use your 5-in-1 Karaoke Player.</p>
	<p>Indon Professional KTV Equipment for Karaoke</p> <p>Explore Indon's professional KTV equipment designed for immersive karaoke experiences. High-quality audio and visual solutions for entertainment.</p>