



Manuals.plus /

- › FOHERE /
- › FOHERE Electric Towel Warmer NJ5EDB User Manual

## FOHERE NJ5EDB

# FOHERE Electric Towel Warmer NJ5EDB User Manual

Model: NJ5EDB

## INTRODUCTION

---

Thank you for purchasing the FOHERE Electric Towel Warmer. This manual provides essential information for the safe and efficient operation, installation, and maintenance of your new appliance. Please read these instructions thoroughly before use and retain them for future reference.

## IMPORTANT SAFETY INSTRUCTIONS

---

To reduce the risk of fire, electric shock, or injury, always follow basic safety precautions when using electrical appliances. This appliance is intended for domestic use only.

- Read all instructions before using the towel warmer.
- Do not immerse the appliance in water or other liquids.
- Ensure the power supply voltage matches the rating label on the appliance.
- Do not operate the appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Keep the cord away from heated surfaces.
- Unplug from outlet when not in use and before cleaning.
- Do not allow children to operate or play with the appliance.
- This appliance has an IPX4 waterproof rating, making it safe for bathroom use. However, avoid direct water jets.
- Only use the appliance for its intended purpose as described in this manual.

## PRODUCT OVERVIEW AND FEATURES

---

The FOHERE Electric Towel Warmer is designed to efficiently dry and warm towels and other fabrics, enhancing comfort and hygiene in your bathroom.

- **Efficient Heating:** Features 10 heating bars and an updated 70mm wide heating surface for quick and even heat distribution. Reaches desired temperature in 1-3 minutes.
- **Customizable Settings:** Equipped with a 0-23 hour timing function and 6 integrated preset modes (Comfort,

Economic, Anti-Freeze, Stand-By, 1H, 2H).

- **Programmable Heating:** Offers 7 independent heating programs that can be adjusted to suit your schedule and preferences.
- **Durable Construction:** Made from aerospace-grade aluminum alloy with an anti-corrosion layer and eco-friendly spray layer, ensuring robustness and rust-proof performance.
- **Waterproof Design:** IPX4 rated for safe use in bathroom environments.
- **Smart Control:** Intuitive LED control panel for precise temperature and timer adjustments.
- **Versatile Use:** Suitable for drying and warming various fabrics including towels, bathrobes, baby clothes, and underwear.



Image: The towel warmer demonstrating fast and uniform heating, with steam rising from towels. Icons indicate saving time, even heat dissipation, overheat protection, and sterilization/disinfection.



Image: A comparison illustrating the faster heating performance of the FOHERE towel warmer, reaching 50°C in approximately 2 minutes and 65°C in about 3 minutes.




Image: A technical diagram displaying temperature graphs and specifications, indicating temperature ranges of 40-45°C and 50-55°C with corresponding performance curves.



Image: The towel warmer shown with various items, including clothes, towels, bathrobes, and socks, demonstrating its suitability for daily care for the whole family.



Image: A cutaway diagram showing the Aerospace-Grade Aluminium Alloy Layer, Anti-Corrosion Layer, and Eco-Friendly Spray Layer of the towel warmer's construction.



Image: The towel warmer shown with water splashing, highlighting its IPX4 waterproof rating for safe use in wet environments.

## SPECIFICATIONS

Brand	FOHERE
Model	NJ5EDB
Color	White
Product Dimensions	60 x 9 x 101 cm
Voltage	220 Volt
Item Weight	6.4 Kilograms
Waterproof Rating	IPX4

## SETUP AND INSTALLATION

The FOHERE Electric Towel Warmer offers two installation options: plug-in or hardwired. Choose the method that best suits your electrical setup. Installation typically involves 3-4 steps.

### Included Components:

- Wall Mount Screws x 4
- Wall Mount Bracket x 4
- Wall Plugs x 4
- Screws x 5

### Installation Options:


1. **Plug-In Installation:** This method does not require an electrician. Simply mount the unit to the wall and plug it into a suitable electrical outlet. Ensure the outlet is within reach of the power cord and is rated for the appliance's voltage.
2. **Hardwired Installation:** This method requires direct wiring into your home's electrical system. *An electrician is recommended for this type of installation to ensure safety and compliance with local electrical codes.*

Refer to the detailed installation diagrams and instructions provided in the separate installation guide for step-by-step

procedures.



Image: Illustration of the two available mounting options: Plug-In, which does not require an electrician, and Hardwired, for which an electrician is recommended.



## Individual 7 days Heating Program

Freely define heating conditions for the next 7 days.

Image: A diagram displaying the dimensions of the towel warmer (60cm width, 110cm height) and a list of included accessories: wall mount screws, wall mount brackets, wall plugs, and additional screws.

## OPERATING INSTRUCTIONS

The FOHERE Electric Towel Warmer features a smart LED control panel for easy operation.

### Control Panel Overview:




Image: A detailed view of the smart touch control panel, showing the LED display with temperature reading and control buttons (+, -, Power, OK, M).

The LED display shows the current temperature and settings. Use the touch buttons to navigate and adjust settings.

### Basic Operation:

1. **Power On/Off:** Press the Power button ( ) to turn the unit on or off.
2. **Adjusting Temperature:** Use the '+' and '-' buttons to increase or decrease the desired temperature. The temperature range is typically between 40°C and 65°C.
3. **Setting the Timer:** The unit features a 0-23 hour timing function. Press the 'M' button to cycle through modes until the timer setting is displayed. Use '+' and '-' to set the desired operating duration.
4. **Selecting Preset Modes:** The towel warmer includes 6 preset modes:
  - **Comfort Mode:** Maintains a comfortable temperature.
  - **Economic Mode:** Energy-saving operation.
  - **Anti-Freeze Mode:** Prevents freezing in cold environments.
  - **Stand-By Mode:** Low power consumption.
  - **1H Mode:** Operates for 1 hour.
  - **2H Mode:** Operates for 2 hours.

Press the 'M' button to cycle through these modes.




Image: The towel warmer with an overlay highlighting the 6 preset modes (Comfort, Economic, Anti-Freeze, Stand-By, 1H, 2H) and the 0-23 hour timing function.



Image: Six individual displays of the control panel, each showing a different preset mode (Comfort, Economic, Anti-Freeze, Stand-By, 1H, 2H) with their respective temperature settings.

### Custom 7-Day Heating Program:

The towel warmer allows you to set up to 7 independent heating programs, customizing the heating schedule for each day of the week. This feature provides flexibility to match your daily routine.

1. Access the programming menu via the 'M' button or a specific combination (refer to the full installation guide for exact steps).
2. Select the day you wish to program (e.g., Monday).
3. Set the desired temperature and operating times for different periods within that day.
4. Repeat for other days as needed.



Image: A series of graphs showing customizable temperature profiles over 24 hours for each day of the week (Monday to Sunday), demonstrating the individual 7-day heating program feature.

## MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your FOHERE Electric Towel Warmer.

- **Cleaning:** Before cleaning, ensure the unit is unplugged and completely cool. Wipe the surface with a soft, damp cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish and protective layers.
- **Rust Prevention:** The towel warmer is constructed with aerospace-grade aluminum alloy and an anti-corrosion layer, making it rust-proof. Regular cleaning helps maintain its appearance and integrity.
- **Storage:** If storing the unit for an extended period, ensure it is clean, dry, and stored in a cool, dry place.

## TROUBLESHOOTING

---

If you encounter issues with your towel warmer, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Unit does not power on.	No power supply; unit unplugged; power button not pressed.	Check if the unit is properly plugged into a working outlet. Press the power button. Check circuit breaker.
Unit is not heating.	Temperature setting too low; timer not set correctly; unit in standby mode.	Increase the temperature setting. Verify timer settings. Ensure the unit is not in standby or anti-freeze mode if heating is desired.
Display is not working.	Power issue; display malfunction.	Check power supply. If power is present and the display remains off, contact customer support.

If the problem persists after attempting these solutions, please contact FOHERE customer support for assistance.

## WARRANTY AND CUSTOMER SUPPORT

---

For warranty information, product support, or any questions not covered in this manual, please refer to the warranty card included with your purchase or visit the official FOHERE website. You may also contact FOHERE customer service directly for assistance.

Please have your model number (NJ5EDB) and purchase date available when contacting support.