

ZIUTY T21

ZIUTY T21 Wireless Earbuds Instruction Manual

Model: T21

1. INTRODUCTION

The ZIUTY T21 Wireless Earbuds are designed to provide a high-quality audio experience with advanced features. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance and user satisfaction.

Key features include Hybrid Active Noise Cancellation (ANC), Environmental Noise Cancellation (ENC) for clear calls, a multifunctional touchscreen charging case, 40-hour total playtime, IPX7 waterproof rating, and Bluetooth 5.3 connectivity.

2. WHAT'S IN THE BOX

Carefully unpack your ZIUTY T21 Wireless Earbuds package and ensure all items are present:

- T21 Wireless Earbuds
- Wireless Charging Case with Touchscreen
- USB-C Charging Cable
- Eartips (S/M/L sizes)
- User Manual

Method for the problem of volume and charging

Use an alcohol pad to clean the charging contacts and ear tip mesh—removing dust or earwax that might be affecting charging or sound volume.




Image: The ZIUTY T21 Wireless Earbuds package contents, showing the earbuds, charging case, USB-C cable, and different sized eartips.

3. SETUP

3.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and charging case. The case provides a total of 40 hours of playtime, with the earbuds offering up to 8 hours on a single charge. A 10-minute quick charge can provide 2 hours of music playback.

Enjoy Non-Stop Music Delight

Enjoy your go-to tracks for up to 8 hours straight, then stretch your listening to an impressive 40 hours total with the charging case.



Image: The ZIUTY T21 earbuds and charging case, highlighting the 40-hour total battery life.

Your browser does not support the video tag.

Video: An official product video demonstrating the touchscreen features and 40-hour playtime of the ZIUTY T21 wireless earbuds.

3.2 Pairing with Your Device

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for available Bluetooth devices and select "T21" from the list.
4. Once connected, you will hear a voice prompt confirming the connection.

The ZIUTY T21 earbuds utilize Bluetooth 5.3 for a stable and efficient wireless connection.



Version 5.3

Earbuds feature Bluetooth 5.3 for faster, stabler connections—letting you focus on music /calls and enjoy free listening at work or while exercising

Image: The ZIUTY T21 earbuds connecting to a smartphone, illustrating the quick and stable Bluetooth 5.3 connection.

3.3 Proper Fit and Comfort

For optimal sound quality and comfort, choose the correct size eartips. The earbuds come with S, M, and L sizes. Insert the earbuds gently into your ears and twist slightly to secure them. The lightweight design ensures comfort during extended wear.

Comfortable and Stable Design

3 sizes of eartips adapt to all people's ear canals



Image: Different eartip sizes (S, M, L) and an earbud properly fitted in an ear, emphasizing comfort and stability.

4. OPERATING INSTRUCTIONS

4.1 Touchscreen Case Functions

The charging case features a responsive touchscreen that provides access to various functions without needing your phone:

- **Music Control:** Play/pause, skip tracks (next/previous).
- **Volume Control:** Adjust playback volume.
- **Noise Reduction:** Switch between ANC, Transparency, and Normal modes.
- **Light Level:** Adjust screen brightness.
- **Equalizer (EQ):** Select from 5 preset EQ modes (Normal, Rock, Classic, Pop, Jazz).
- **Find My Earphone:** Locate misplaced earbuds by activating an audible signal.

- **Remote Camera Control:** Trigger your phone's camera shutter remotely.
- **Screen Lock:** Lock the touchscreen to prevent accidental touches.
- **Language Switch:** Change the interface language.
- **Flashlight:** Activate a built-in flashlight.

Multi-Function LCD Touch Screen

12 functional modes, 16 language options,
providing you with a rich and enjoyable usage experience




Image: The ZIUTY T21 charging case touchscreen displaying multiple functional modes and settings.

4.2 Earbud Touch Controls

The earbuds themselves feature touch-sensitive areas for quick control:

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Volume Up:** Triple tap on the right earbud.
- **Volume Down:** Triple tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Press and hold either earbud.
- **Activate Voice Assistant:** Press and hold for 2 seconds on either earbud.
- **Switch ANC/Transparency/Normal Mode:** Press and hold for 3 seconds on either earbud.

40 Hours Playtime

Long-lasting battery life ensures your continuous use throughout the day.

8 single charge

40 With Charging case



Image: A visual guide to the smart touch controls on the ZIUTY T21 earbuds.

4.3 Noise Control (ANC & Transparency Mode)

The ZIUTY T21 earbuds offer versatile noise control options:

- **Hybrid Active Noise Cancellation (ANC):** Blocks up to 40dB of ambient noise, providing an immersive listening experience. Ideal for noisy environments.
- **Transparency Mode:** Allows you to hear your surroundings clearly without removing the earbuds, enhancing

awareness and safety.

- **Normal Mode:** Standard audio playback without noise cancellation or transparency.

Switch between these modes using the touchscreen on the charging case or the touch controls on the earbuds.

Active Noise-Cancelling

Boasting ANC+ENC dual noise reduction!
Enjoy immersive music undisturbed and
crystal-clear calls.



Image: A visual representation of the Active Noise Cancellation feature, demonstrating how external noise is reduced.

4.4 Studio-Quality Sound with EQ Presets

Equipped with large 14.2mm dynamic drivers, the earbuds deliver powerful bass and balanced highs. Customize your audio experience with 5 Equalizer (EQ) presets available via the touchscreen case:

- Normal
- Rock
- Classic
- Pop
- Jazz

5 EQ Modes

Discover your perfect sound right now,
dive deep into every beat.



Image: The 5 EQ modes available on the ZIUTY T21 earbuds for personalized sound quality.

4.5 Crystal-Clear Calls

The dual-ENC microphones are designed to eliminate up to 98% of background noise, ensuring your voice is transmitted clearly during phone calls, even in busy environments.

Superior Call Clarity

With built-in mics and smart noise reduction, these wireless Bluetooth earbuds deliver crisp calls—cutting through background noise (busy cafes, crowded streets) for seamless chats.



Image: The ENC (Environmental Noise Cancellation) feature ensuring clear calls in noisy settings.

5. MAINTENANCE

5.1 Cleaning

To maintain optimal performance and sound quality, regularly clean the earbuds and charging case. Use an alcohol pad to gently clean the charging contacts on both the earbuds and inside the case. Also, clean the ear tip mesh to remove any dust or earwax that might affect sound volume or charging.

Method for the problem of volume and charging

Use an alcohol pad to clean the charging contacts and ear tip mesh—removing dust or earwax that might be affecting charging or sound volume.




Image: Instructions for cleaning the earbuds and charging case to ensure proper function.

5.2 Water Resistance

The ZIUTY T21 Wireless Earbuds have an IPX7 waterproof rating, meaning they can withstand sweat and splashes. They are suitable for workouts and outdoor activities. However, they are not designed for swimming or prolonged submersion in water.

IPX7 Waterproof

IPX7 water resistance shields these true wireless Bluetooth earbuds, ensuring that you stay immersed without wet worries.



Image: The ZIUTY T21 earbuds demonstrating their IPX7 water resistance.

5.3 Earbud Removal Gesture

To easily remove the earbuds from the charging case, follow these steps:

1. Grasp the earbud from the side, avoiding direct pressure on the touch control area.
2. Gently lift and pull the earbud upwards and outwards from its slot.

Easy Removal Gesture

Please follow the gestures shown in the following two pictures to easily take out the earbuds.




Image: A visual guide on the proper technique for removing earbuds from the charging case.

6. TROUBLESHOOTING

If you encounter any issues with your ZIUTY T21 Wireless Earbuds, try the following common solutions:

- **No Sound:** Ensure earbuds are charged, properly paired, and volume is adjusted on both the earbuds and your device.
- **Connection Issues:** Turn off and on Bluetooth on your device, then re-pair the earbuds. Ensure no other devices are interfering.
- **Charging Problems:** Clean the charging contacts on both earbuds and the case with an alcohol pad. Ensure the USB-C cable is securely connected.
- **Earbuds Lost:** Use the "Find My Earphone" feature on the charging case touchscreen to emit an audible signal from the misplaced earbud.

Never Lose Your Earbuds Again

Thanks to the charging case's earbud-finding feature, you can track down your buds in seconds.



Image: Demonstrating the 'Find My Earphone' feature on the touchscreen case to locate a lost earbud.

7. SPECIFICATIONS

Brand	ZIUTY
Model Number	T21
Connectivity Technology	Wireless (Bluetooth 5.3)
Bluetooth Range	15 Meters
Ear Placement	In Ear
Noise Control	Active Noise Cancellation (ANC)
Audio Driver Size	14.2 Millimeters
Frequency Response	20Hz - 20,000Hz
Sensitivity	107 dB
Impedance	32 Ohms
Audio Latency	55 Milliseconds
Battery Average Life	40 Hours (with charging case)
Battery Charge Time	1.5 Hours
Water Resistance Level	IPX7
Control Type	Touch Control
Material	Acrylonitrile Butadiene Styrene (ABS)

8. WARRANTY AND SUPPORT

The ZIUTY T21 Wireless Earbuds come with a **1-Year Warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use.

For warranty claims, technical support, or any questions regarding your product, please contact ZIUTY customer service through the retailer where you purchased the product or visit the official ZIUTY website for contact information. Please retain your proof of purchase for warranty validation.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question