Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Mojgar MJ-845

Mojgar 2-inch Clear Ice Square Maker Machine MJ-845 User Manual

Model: MJ-845

1. Introduction

Thank you for choosing the Mojgar 2-inch Clear Ice Square Maker Machine, Model MJ-845. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new ice maker. Please read these instructions thoroughly before use and retain them for future reference.

2. Safety Instructions

To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions:

- Ensure the power supply matches the voltage requirements specified on the appliance label.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Unplug the ice maker from the outlet when not in use, before cleaning, or during maintenance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Keep the appliance away from heat sources and direct sunlight.
- Ensure adequate ventilation around the unit. Maintain a minimum of 6 inches (15 cm) clearance on all sides.
- Use only potable water in the ice maker.
- This appliance is for household use only.

3. Product Overview

The Mojgar MJ-845 is designed to produce crystal-clear, slow-melting 2-inch square ice cubes. It features an efficient ice-making system, automatic cleaning, and quiet operation.

Key Features:

- **Crystal Clear Ice:** Produces high-density, bubble-free ice squares that melt slowly.
- **High Efficiency:** Makes 3 ice squares in 20-40 minutes, with a daily production capacity of up to 200 ice squares.

- **Automatic Cleaning:** A 3-minute deep cleaning cycle ensures hygiene and convenience.
- **Low Noise Operation:** Operates below 35dB for a quiet environment.
- **Transparent Door:** Allows easy monitoring of ice production and storage.
- **Ice Basket Capacity:** Stores up to 20 ice squares.

Components:

- Ice Maker Unit
- Ice Basket (Pull-out drawer)
- Ice Scoop
- Drain Plug
- LCD Display Panel



Figure 3.1: Mojgar MJ-845 Ice Maker main unit.



Figure 3.2: Pull-out drawers for easy ice retrieval and storage.



Figure 3.3: LCD Display showing operational status.

4. Setup

1. **Unpacking:** Carefully remove the ice maker from its packaging. Remove any positioning tape or protective materials.
2. **Placement:** Place the ice maker on a stable, level surface, away from direct sunlight and heat sources. Ensure there is at least 6 inches (15 cm) of clearance around the unit for proper ventilation. The unit features bottom anti-slip pads for stability.
3. **Initial Cleaning:** Before first use, wipe the interior of the unit with a soft cloth and mild detergent. Rinse thoroughly and drain any water. Wash the ice basket and scoop with warm, soapy water.
4. **Water Filling:** Open the water reservoir lid and fill with potable water up to the MAX fill line. Do not overfill. Using filtered or purified water is recommended for optimal ice quality.
5. **Power Connection:** Plug the power cord into a grounded electrical outlet.



Figure 4.1: Bottom anti-slip pads for secure placement.

5. Operating Instructions

1. **Power On:** Press the Power button on the control panel to turn on the ice maker. The LCD display will illuminate.
2. **Ice Making Cycle:** The machine will automatically begin the ice-making process. The first batch of 3 ice squares typically takes 20-40 minutes. Subsequent batches may be faster.
3. **Monitoring Ice:** The transparent door allows you to observe the ice production. The ice basket can hold approximately 20 ice squares.
4. **Ice Full Indicator:** When the ice basket is full, the machine will pause ice production and an indicator light on the LCD display will illuminate. Remove ice from the basket to resume production.
5. **Add Water Indicator:** If the water level in the reservoir is too low, the machine will pause and an indicator light will prompt you to add more water.
6. **Power Off:** Press the Power button again to turn off the ice maker.



Figure 5.1: The ice maker produces ice efficiently for immediate use.



Figure 5.2: Enjoy chilled beverages with freshly made ice.

6. Maintenance and Cleaning

Automatic Cleaning Function:

The Mojgar MJ-845 features an automatic cleaning mode for convenience.

1. Ensure the water reservoir is filled with clean water.
2. Press and hold the dedicated cleaning button (or Power button for 5 seconds, refer to your specific unit's controls) on the control panel.
3. The machine will initiate a 3-minute deep cleaning cycle.
4. After the cycle, drain the water as described in the manual cleaning section.



Figure 6.1: Self-cleaning mode for maintaining hygiene.

Manual Cleaning:

Regular manual cleaning is recommended to ensure optimal performance and hygiene.

- **Drain Water:** Unplug the unit. Locate the drain hole at the bottom of the machine. Open the drain plug to allow water to drain automatically into a suitable container.
- **Clean Interior:** Wipe the interior surfaces, including the water reservoir and ice-making components, with a soft cloth dampened with a mild, food-safe cleaning solution.
- **Clean Ice Basket & Scoop:** Wash the ice basket and scoop with warm, soapy water, rinse thoroughly, and dry before returning to the unit.
- **Exterior Cleaning:** Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners.
- **Drying:** Ensure all parts are completely dry before reassembling and storing or operating the unit.




Figure 6.2: Easy-to-drain design for convenient water removal.

7. Troubleshooting

If you encounter issues with your ice maker, refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
Ice maker not turning on	No power supply	Check if the power cord is securely plugged into a working outlet.
No ice production	Insufficient water in reservoir	Add water to the reservoir up to the MAX fill line.
Ice is cloudy	Mineral content in water	Use filtered or purified water for clearer ice. Perform a cleaning cycle.
Ice production is slow	High ambient temperature; Poor ventilation	Ensure the unit is in a cool, well-ventilated area. Maintain proper clearance around the machine.
Ice full indicator remains on	Ice basket is full or sensor is blocked	Remove ice from the basket. Check if the ice sensor is clear of obstructions.

8. Specifications

Feature	Specification
Brand	Mojgar
Model Name	MJ-845
Product Dimensions (D x W x H)	9.45" x 15.04" x 14.96"
Capacity	2 Liters (Water Reservoir)
Refrigerant	R290a
Item Weight	23.6 pounds
Daily Ice Production	Up to 200 ice squares
Noise Level	Below 35dB

9. Warranty and Support

Warranty Information:

This Mojgar ice maker comes with a**5-year warranty** from the date of purchase, covering manufacturing defects under normal use. Please retain your proof of purchase for warranty claims.

Customer Support:

For any questions, technical assistance, or warranty claims, please contact Mojgar customer service. We offer**24-hour customer service** to ensure your satisfaction.
Contact information can typically be found on the product packaging or the official Mojgar website.

© 2025 Mojgar. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FRFMJYZ8

More documents and user manuals: **https://manuals.plus/**