Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TIMU M9

TIMU M9 Portable Bluetooth Speaker User Manual

Model: M9 | Brand: TIMU

Introduction

Thank you for choosing the TIMU M9 Portable Bluetooth Speaker. This manual provides essential information for safe and efficient use of your device. Please read it thoroughly before operation and keep it for future reference.



Image: The TIMU M9 Portable Bluetooth Speaker, a compact device designed for powerful audio on the go.

What's in the Box

Verify that all items are present in your package:

- TIMU M9 Bluetooth Speaker x1
- Type-C Charging Cable x1
- User Manual x1

Product Overview

Speaker Features

- **Powerful 15W Stereo Sound:** Delivers clear and robust audio.

- **Bluetooth 5.4 Connectivity:** Ensures fast, stable, and wide-range wireless connection.
- **IPX7 Waterproof Rating:** Protected against immersion in water up to 1 meter for 30 minutes.
- **20 Hours Playtime:** Extended battery life for continuous music enjoyment.
- **TWS (True Wireless Stereo) Pairing:** Connect two M9 speakers for an immersive stereo experience.
- **Digital Display:** Shows battery status, volume, and mode at a glance.
- **Multiple Playback Modes:** Supports Bluetooth, TF Card, USB Drive, and FM Radio.
- **Portable Design:** Lightweight with a durable metal ring for easy carrying.

Button Functions

Familiarize yourself with the control buttons located on the top of the speaker:



Image: Button layout and their corresponding functions on the TIMU M9 speaker.

Button	Short Press	Long Press
Power Button ( )	Power On/Off	Power On/Off
Volume Down (-)	Decrease Volume	Previous Track
Play/Pause (▶)	Play/Pause Music	Disconnect/Reconnect Bluetooth
Volume Up (+)	Increase Volume	Next Track
Mode (M)	Switch Mode (Bluetooth, FM Radio, TF Card, USB)	(No specific function)

Ports

The speaker features a Type-C charging port, a USB port for playback, and a TF card slot.



Image: Connectivity ports on the TIMU M9 speaker, including Type-C, USB, and TF card slot.

Setup

Charging the Speaker

1. Connect the provided Type-C charging cable to the speaker's Type-C port.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The digital display will show the battery charging status.
4. Charge the speaker fully before first use (approximately 3-4 hours).



Image: The digital display shows real-time battery percentage, ensuring you know when to recharge.

Operating Instructions

Power On/Off

- **To Power On:** Long press the Power button () until the digital display lights up.
- **To Power Off:** Long press the Power button () again until the display turns off.

Bluetooth Pairing

1. Power on the speaker. It will automatically enter Bluetooth pairing mode, indicated by a flashing 'BT' on the digital display.
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "TIMU M9" from the list of devices.
4. Once connected, the 'BT' indicator on the speaker's display will stop flashing and remain solid.
5. The speaker is now ready to play audio from your device.



Image: The TIMU M9 speaker seamlessly connects to a smartphone for wireless audio streaming.

TWS (True Wireless Stereo) Pairing

To achieve a true stereo sound experience, you can pair two TIMU M9 speakers together:

1. Ensure both TIMU M9 speakers are powered on and not connected to any Bluetooth device.
2. On one speaker (this will be the primary speaker), long press the Play/Pause button (⏯) for 3 seconds. You will hear a prompt indicating TWS pairing mode.
3. The two speakers will automatically search for and connect to each other. Once connected, you will hear a

confirmation tone.

4. Now, connect your device to the primary speaker via Bluetooth as described in the "Bluetooth Pairing" section.
5. Audio will now play in stereo through both speakers.



Image: Two TIMU M9 speakers paired together for an enhanced stereo audio experience.

Switching Playback Modes (FM Radio, TF Card, USB)

The TIMU M9 supports multiple audio sources. Press the 'M' button to cycle through the available modes:

- **Bluetooth Mode:** Default mode after power-on.
- **FM Radio Mode:**
    1. Press the 'M' button to switch to FM Radio mode. The display will show the frequency.
    2. Long press the Play/Pause button (▶) to automatically scan and save available FM stations.
    3. Use the Volume Up (+) and Volume Down (-) buttons (short press) to adjust volume, or long press to switch between saved stations.
- **TF Card Mode:**
    1. Insert a TF (MicroSD) card with audio files into the TF card slot.
    2. Press the 'M' button until the speaker enters TF Card mode. It will automatically start playing.
- **USB Drive Mode:**
    1. Insert a USB flash drive with audio files into the USB port.
    2. Press the 'M' button until the speaker enters USB Drive mode. It will automatically start playing.



Image: The TIMU M9 offers versatile playback options, including Bluetooth, USB, TF card, and FM radio.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the speaker. Do not use abrasive cleaners or solvents.
- **Water Exposure:** While IPX7 waterproof, ensure the charging port cover is securely closed before exposing the speaker to water. After water exposure, wipe the speaker dry.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the speaker frequently. Recharge it regularly.



Image: The TIMU M9 speaker's IPX7 rating allows it to be submerged in water without damage, making it ideal for use in wet environments.

Troubleshooting

Problem	Possible Solution
Speaker does not power on.	Ensure the speaker is charged. Connect it to a power source using the Type-C cable.

Problem	Possible Solution
Cannot pair via Bluetooth.	◦ Ensure the speaker is in Bluetooth pairing mode (flashing 'BT'). ◦ Make sure Bluetooth is enabled on your device. ◦ Move the speaker closer to your device. ◦ Forget "TIMU M9" from your device's Bluetooth list and try pairing again. ◦ Long press the Play/Pause button on the speaker to disconnect/reconnect Bluetooth.
No sound or low volume.	◦ Increase the volume on both the speaker and your connected device. ◦ Ensure the speaker is correctly paired and playing from the selected source.
TWS pairing fails.	◦ Ensure both speakers are powered on and not connected to any other Bluetooth device. ◦ Follow the TWS pairing steps carefully, starting with a long press on the Play/Pause button of one speaker.
FM radio reception is poor.	◦ Move the speaker to an open area, away from obstructions or interference. ◦ Perform an auto-scan for stations again.

Specifications

Feature	Detail
Brand	TIMU
Model Name	M9
Speaker Output Power	15 Watts
Connectivity Technology	Bluetooth 5.4
Audio Output Mode	Stereo
Speaker Type	Portable Speaker
Waterproof Rating	IPX7
Battery Life	Up to 20 Hours
Battery Capacity	4000 mAh
Bluetooth Range	Up to 30 Meters
Driver Size	42 mm
Item Dimensions (DxWxH)	10 x 5 x 5 cm
Power Source	Battery Powered
Supported Playback	Bluetooth, TF Card, USB Drive, FM Radio

Warranty and Support

The TIMU M9 Portable Bluetooth Speaker comes with a **1-year warranty** from the date of purchase.
If you encounter any issues or have questions regarding your product, please contact the seller or manufacturer for assistance. Please have your purchase receipt and product model number (M9) ready when contacting support.

© 2023 TIMU. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FRFMYTBG

More documents and user manuals: **https://manuals.plus/**