

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Aveek](#) /

› **Aveek 2.4GHz Wireless Microphone V2 Instruction Manual**

Aveek V2

Aveek 2.4GHz Wireless Microphone V2 Instruction Manual

Model: V2 | Brand: Aveek

INTRODUCTION

Thank you for choosing the Aveek 2.4GHz Wireless Microphone V2. This manual provides detailed instructions for setting up, operating, and maintaining your wireless microphone system. Please read this manual carefully before use to ensure proper functionality and to maximize your user experience.

PACKAGE CONTENTS

The Aveek Wireless Microphone V2 package typically includes the following items:

- 2 x Aveek Wireless Microphones
- 1 x 2.4GHz Wireless Receiver
- 1 x USB Charging Cable
- 1 x 6.35mm to 3.5mm Adapter
- 1 x User Manual

Plug and Play



Image: Typical contents of the Aveek Wireless Microphone V2 package.

PRODUCT OVERVIEW

The Aveek Wireless Microphone V2 system features advanced DSP chips and a cardioid pickup pattern for clear sound. It operates on a stable 2.4GHz wireless transmission, offering a range of up to 30 meters (100 feet).

Micrófono Inalámbrico de 2.4GHz

Ideal para reuniones familiares, karaoke, fiestas y ocasiones similares.

Audio de alta calidad

Funcionamiento plug and play

12 horas de duración de la batería

Alcance de recepción de 30 metros



Image: Key features for high-fidelity vocal sound, including cardioid pickup and DSP noise reduction.

SETUP INSTRUCTIONS

Follow these steps to set up your Aveek Wireless Microphone V2 system:

- Charge the Devices:** Ensure both microphones and the receiver are fully charged using the provided USB charging cable. A full charge takes approximately 2-3 hours and provides over 12 hours of operation.
- Connect the Receiver:** Plug the 2.4GHz wireless receiver into your audio device's 6.35mm microphone input. If your device has a 3.5mm input, use the included 6.35mm to 3.5mm adapter.
- Power On the Receiver:** Press and hold the power button on the receiver until its indicator lights turn on.
- Power On the Microphones:** Press and hold the power button on each microphone until its display screen illuminates. The microphones will automatically pair with the receiver.
- Adjust Volume:** Adjust the volume on your audio device and the microphone as needed.

Plug and Play

Simplemente encienda el receptor para emparejarlo automáticamente con el micrófono.




Image: Visual guide for the plug-and-play setup process.

OPERATING INSTRUCTIONS

Once set up, the Aveek Wireless Microphone V2 is ready for use:

- Usage:** Speak or sing into the microphone. The 2.4GHz wireless technology ensures a stable connection up to 30

meters (100 feet) without latency.

- **Power On/Off:** Press and hold the power button on the microphone or receiver to turn them on or off.
- **Battery Indicator:** The microphone and receiver have indicators to show battery status. Recharge when the battery is low.

Dispositivos Compatibles

Nota: Solo es compatible con dispositivos con conectores de 6,35 mm o 3,5 mm



Image: Illustration of the 30-meter (100-foot) wireless transmission range.

CHARGING INSTRUCTIONS

The microphones and receiver are equipped with rechargeable batteries:

- Connect the USB charging cable to the charging port on the microphone or receiver.
- Plug the other end of the USB cable into a standard USB power adapter (not included) or a USB port on a computer.
- Charging time is approximately 2-3 hours for a full charge.
- A fully charged device provides over 12 hours of continuous operation.



Image: Charging setup for the microphones and receiver, highlighting battery duration.

COMPATIBILITY NOTES

The Aveek Wireless Microphone V2 is designed for broad compatibility with audio devices:

- **Compatible Devices:** Works with audio devices featuring 6.35mm or 3.5mm microphone input jacks, such as karaoke machines, speakers, audio amplifiers, mixing consoles, and PA systems.
- **Incompatible Devices:** This system is **not compatible** with mobile phones, Bluetooth speakers, computers, tablets, or smart TVs directly. It does not support Bluetooth connectivity.



Image: Examples of compatible audio devices and connector types.



Image: Devices that are not compatible with the wireless microphone system.

MAINTENANCE

To ensure the longevity and optimal performance of your Aveek Wireless Microphone V2, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the microphones and receiver. Avoid using liquid cleaners or abrasive materials.
- **Storage:** Store the devices in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** For long-term storage, charge the batteries to about 50% every few months to prevent deep discharge.
- **Handling:** Handle the microphones and receiver with care to avoid dropping or physical damage.

TROUBLESHOOTING

If you encounter issues with your Aveek Wireless Microphone V2, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No sound from microphone	Microphone or receiver not powered on; Low battery; Incorrect connection; Volume too low.	Ensure both devices are on; Charge batteries; Verify receiver is plugged into the correct input (6.35mm/3.5mm); Increase volume on audio device and microphone.
Sound is intermittent or distorted	Out of range; Interference; Low battery.	Move closer to the receiver (within 30m/100ft); Avoid obstacles; Charge batteries; Move away from other 2.4GHz devices.
Microphone not pairing	Receiver or microphone not in pairing mode; Interference.	Ensure both devices are powered on and within close proximity for initial pairing; Restart both devices.
Short battery life	Batteries not fully charged; Aging batteries.	Ensure full charge (2-3 hours); If issues persist, contact customer support.

SPECIFICATIONS

Model	V2
Brand	Aveek
Connectivity Technology	2.4GHz Wireless
Connector Type	6.35mm / 3.5mm Jack
Special Feature	Noise Reduction (DSP Chip)
Wireless Range	Up to 30 meters (100 feet)
Battery Type	Rechargeable Lithium Ion (2 AA equivalent per microphone, included)
Charging Time	Approx. 2-3 hours
Operating Time	Over 12 hours
Product Weight	640 g (approx. 1.4 lbs)
Package Dimensions	31.6 x 17 x 5.9 cm (approx. 12.4 x 6.7 x 2.3 inches)
Country of Origin	China

SAFETY INFORMATION

Please observe the following safety precautions:

- Do not expose the devices to water or excessive moisture.
- Avoid extreme temperatures and direct heat sources.
- Do not attempt to disassemble or modify the devices. This will void the warranty.
- Keep out of reach of children.

- Use only the provided charging cable.

WARRANTY AND SUPPORT

Aveek products are designed for reliability and performance. For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official Aveek website. Please retain your proof of purchase for warranty claims.