Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bonnlo BL0SM01NO

Bonnlo Fireplace TV Stand User Manual

Model: BL0SM01NO

Introduction

This manual provides essential information for the safe assembly, operation, and maintenance of your Bonnlo Fireplace TV Stand. Please read all instructions carefully before beginning assembly or operation to ensure proper use and longevity of the product.



Image: The Bonnlo Fireplace TV Stand in Natural Oak, featuring a central electric fireplace, two side storage compartments with adjustable shelves, and a top surface supporting a television and various decorative items.

Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons.

- Read all instructions before using this appliance.
- Do not operate any fireplace with a damaged cord or plug, or if the heater malfunctions or has been dropped or damaged in any manner.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).
- This product is designed for indoor use only.

Package Contents

Your Bonnlo Fireplace TV Stand will be delivered in two separate packages, which may arrive at different times. Please ensure all components are present before beginning assembly.

- TV Stand components (Engineered Wood panels, hardware)
- Electric Fireplace Insert
- Remote Control for Fireplace
- Instruction Book (this manual)



Image: The electric fireplace insert, its remote control, and a visual representation of the multiple flame color options. The image also indicates that the product ships in two separate packages.

Setup and Assembly

Assembly is required for the TV stand. The electric fireplace insert is pre-assembled. Follow the step-by-step instructions provided in the included assembly guide. All necessary hardware is included.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface to prevent scratches.
2. **Identify Parts:** Refer to the parts list in the separate assembly guide to identify each component.
3. **Assemble TV Stand:** Follow the numbered steps in the assembly guide to construct the TV stand frame and shelves. Ensure all connections are secure.
4. **Install Fireplace Insert:** Once the TV stand frame is complete, carefully slide the electric fireplace insert into its designated opening.
5. **Adjust Shelves:** The side compartments feature adjustable shelves. Position them according to your storage needs.

Important: For optimal stability and safety, ensure the TV stand is placed on a flat, level surface. This stand is designed to support TVs up to 70 inches and a maximum weight of 420 lbs.



Image: A visual guide demonstrating the compatibility of the TV stand with televisions ranging from 40 to 70 inches in size.



Image: This image demonstrates the flexible storage options of the TV stand, showcasing how shelves can be configured as fixed or adjusted to different heights to accommodate various items.

Operating Instructions (Electric Fireplace)

The electric fireplace provides both aesthetic flame effects and heating functionality. It can be operated via the control panel on the unit or the included remote control.

Control Panel Functions:

- **Power Button:** Turns the fireplace ON/OFF.
- **Flame Color Button:** Cycles through 7 different flame color options.
- **Temperature Control:** Adjusts the heat output from 62°F to 82°F.
- **Timer Button:** Sets an automatic shut-off timer for 0.5 to 6 hours.

Remote Control Functions:

The remote control duplicates all functions available on the control panel for convenient operation.

- Ensure batteries are correctly inserted into the remote control.
- Point the remote directly at the fireplace insert for best response.

Note: The flame effect can be operated independently of the heating function, allowing for ambiance year-round.

Maintenance and Care

Proper care will ensure the longevity and appearance of your TV stand and fireplace.

- **Cleaning the Stand:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Cleaning the Fireplace:** Ensure the fireplace is turned OFF and unplugged before cleaning. Use a soft, dry cloth to clean the glass and exterior. Do not spray liquids directly onto the unit.
- **Dusting:** Regularly dust all surfaces to prevent buildup.
- **Cord Care:** Periodically inspect the power cord for any signs of damage. If damaged, discontinue use and contact customer support.

Troubleshooting

Problem	Possible Cause	Solution
Fireplace does not turn on.	No power, power cord not plugged in, circuit breaker tripped.	Ensure the power cord is securely plugged into a working outlet. Check your home's circuit breaker.
No heat output.	Heat function is off, temperature setting is too low, overheating protection activated.	Activate the heat function. Increase the temperature setting. Unplug the unit for 15 minutes to reset the overheating protection.
Remote control not working.	Dead batteries, remote not pointed at sensor.	Replace batteries. Ensure the remote is pointed directly at the fireplace's sensor.
Stand is wobbly after assembly.	Loose connections, uneven floor.	Check all screws and fasteners to ensure they are tightened. Move the stand to a level surface or use shims if necessary.

Specifications

- **Brand:** Bonnlo
- **Model Name:** Fireplace TV Stand
- **Model Number:** BL0SM01NO
- **Product Dimensions:** 15.75"D x 58.66"W x 23.59"H
- **Material:** Engineered Wood
- **Finish Type:** Natural Oak
- **Color:** Natural Oak
- **Item Weight:** 61.7 Pounds
- **Power Source:** Corded Electric

- **Installation Type:** Freestanding
- **Ventilation Type:** Vent Free
- **Maximum TV Size Compatibility:** Up to 70 inches
- **Maximum Load Capacity:** 420 lbs
- **Fireplace Features:** 7 flame color options, adjustable temperature (62°F–82°F), 0.5–6 hour timer, remote control, overheating protection, CSA Listed.

Warranty and Customer Support

This Bonnlo Fireplace TV Stand comes with a limited warranty. For specific details regarding warranty coverage, please refer to the warranty information included with your product packaging or contact Bonnlo customer service.
For any questions, missing parts, or assistance with assembly or operation, please contact Bonnlo's responsive customer service. Contact information can typically be found on the product packaging or the official Bonnlo website.
You can also visit the Bonnlo brand page on Amazon for more information.

© 2025 Bonnlo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FRGDF2SS

More documents and user manuals: **https://manuals.plus/**