



[Manuals.plus](#) /

> [SlickBlue](#) /

> SlickBlue 47-Inch Lift Top Coffee Table with Hidden Storage - User Manual

## SlickBlue D-CO-JV12613WT

# SlickBlue 47-Inch Lift Top Coffee Table - User Manual

Model: D-CO-JV12613WT

## INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your SlickBlue 47-Inch Lift Top Coffee Table. Please read all instructions carefully before assembly and use to ensure safe and proper functionality. This coffee table features a dual lift tabletop and hidden storage compartments, designed for versatile use in your living space.

## SAFETY INSTRUCTIONS

- Always assemble the product on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten if necessary.
- Do not stand or sit on the lift-top mechanism.
- Keep hands and fingers clear of the lift mechanism when opening or closing the tabletop to prevent pinching.
- Do not overload the tabletop or storage compartments. Refer to specifications for weight limits.
- Keep small parts away from children during assembly.
- If any parts are missing or damaged, do not attempt to assemble or use the product. Contact customer support immediately.

## PARTS LIST

Before beginning assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact SlickBlue customer support.

Part	Description	Quantity
A	Tabletop (Left)	1
B	Tabletop (Right)	1
C	Main Body Frame	1
D	Solid Wood Legs	4
E	Adjustable Center Leg	1

Part	Description	Quantity
F	Pneumatic Lift Mechanism	2 sets
G	Hardware Pack (Screws, Allen Wrench, etc.)	1

## SETUP AND ASSEMBLY

Follow these steps carefully to assemble your coffee table. It is recommended to have two people for assembly.

- 1. Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a soft, clean surface and compare them against the Parts List to ensure everything is present.
- 2. Attach Legs:** Secure the four solid wood legs (D) to the bottom corners of the main body frame (C) using the provided screws from the hardware pack (G). Ensure they are tightened firmly.



Image: Dimensions overview, showing the table's overall size and internal storage measurements. This image also illustrates the general structure where legs would attach.

- 3. Install Center Leg:** Attach the adjustable center leg (E) to the designated central point on the bottom of the main body

frame (C). Adjust its height so it firmly supports the center of the table, preventing sagging.

- 4. Install Lift Mechanisms:** Attach the pneumatic lift mechanisms (F) to the inside of the main body frame (C) according to the pre-drilled holes. Ensure the mechanisms are oriented correctly for smooth operation.
- 5. Attach Tabletops:** Carefully align and attach the left tabletop (A) and right tabletop (B) to their respective pneumatic lift mechanisms (F) using the provided screws. Ensure they are securely fastened and can move freely.

## Lift Top Coffee Table

### Split Top for Versatile Use



**Premium Gas Struts**

- ✓ Smooth Lift
- ✓ Strong Support
- ✓ Quiet Operation

**Squeaky & Wobbly Spring Mechanism**

*Image: Detailed view of the premium gas struts, highlighting smooth lift, strong support, and quiet operation, contrasting with a squeaky spring mechanism. This shows the type of mechanism to be installed.*

- 6. Final Check:** Once assembled, gently test the lift-top function of both tabletops. Ensure all connections are secure and the table is stable.



*Image: The coffee table with both lift-tops raised, revealing the two hidden storage compartments. A laptop and coffee cup are on one raised top, while books and headphones are in the storage.*

## OPERATING INSTRUCTIONS

### Using the Lift-Top Function

- To raise a tabletop, gently pull it upwards from the front edge. The pneumatic mechanism will assist in a smooth and controlled lift.
- To lower a tabletop, gently push it downwards from the front edge. The mechanism will guide it back into the closed position. Ensure hands are clear of the edges to avoid pinching.
- The dual lift design allows each tabletop to be operated independently, moving both forward and slightly sideways for optimal access.



*Image: The coffee table with the right lift-top raised, showcasing the hidden storage compartment. A laptop is placed on the raised top, and a tea set is on the closed left top.*

## **Accessing Hidden Storage**

The hidden storage compartments are located directly beneath the lift-tops. Simply raise the desired tabletop to access the space for storing remotes, magazines, snacks, or other items.



*Image: The coffee table positioned in a living room with a sofa, showing both lift-tops raised. A laptop and coffee are on one side, while books and other items are stored in the compartments.*



Image: A wider view of the coffee table in a living room, with both lift-tops raised, demonstrating its functionality and the accessible storage space.

## MAINTENANCE

- **Cleaning:** Wipe the table surface with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, as they may damage the wood-grain finish. The surface is waterproof for easy cleaning.
- **Spills:** Immediately wipe up any spills to prevent staining or damage to the finish.
- **Mechanism Care:** The pneumatic lift mechanism is designed for durability and quiet operation. No special lubrication is typically required. If you notice any stiffness or unusual noise, ensure no debris is obstructing the mechanism.
- **Leg Stability:** Periodically check the tightness of the leg screws and the adjustment of the center leg to ensure continued stability.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Tabletop does not lift smoothly.	Obstruction in mechanism; mechanism not installed correctly.	Check for any objects blocking the lift mechanism. Review assembly steps for correct mechanism installation.
Table feels wobbly or unstable.	Legs not tightened; center leg not adjusted properly.	Ensure all leg screws are securely tightened. Adjust the center leg to make firm contact with the floor.
Pinching hazard when closing tabletop.	Hands placed too close to the edges.	Always keep hands clear of the tabletop edges and mechanism when lowering. The table has cut-out edges to reduce pinching risk, but caution is still advised.

## SPECIFICATIONS

- **Model Number:** D-CO-JV12613WT
- **Dimensions (Overall):** Approximately 47 inches (Length) x 19 inches (Width) x 15.5 inches (Height, closed) / 21 inches (Height, open)
- **Color:** Walnut
- **Material:** Solid Wood Legs, Engineered Wood with Wood Grain Finish
- **Special Features:** Dual Lift Top, Hidden Storage, Pneumatic Lifting Mechanism, 5-Leg Support System, Waterproof Surface, 10" Floor Clearance
- **Item Weight:** 43 Pounds
- **Assembly Required:** Yes
- **UPC/GTIN:** 610803640909



*Image: The coffee table in its closed position, showcasing its compact form. A laptop, coffee cup, and decorative items are placed on the tabletop.*

## **WARRANTY AND SUPPORT**

For warranty information, missing parts, or any product-related inquiries, please contact SlickBlue customer support. Refer to your purchase documentation for specific warranty terms and contact details.

### **SlickBlue Customer Support:**

*Please refer to the contact information provided with your purchase or visit the official SlickBlue website for the most up-to-date support details.*

