

Telefunkens 50FTV825

Telefunkens 50FTV825 50-inch 4K UHD Smart Fire TV User Manual

Model: 50FTV825

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Telefunkens 50FTV825 50-inch 4K UHD Smart Fire TV. Please read these instructions thoroughly before using the television and retain them for future reference.



Image: Front view of the Telefunkens 50FTV825 50-inch 4K UHD Smart Fire TV.

2. SAFETY INFORMATION

Always follow basic safety precautions when using this television to reduce the risk of fire, electric shock, and injury.

- Do not expose the TV to rain or moisture.
- Ensure proper ventilation around the TV.
- Do not block ventilation openings with items like newspapers, table-cloths, or curtains.
- Do not place the TV on unstable carts, stands, tripods, brackets, or tables.
- Unplug the TV during lightning storms or when unused for long periods.
- Refer all servicing to qualified service personnel.

3. WHAT'S IN THE Box

Verify that all components are present upon unboxing:

- Telefunken 50FTV825 50-inch 4K UHD Smart Fire TV
- Remote Control
- Batteries (for remote control)
- User Manual (this document)

4. SETUP

4.1. Attaching the Stand or Wall Mounting

Carefully place the TV face down on a soft, flat surface. Attach the stand using the provided screws, ensuring it is securely fastened. If wall-mounting, follow the instructions provided with your VESA-compatible wall mount (sold separately).

4.2. Connecting Power and Devices

1. Connect the power cord to the TV and then to a power outlet.
2. Connect external devices (e.g., cable box, gaming console, Blu-ray player) to the HDMI ports.
3. For internet access, connect an Ethernet cable to the LAN port or prepare for Wi-Fi setup.

4.3. Initial Power On and Setup Wizard

Press the power button on the remote control. The TV will guide you through the initial setup process, including language selection, network connection, and Fire TV account login.

5. OPERATING YOUR TELEFUNKEN FIRE TV

5.1. Fire TV Interface

Your TV features an integrated Fire OS, providing access to a wide range of streaming services and applications. Navigate the home screen using the remote control to browse content from Netflix, Prime Video, Disney+, and more.



Todo tu entretenimiento en un solo lugar.

Fire TV reúne Netflix, Prime Video, Disney+, la TV en directo y todos tus favoritos en un solo lugar, para que encuentres rápido series, películas y TV en vivo sin interminables desplazamientos.

Pueden requerirse suscripciones por separado. La disponibilidad de funciones y contenidos puede variar.

Image: The Fire TV home screen displaying available streaming applications.

5.2. Alexa Voice Control

The remote control includes an integrated Alexa button. Press and hold this button to activate voice commands. You can ask Alexa to:

- Change channels or adjust volume.
- Search for movies, TV shows, or music.
- Control compatible smart home devices.
- Check the weather or get information.

Press & ask | alexa

Más corto que un atajo.

Pulsa y pídele a Alexa que busque, inicie y controle tu contenido.



Image: Close-up of the remote control highlighting the Alexa voice button.

5.3. Apple AirPlay

Utilize Apple AirPlay to stream content directly from your iPhone, iPad, or Mac to the television. This allows for easy sharing of photos, videos, and screen mirroring without complex configurations.

5.4. Picture and Sound Enhancements

- **4K UHD + HDR10:** Experience stunning visuals with four times the resolution of Full HD, enhanced by HDR10 for vibrant colors and deep contrasts.
- **Dolby Audio:** Enjoy immersive and clear sound quality, bringing movies, series, and games to life.
- **MEMC:** Motion Estimation, Motion Compensation technology ensures smoother motion in fast-paced scenes.

6. MAINTENANCE

6.1. Cleaning the Screen

Gently wipe the screen with a soft, dry, lint-free cloth. For stubborn marks, lightly dampen the cloth with water or a specialized screen cleaner. Avoid using harsh chemicals or abrasive materials.

6.2. Cleaning the Cabinet

Wipe the TV cabinet with a soft, dry cloth. Do not use liquid or aerosol cleaners directly on the cabinet.

6.3. Software Updates

Your Fire TV will periodically receive software updates. Ensure your TV is connected to the internet to receive these updates, which improve performance and add new features.

7. TROUBLESHOOTING

If you encounter issues with your TV, refer to the following common solutions:

Problem	Possible Cause	Solution
No power	Power cord not connected, power outlet not working.	Check power cord connection. Test outlet with another device.
No picture, but sound is present	Incorrect input source selected.	Press the 'Input' button on the remote to select the correct source.
No sound, but picture is present	Volume is muted or too low. External audio device issues.	Unmute or increase volume. Check connections to external audio systems.
Remote control not working	Batteries are dead or incorrectly inserted. Obstruction between remote and TV.	Replace batteries. Ensure clear line of sight to the TV's IR sensor.
Wi-Fi connection issues	Incorrect password, router issues, TV too far from router.	Re-enter Wi-Fi password. Restart router. Move TV closer to router or use Ethernet.

For further assistance, please contact Telefunken customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	Telefunken
Model Number	50FTV825
Screen Size	50 Inches
Display Technology	LED
Resolution	4K UHD (3840 x 2160)
Refresh Rate	120 Hz

Feature	Detail
Operating System	Fire OS
Special Features	Alexa Compatible, Bezel-less Design, VESA Wall Mountable, HDR - HLG, Smart TV
Connectivity Technology	Bluetooth, Ethernet, HDMI, USB, Wi-Fi
Aspect Ratio	16:9
Product Dimensions (W x D x H)	112 x 26.1 x 68.6 cm
Product Weight	9.56 kg
Country of Origin	Turkey
Energy Efficiency Rating (SDR)	E
Energy Efficiency Rating (HDR)	G

For detailed energy information, refer to the product information sheet and energy label:



ENERG⁺



TELEFUNKEN

50FTV825




54 kWh/1000h

ABCDEF G



104 kWh/1000h

3840 px



2019/2013



50757172

Image: Product Information Sheet detailing technical specifications and energy consumption.

Ficha de información del producto

REGLAMENTO DELEGADO (UE) 2019/2013 DE LA COMISIÓN en lo relativo al etiquetado energético de las pantallas electrónicas

Parámetro	Parámetro o valor y preci- sión	Unidad
1. Nombre o marca comercial del proveedor	TELEFUNKEN	
Dirección del proveedor	Product Management, PARKRING 6 85748 GAR- CHING, DE	
2. Identificador del modelo	50FTV825	
3. Clase de eficiencia energética para el rango dinámi- co normal (SDR)	E	
4. Demanda de potencia en modo encendido en SDR	54,0	W
5. Clase de eficiencia energética para el alto rango di- námico (HDR)	G	
6. Demanda de potencia en modo encendido en HDR, si se aplica	104	W
7. Demanda de potencia en modo desactivado, si pro- cede	no aplicable	W
8. Demanda de potencia en modo preparado, si proce- de	0,5	W
9. Demanda de potencia en modo preparado en red, si procede	2,0	W
10. Categoría de pantalla electrónica	Televisión	
11. Ratio de tamaño	16 : 9	
12. Resolución de pantalla	3 840 x 2 160	pixels
13. Diagonal de la pantalla	126,0	cm
14. Diagonal de la pantalla	50	pulga- das
15. Superficie visible de la pantalla	67,5	dm ²
16. Tecnología usada en el panel	LCD	
17. Control automático de brillo (ABC) disponible	No	
18. Sensor de reconocimiento vocal disponible	No	
19. Sensor de presencia disponible	No	
20. Frecuencia de refresco de la imagen (por defecto)	50	Hz
21. Disponibilidad mínima garantizada de actualizacio- nes de software y de firmware (a partir de la fecha de introducción en el mercado de la última unidad)	8	Años
22. Disponibilidad mínima garantizada de piezas de re- cambio (a partir de la fecha de introducción en el mercado de la última unidad)	7	Años
23. Disponibilidad mínima garantizada de asistencia pa- ra el producto	7	Años
Duración mínima de la garantía general ofrecida por el proveedor	0	Años
24. Tipo de fuente de alimentación	Interna	
25. Fuente de alimentación externa (no normalizada e incluida en la caja del producto)		
i -		
ii Tensión de entrada	-	V
iii Tensión de salida	-	V
26. Fuente de alimentación externa normalizada (o una adecuada, si no está incluida en la caja del producto)		
i -		
ii Tensión de salida requerida	-	V
iii Intensidad de corriente requerida (mínima)	-	A
iv Frecuencia de corriente requerida	-	Hz

Image: Energy Efficiency Label showing ratings for SDR and HDR modes.

Additional energy information can be found at: <https://eprel.ec.europa.eu/qr/2400040>

9. WARRANTY AND SUPPORT

Your Telefunken 50FTV825 television comes with a standard manufacturer's warranty. Please refer to the warranty card included in your packaging for specific terms and conditions, including warranty duration and coverage details.

For technical support, troubleshooting assistance beyond this manual, or warranty claims, please contact Telefunken customer service through their official website or the contact information provided in your warranty documentation.

© 2026 Telefunken. All rights reserved.